

## Gorenje 380375

# Gorenje 380375 Refrigerator Door Handle Instruction Manual

## INTRODUCTION

---

This instruction manual provides essential information for the installation, care, and maintenance of your Gorenje 380375 Refrigerator Door Handle. Please read these instructions carefully before proceeding with installation to ensure proper function and longevity of the product.

## PRODUCT OVERVIEW

---

The Gorenje 380375 is a genuine replacement door handle designed for various Gorenje refrigerator and freezer models. It is made of durable white plastic and is intended for vertical mounting on appliance doors.



Image 1: Front view of the Gorenje 380375 white plastic refrigerator door handle, showing its curved design and mounting points.



Image 2: Angled view of the Gorenje 380375 door handle, highlighting its ergonomic shape and the two screw holes for attachment.

## SPECIFICATIONS

<b>Model Number</b>	380375
<b>Material</b>	Plastic
<b>Color</b>	White
<b>Length</b>	210 mm
<b>Width</b>	90 mm
<b>Depth</b>	30 mm
<b>Weight</b>	87.4 Grams
<b>Mounting Type</b>	Vertical

## COMPATIBLE MODELS

This door handle is compatible with various Gorenje refrigerator and freezer models. Please verify your appliance's model number to ensure compatibility. Known compatible models include, but are not limited to:

- R6093AW
- RK41295W
- RF4275W
- R6168W
- F6241W
- F317AK
- WGF24
- And other models requiring Gorenje part number 380375.

*If you are unsure about compatibility, please contact Gorenje customer support or a qualified technician with your appliance's full model number.*

## INSTALLATION INSTRUCTIONS

Follow these steps to properly install the Gorenje 380375 Refrigerator Door Handle. Ensure the

appliance is unplugged before beginning any installation or repair work.

1. **Safety First:** Disconnect your refrigerator or freezer from the power supply before starting the installation. This prevents accidental injury or damage to the appliance.
2. **Remove Old Handle (if applicable):** If replacing an existing handle, carefully unscrew and remove the old handle. Keep any screws that are in good condition, as they may be reused if compatible.
3. **Position the New Handle:** Align the new Gorenje 380375 handle with the mounting holes on the refrigerator or freezer door. The handle is designed for vertical attachment.
4. **Secure the Handle:** Insert appropriate screws (not included with the handle, typically reused from the old handle or purchased separately if needed) into the mounting holes of the handle and tighten them securely. Do not overtighten, as this can crack the plastic.
5. **Test Stability:** Gently pull on the newly installed handle to ensure it is firmly attached and does not wobble.
6. **Reconnect Power:** Once the handle is securely installed, reconnect the appliance to the power supply.



Image 3: Side view of the Gorenje 380375 door handle, illustrating the design of the mounting ends where screws are inserted.

## CARE AND MAINTENANCE

---

To maintain the appearance and integrity of your Gorenje 380375 door handle, follow these simple care instructions:

- **Cleaning:** Wipe the handle regularly with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic finish.
- **Drying:** After cleaning, dry the handle thoroughly with a clean, soft cloth to prevent water spots.
- **Inspection:** Periodically check the handle for any signs of loosening. If it feels loose, gently tighten the mounting screws.

## TROUBLESHOOTING

---

As a simple mechanical component, the Gorenje 380375 door handle typically requires minimal troubleshooting. However, if you encounter issues:

- **Loose Handle:** If the handle becomes loose, check the mounting screws and tighten them carefully. Do not overtighten.
- **Cracked or Broken Handle:** If the handle is cracked or broken, it indicates physical damage. The handle is not repairable and must be replaced.
- **Difficulty Opening Door:** If the door is difficult to open, ensure the handle is securely attached and not obstructing the door's movement. If the issue persists, it may be related to the refrigerator's door seal or hinges, not the handle itself.

## SUPPORT

---

For further assistance, compatibility inquiries, or to purchase replacement parts, please refer to the official Gorenje website or contact their customer service department. When contacting support, have your appliance's full model number and serial number ready for efficient service.

You can often find more information and support resources on the [Gorenje official website](#).