JustFine DAV-DZ20, DAV-HDX266, DAV-HDZ235, HCD-DZ120, HCD-HDX465

Instruction Manual

JustFine Replacement Remote Control

Compatible Models: DAV-DZ20, DAV-HDX266, DAV-HDZ235, HCD-DZ120, HCD-HDX465

Introduction

Thank you for purchasing the JustFine Replacement Remote Control. This remote is designed to be a high-quality, direct replacement for your original remote, compatible with various Sony Home Theater Audio Video AV Receiver Systems. It comes pre-programmed and requires no additional setup beyond battery installation.

Product Overview

The JustFine Replacement Remote Control is an ergonomic device designed for comfortable handling and intuitive operation of your compatible Sony Home Theater system. It features a comprehensive set of buttons for various functions, including power, volume, channel control, input selection, and specific home theater functions.



Figure 1: Front view of the remote control, displaying all functional buttons.



Figure 2: Back view of the remote control, highlighting the battery compartment.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide the battery compartment cover downwards or press the latch to open it.

3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely.

Note:

- This remote control is pre-programmed and does not require any additional programming steps.
- Batteries are not included with the remote control.

Operating Instructions

Once batteries are installed, the remote is ready for use with your compatible Sony Home Theater AV Receiver System. Point the remote directly at your home theater system's infrared receiver and press the desired function button.

Compatibility

This replacement remote control is compatible with the following Sony Home Theater Audio Video AV Receiver System models:

- DAV-DZ20
- DAV-HDX266
- DAV-HDZ235
- HCD-DZ120
- HCD-HDX465

Ensure your model number is listed above for proper functionality.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface or internal components.
- **Battery Care:** If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent leakage and corrosion.
- **Storage:** Store the remote in a cool, dry place, away from direct sunlight, high temperatures, and humidity.
- **Avoid Drops:** Protect the remote from physical shocks and drops, which can damage internal circuitry.

Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old or depleted batteries with new ones.
  - Ensure there are no obstructions between the remote control and the home theater system's infrared receiver.
  - Make sure you are within the effective operating range and pointing the remote directly at the system.
- **Specific Buttons Not Working:**
  - This remote is designed for the listed models. Verify your home theater system model is compatible.
  - Some functions may be specific to the original remote or the system's capabilities.

If the problem persists after trying these steps, please contact customer support for assistance.

Specifications

Feature	Detail
Brand	JustFine
Product Dimensions	4.53 x 1.57 x 1.38 inches
Item Weight	2.72 ounces
ASIN	B07WHQQQPN
Manufacturer	JustFine
Special Feature	Ergonomic
Max Number of Supported Devices	1
Compatible Devices	Home Theater
Connectivity Technology	Infrared

Warranty and Support

Your JustFine Replacement Remote Control is sold with a commitment to quality and customer satisfaction.

- **Money-Back Guarantee:** We offer a money-back guarantee for your peace of mind.
- **Hassle-Free Return:** Enjoy a hassle-free return process if you encounter any issues.
- **30-Day Quality Warranty:** The product is covered by a 30-day quality warranty from the date of purchase.

For any problems, questions, or support inquiries, please kindly email us. Our customer service team is ready to assist you.

© 2024 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question