



Manuals.plus /

› VIVO /

› Vivo Y200 5G Mobile User Manual

## VIVO Y200 5G

# Vivo Y200 5G Mobile User Manual

Model: Y200 5G | Brand: VIVO

## 1. PRODUCT OVERVIEW

The Vivo Y200 5G smartphone is designed for a seamless mobile experience, featuring advanced camera capabilities, a vibrant display, and efficient performance. It comes equipped with a dual 64MP+2MP rear camera system and a 16MP selfie camera, ensuring high-quality photography. Powered by an SDM 4 Gen 1 Processor built on 6nm architecture, it offers smooth operation. The device includes 8GB RAM and 256GB internal storage, providing ample space for applications and media. Fast charging is supported with 44W capability for its 4800 mAh battery. The 16.94cm (6.67") FHD+ AMOLED display offers a rich visual experience.



Image: Front and back view of the Vivo Y200 5G Mobile in Jungle Green.

## Key Features

- **Camera:** Dual 64MP+2MP Rear Camera with Rear Aura Light and dual color temperature, 16MP Selfie Camera.
- **Display:** 16.94 cm (6.67" inch) FHD+ AMOLED Capacitive multi-touch display with 120Hz refresh rate and 394 ppi.
- **Memory & SIM:** 8GB RAM | 256GB internal memory; LPDDR4X | UFS 2.2.
- **Battery & Charging:** 4800 mAh battery with 44W fast charging (C-Type).
- **Security:** In-display optical fingerprint sensor.
- **Processor:** SD 4 Gen 1 (based on 6nm architecture).
- **Camera Features:** Video, photo, portrait, pano, live photo, slo-mo, time-lapse, supermoon, pro, double exposure, dual view, styles, filters, light effect.

## 2. PACKAGE CONTENTS

---

Ensure all items are present in the box before initial setup:

- Vivo Y200 5G Mobile Phone
- USB Cable
- Power Adapter
- Phone Case
- SIM Tray Ejector
- Screen Protector (pre-applied or included)

## 3. INITIAL SETUP

---

### 3.1. Inserting SIM Card and microSD Card

1. Locate the SIM card tray on the side of the phone.
2. Insert the SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully push the tray back into the phone until it is flush with the side.



Image: Bottom view of the Vivo Y200 5G, showing the USB-C port and SIM tray location.

### 3.2. Powering On/Off

- **To Power On:** Press and hold the Power button (located on the right side) until the Vivo logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options that appear on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options.

### 3.3. Initial Configuration

Upon first power-on, follow the on-screen prompts to complete the initial setup:

- Select your language and region.
- Connect to a Wi-Fi network.
- Accept the End User License Agreement.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, pattern, password, or fingerprint).
- Restore data from a previous device (optional).

## 4. BASIC OPERATION

---

### 4.1. Navigation

- **Home Screen:** Swipe left or right to navigate between home screens.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and access quick settings toggles.
- **Recent Apps:** Swipe up from the bottom and hold (or tap the square navigation button) to view recently used applications.

### 4.2. Camera Usage

The Vivo Y200 5G features a versatile camera system:

- **Rear Camera:** Dual 64MP main sensor with OIS (Optical Image Stabilization) and a 2MP depth sensor.
- **Front Camera:** 16MP for high-quality selfies and video calls.
- **Smart Aura Light:** Enhances low-light photography with intelligent lighting.
- **Modes:** Access various modes like Portrait, Night, Pro, Panorama, Slow-motion, Time-lapse, and more from the camera app interface.



Image: Illustrates key camera features including Night Portrait with Smart Aura Light and 64 MP OIS Anti-Shake Camera.

### 4.3. Display Features

The 16.94 cm (6.67 inch) FHD+ AMOLED display offers vibrant colors and deep blacks. The 120Hz refresh rate provides a smoother scrolling and gaming experience. Adjust display settings such as brightness, dark mode, eye protection, and color temperature in the 'Display & Brightness' section of the Settings app.

### 4.4. Battery and Charging

The device is equipped with a 4800 mAh battery and supports 44W fast charging. Use the provided Vivo 44W charger and USB Type-C cable for optimal charging speed. Avoid using non-certified chargers to prevent damage to the device.

### 4.5. Fingerprint Sensor

The Vivo Y200 5G features an in-display optical fingerprint sensor for secure and convenient unlocking. To set up, navigate to Settings > Security > Fingerprint and follow the on-screen instructions to register your fingerprints.

## 5. CARE AND MAINTENANCE

---

To ensure the longevity and optimal performance of your Vivo Y200 5G, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid using harsh chemicals or abrasive materials.
- **Protection:** Use the provided phone case and screen protector to guard against scratches and minor impacts.
- **Temperature:** Avoid exposing the phone to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.
- **Water Resistance:** The device is not rated for water resistance. Avoid contact with liquids.
- **Software Updates:** Regularly check for and install system updates to ensure your device has the latest features, security patches, and performance improvements.
- **Storage Management:** Periodically clear unnecessary files, cache, and uninstall unused apps to maintain optimal storage and performance.

## 6. TROUBLESHOOTING COMMON ISSUES

---

Problem	Possible Solution
Phone not turning on	Ensure the battery is charged. Connect to the charger for at least 15 minutes. If still unresponsive, perform a force restart by holding the Power button for 10-15 seconds.
Battery drains quickly	Check for background apps consuming power. Reduce screen brightness. Disable unused features like Wi-Fi, Bluetooth, GPS when not needed. Update software.
Apps crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Update the app to the latest version. If the issue persists, reinstall the app.
Poor network signal	Ensure SIM card is correctly inserted. Try restarting the phone. Check if Airplane Mode is off. Contact your network provider if the issue persists in different locations.
Fingerprint sensor not working	Ensure your finger is clean and dry. Re-register your fingerprints in Settings > Security > Fingerprint. Ensure the screen protector is not interfering.

## 7. TECHNICAL SPECIFICATIONS

---

Feature	Specification
Operating System	FunTouch OS 12
RAM	8 GB
Internal Storage	256 GB
Processor	SD 4 Gen 1 (6nm architecture)
CPU Speed	1.8, 2.0 GHz
Product Dimensions	16.2 x 7.5 x 0.8 cm
Item Weight	190 g
Batteries	1 Lithium Ion battery (included)
Battery Power Rating	4800 mAh
Display Resolution	1080 x 2400
Connectivity	Bluetooth, USB, Wi-Fi, Cellular
GPS	GLONASS
Audio Jack	USB Type-C
Colour	Jungle Green

## 8. WARRANTY INFORMATION AND SUPPORT

Your Vivo Y200 5G Mobile is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or warranty claims, please contact Vivo customer service. You can find contact information on the official Vivo website or through the support section within your device's settings.

**Manufacturer:** vivo Mobile India Pvt Ltd

**Address:** vivo Mobile India Pvt Ltd Tech-1 and Tech-2, World Trade Centre, Plot no-TZ-13A, Techzone (I.T. Park), Greater Noida, Uttar Pradesh, India. Pin - 201308

For further assistance, you may also visit the official VIVO Store on Amazon: [VIVO Store](#)