

vivo V30 5G

vivo V30 5G Smartphone User Manual

Model: V30 5G

[Introduction](#) [What's in the Box](#) [Product Overview Specifications](#) [Setup Warranty & Support](#) [Operating](#) [Maintenance](#) [Troubleshooting](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your vivo V30 5G smartphone. Please read this manual thoroughly before using your device to ensure optimal performance and longevity. The vivo V30 5G features a powerful Qualcomm Snapdragon 7 Gen 3 Processor, a vibrant 17.22 cm (6.78") FHD+ AMOLED Display, advanced dual 50MP+50MP rear cameras, and a 50MP selfie camera, all powered by a 5000 mAh battery with 80W fast charging capabilities.

2. WHAT'S IN THE BOX

Upon unboxing your vivo V30 5G, verify that all the following items are included:

- vivo V30 5G Smartphone
- Adapter (for charging)
- USB Cable (Type-C)
- Phone Case
- Screen Protector (pre-applied or in box)
- SIM Tray Ejector
- Quick Start Guide (may be separate from this manual)

3. PRODUCT OVERVIEW

Familiarize yourself with the physical components of your vivo V30 5G smartphone.



Image 3.1: Front and Rear View of vivo V30 5G. The image displays the smartphone from two angles: the front, highlighting its large AMOLED display, and the rear, showcasing the dual camera module with OIS branding and the vivo logo at the bottom.

3.1 Front View

- **Display:** 17.22 cm (6.78") FHD+ AMOLED screen for vivid visuals.
- **Front Camera:** 50MP selfie camera, typically located at the top center of the display.
- **Earpiece:** Located above the front camera.

3.2 Rear View

- **Dual Rear Cameras:** Two 50MP cameras, typically arranged in a module, often with OIS (Optical Image Stabilization) branding.
- **Flash:** LED flash unit for low-light photography.
- **vivo Logo:** Brand identification at the bottom.

3.3 Side and Bottom Views

- **Power Button:** Usually on the right side, used to turn the device on/off or wake/sleep the screen.
- **Volume Buttons:** Typically located above the power button, used to adjust media and call volume.
- **USB Type-C Port:** At the bottom, for charging and data transfer.
- **SIM Card Tray:** Located on one of the sides, requires the SIM ejector tool to open.
- **Microphone/Speaker:** Small openings for audio input and output.

4. SETUP

4.1 Installing the SIM Card

1. Locate the SIM card tray on the side of your device.
2. Insert the provided SIM tray ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down, ensuring they are correctly oriented.
4. Carefully push the SIM tray back into the slot until it is flush with the device's side.

4.2 Initial Power On

Press and hold the **Power Button** (typically on the right side) for a few seconds until the vivo logo appears on the screen. The device will then boot up.

4.3 Basic Setup

Follow the on-screen prompts to complete the initial setup:

- Select your preferred language and region.
- Connect to a Wi-Fi network for internet access.
- Sign in with your Google Account or create a new one.
- Set up screen lock methods (PIN, pattern, password, or fingerprint).
- Review and accept terms and conditions.

5. OPERATING YOUR DEVICE

5.1 Display and Navigation

Your vivo V30 5G runs on Funtouch OS 14, based on Android 14. Navigate the interface using touch gestures:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Camera Usage

The device features a dual 50MP+50MP rear camera system and a 50MP front camera. Open the Camera app to access various shooting modes, including:

- **Photo:** Standard still image capture.
- **Portrait:** For artistic photos with blurred backgrounds.
- **Video:** Record high-resolution videos.
- **Night:** Enhanced low-light photography.
- **Pro:** Manual controls for advanced users.

5.3 Charging the Battery

Connect the USB Type-C cable to the phone's charging port and the other end to the provided 80W fast charging adapter. Plug the adapter into a power outlet. The device supports rapid charging for its 5000 mAh battery.

5.4 Connectivity

- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi* to connect to available wireless networks.
- **Bluetooth:** Go to *Settings > Connected devices > Bluetooth* to pair with Bluetooth accessories like headphones or speakers.
- **Mobile Data:** Ensure your SIM card is active and mobile data is enabled in *Settings > Network & internet > Mobile network*.

5.5 Security Features

The vivo V30 5G includes a Fingerprint Recognition sensor for secure and quick unlocking. Set it up via *Settings > Security > Fingerprint*.

6. MAINTENANCE

6.1 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to *Settings > System > System update*

6.2 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials, which can damage the finish. The device is not water resistant, so avoid exposure to liquids.

6.3 Battery Care

To prolong battery life:

- Avoid exposing the device to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use only the original charger and cable provided.

7. TROUBLESHOOTING

If you encounter issues with your vivo V30 5G, try the following common solutions:

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Screen frozen or unresponsive:** Perform a force restart by pressing and holding the Power button for about 10-15 seconds until the device restarts.
- **Apps crashing:** Clear the cache of the problematic app (*Settings > Apps > [App Name] > Storage & cache > Clear cache*) or reinstall the app.
- **Poor network signal:** Check if your SIM card is properly inserted. Try restarting the device or toggling Airplane Mode on and off.
- **Charging issues:** Ensure the charging cable and adapter are securely connected and undamaged. Try a different power outlet.

If problems persist, contact customer support or visit an authorized service center.

8. SPECIFICATIONS

Brand	vivo
Model	V30 5G
Operating System	Funtouch OS 14 Global (Based on Android 14)
Processor	Qualcomm Snapdragon 7 Gen 3
RAM	12 GB
Internal Storage	256 GB
Display	17.22 cm (6.78") FHD+ AMOLED, 2800 x 1260 Pixels, 400 PPI
Rear Camera	Dual 50MP + 50MP
Front Camera	50MP
Battery Capacity	5000 mAh
Charging	80W Fast Charging, USB Type-C
SIM Card Type	Nano-SIM (Single SIM)
Biometric Security	Fingerprint Recognition
Dimensions	16.4 x 7.5 x 0.7 Centimeters
Weight	186 Grams
Connectivity	Bluetooth, USB, Wi-Fi, LTE
Headphones Jack	No headphone jack
Water Resistance	Not Water Resistant

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your vivo V30 5G smartphone comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or exposure to liquids.

9.2 Customer Support

For technical assistance, service inquiries, or warranty claims, please contact vivo customer support. You can find contact details on the official vivo website or through the support information provided with your device.

Manufacturer: vivo Mobile India Pvt Ltd

Address: Tech-1 and Tech-2, World Trade Centre, Plot no-TZ-13A, Techzone (I.T. Park), Greater Noida, Uttar Pradesh, India. Pin - 201308

