Kid Trax KT1283

Kid Trax Toddler Marvel's Spider-Man Premium Toddler Quad Ride-On Instruction Manual

Model: KT1283

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Kid Trax Toddler Marvel's Spider-Man Premium Toddler Quad Ride-On. Please read all instructions carefully before use.

The Spider-Man themed ride-on is designed for children aged 18 to 30 months, with a maximum weight capacity of 44 lbs. It features bouncy springy web bumpers, a light-up spider emblem, easy push-button acceleration, and Power Trax rubber traction strip tires for a smooth ride.

Safety Information

WARNING: Adult Assembly Required.

- This product contains small parts. Sharp edges and points may be present during assembly.
- Continuous adult supervision is required to avoid serious injury.
- Never use near motor vehicles, streets, swimming pools, hills, steps, or sloped driveways.
- Always wear shoes, a helmet, and pads.
- Allow only one rider.
- If batteries are required: batteries must be handled by an adult. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

What's in the Box

Verify that all components are present before beginning assembly:

- 6V Marvel Spider-Man Premium Toddler Quad
- 6-Volt Rechargeable Battery
- Wall Charger
- Assembly Hardware (if applicable, refer to separate assembly guide)

Setup and Assembly

Adult assembly is required for this product. Please follow the detailed assembly instructions provided in the separate assembly guide included with your purchase. Ensure all parts are securely fastened before initial use.

Key assembly steps typically include:

1. Attaching wheels and axles.
2. Connecting the steering mechanism.
3. Installing the seat.
4. Connecting the battery (refer to the "Charging the Battery" section for initial charge).



Image: The Kid Trax Spider-Man Toddler Quad with dimensions labeled: 27.76" L, 15.75" W, 18.31" H. This image helps in understanding the physical size of the assembled product.

Charging the Battery

The ride-on is powered by a 6-volt rechargeable battery. For optimal performance, fully charge the battery before the first use and after each play session.

1. Locate the direct connect charging port on the vehicle.
2. Plug the included wall charger into a standard electrical outlet.
3. Connect the charger to the vehicle's charging port.
4. Allow the battery to charge for the recommended duration (refer to the separate battery charging instructions for specific times, typically 8-12 hours for a full charge). Do not overcharge.
5. Disconnect the charger once charging is complete.



Image: Front view of the Spider-Man Quad, showing icons for "1.5 MPH Max Speed" and "6V Rechargeable Battery". This illustrates key operational features and the battery type.

Operating Instructions

Ensure the child is wearing appropriate safety gear, including a helmet and shoes, and is under continuous adult supervision.

1. **Getting On:** Help the child safely mount the quad, ensuring they are seated comfortably and their feet are on the footrests.
2. **Starting the Ride:** The quad features easy push-button acceleration. Instruct the child to press the button located on the handlebar to move forward. Releasing the button will stop the vehicle.
3. **Steering:** The handlebar controls the direction of the quad. Guide the child on how to turn left and right.
4. **Features:**
    - **Light-Up Spider Emblem:** The spider emblem on the handlebar lights up when the vehicle accelerates, adding to the interactive experience.
    - **Springy Web Bumpers:** The web bumpers are designed to move in and out, providing a playful element.
    - **Power Trax Rubber Traction Strip Tires:** These tires are designed to provide a smooth and stable ride on various surfaces.



Image: A young child happily riding the 6V battery-powered Spider-Man Quad. This demonstrates the product in use.



Image: Side view of the Spider-Man Quad, highlighting the "Rubber Traction Strip Tires" for improved grip and ride quality.

Your browser does not support the video tag.

Video: An official product video from Pacific Cycle Inc. showcasing the Kid Trax Spider-Man Toddler Quad in action, demonstrating its features and operation.

Maintenance

- **Battery Care:** Always recharge the battery after each use. Store the battery in a cool, dry place. If storing the vehicle for an extended period, charge the battery once a month to prolong its lifespan.
- **Cleaning:** Wipe the vehicle with a damp cloth to clean. Do not use harsh chemicals or abrasive cleaners. Avoid spraying water directly onto electrical components.
- **Inspection:** Regularly check all nuts, bolts, and fasteners to ensure they are tight. Inspect the wheels and tires for wear and tear.

Troubleshooting

If the vehicle is not operating correctly, check the following:

- **Vehicle Not Moving:**
  - Ensure the battery is fully charged and properly connected.
  - Check that all electrical connections are secure.
  - Verify the push-button accelerator is functioning correctly.
- **Slow Operation:**
  - The battery may need recharging.
  - Ensure the vehicle is not overloaded (maximum weight 44 lbs).
  - Operating on soft surfaces like grass can reduce speed.
- If problems persist, contact customer support.

Specifications

Feature	Detail
Brand	Kid Trax
Model Number	KT1283
Age Range	18-30 Months
Maximum Weight Capacity	44 lbs
Battery	6-Volt Rechargeable
Max Speed	1.5 MPH
Material	Plastic
Item Weight	14.33 Pounds
Item Dimensions (L x W x H)	27.9" x 12" x 15.7"
Assembly Required	Yes

Warranty and Support

Warranty: This product comes with a one-year limited warranty on the product itself and a 6-month limited warranty on the battery, provided by the manufacturer, Pacific Cycle Inc.

For warranty claims, replacement parts, or technical assistance, please contact Kid Trax customer support. Refer to the contact information provided in your product packaging or visit the official Kid Trax website.

© 2024 Kid Trax. All rights reserved. Marvel and Spider-Man are trademarks of Marvel Entertainment LLC.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question