

[Manuals.plus](#) /

› [LITBLOOM](#) /

› LITBLOOM 4FT 200 LED Lighted Birch Twig Tree Instruction Manual (Model TS-3W4.5V)

LITBLOOM TS-3W4.5V

LITBLOOM 4FT 200 LED Lighted Birch Twig Tree Instruction Manual

Model: TS-3W4.5V

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and safety of your LITBLOOM 4FT 200 LED Lighted Birch Twig Tree (Model TS-3W4.5V). Please read this manual thoroughly before initial use to ensure proper function and longevity of your product.

PACKAGE CONTENTS

- One (1) LITBLOOM 4FT Lighted Birch Twig Tree with 200 LED Fairy Lights
- One (1) Power Adapter (4.5V)
- Four (4) Ground Stakes (for outdoor use)

SAFETY INFORMATION

Important Safety Instructions:

- Keep the product away from children and heated sources to avoid accidents.
- Do **NOT** cover the birch tree with cloth, paper, or any other items when in use.
- Do **NOT** unplug by pulling on the cord. Always hold the plug to insert or remove it from the power source.
- Cut off the power supply before cleaning for safety.
- The product is designed with low output voltage (4.5V) to ensure safety.
- The product has an IP44 waterproof rating, suitable for outdoor use, but the power adapter should be protected from direct water exposure.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Assemble Base:** Insert the tree trunk firmly into the provided base. Ensure it is stable.
3. **Shape Branches:** The branches are flexible. Gently bend and shape them to achieve your desired aesthetic. Avoid excessive force to prevent damage.

4. **Secure for Outdoor Use (Optional):** If placing outdoors, use the four included ground stakes to secure the base to the ground for added stability.
5. **Connect Power:** Connect the power adapter cable to the tree's power input. Then, plug the power adapter into a standard electrical outlet.



Image: The LITBLOOM 4FT Lighted Birch Twig Tree, fully assembled and illuminated, showcasing its warm white LED fairy lights and realistic birch bark texture.



Image: Two LITBLOOM Lighted Birch Twig Trees of different heights (4FT and 6FT) displayed indoors, demonstrating their decorative potential.

OPERATING INSTRUCTIONS

- Once the power adapter is connected to a functional electrical outlet, the tree's 200 LED fairy lights will illuminate.
- There are no additional controls for light modes; the lights provide a steady warm white glow.
- To turn off the tree, simply unplug the power adapter from the electrical outlet.
- The tree is suitable for both indoor and outdoor use due to its IP44 waterproof rating. Ensure the power adapter is protected from direct moisture when used outdoors.



Image: Three LITBLOOM Lighted Birch Twig Trees arranged outdoors against a stone wall, demonstrating their suitability for exterior decoration.

MAINTENANCE

- **Cleaning:** Always disconnect the tree from the power source before cleaning. Use a soft, dry cloth to gently wipe down the branches and base. Do not use liquid cleaners, abrasive materials, or immerse any part of the tree in water.
- **Storage:** When not in use, unplug the tree and carefully reshape the branches to their original compact form. Store the tree in a cool, dry place, ideally in its original packaging, to protect it from dust and damage.

TROUBLESHOOTING

- **Lights Not Illuminating:**
 - Ensure the power adapter is securely connected to both the tree's input and a functional electrical outlet.
 - Verify that the electrical outlet is active by testing it with another device.

- Check the power cord and adapter for any visible signs of damage. If damaged, discontinue use and contact customer support.

• **Flickering Lights:**

- Ensure all connections, especially between the tree and the power adapter, are secure and tight.
- If flickering persists, unplug the tree for a few minutes and then plug it back in. If the issue continues, contact customer support.

• **Tree Unstable:**

- Ensure the tree trunk is fully and firmly seated into its base.
- For outdoor placement, ensure all four ground stakes are fully inserted into stable ground.

SPECIFICATIONS

Feature	Detail
Brand	LITBLOOM
Model Number	TS-3W4.5V
Product Dimensions	20"D x 20"W x 48"H (4FT)
Item Weight	2 Pounds
Material	Plastic
Light Type	LED Fairy Lights
Number of LEDs	200
Light Color	Warm White
Voltage	4.5V (Low Output)
Waterproof Rating	IP44
Recommended Uses	Indoor, Outdoor
Assembly Required	Yes
Batteries Required	No

WARRANTY AND SUPPORT

LITBLOOM is committed to providing quality products and customer satisfaction. If you have any questions, concerns, or require assistance with your LITBLOOM Lighted Birch Twig Tree, please contact LITBLOOM customer support. Refer to your purchase documentation or the official LITBLOOM website for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question