Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

xingzhihua ZC/LW-01

xingzhihua ZC/LW-01 Universal Replacement AC Remote Control User Manual

1. Introduction

This manual provides instructions for the xingzhihua ZC/LW-01 Universal Replacement AC Remote Control, designed for use with CHIGO Air Conditioners. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

2. Product Overview

- **Model:** ZC/LW-01
- **Compatibility:** This remote control is a replacement for specific CHIGO Air Conditioner models. Verify that the buttons and model number match your original remote control before use. **Note:** ZC/LW-01 is not compatible with ZH/LW-03.
- **Features:** Designed to replace old or broken remote controls, offering compatibility with most functions of the original remote.
- **Display:** The temperature display on this remote is in Celsius, not Fahrenheit.

3. Setup

3.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



This image displays the rear view of the ZC/LW-01 remote control. The battery compartment cover is removed, revealing two empty slots for AAA batteries and the 'ZC/LW-01 Rated voltage 3V.DC' label.



This image shows the back of the ZC/LW-01 remote control with the battery compartment securely closed. The model number 'ZC/LW-01' and 'Rated voltage 3V.DC' are visible.

4. Operating Instructions

To operate your air conditioner using the ZC/LW-01 remote control, point the remote directly at the air conditioner's infrared receiver. Ensure there are no obstructions between the remote and the AC unit.

4.1 Basic Functions

- **Power On/Off:** Press the **POWER** button to turn the air conditioner on or off.
- **Mode Selection:** Use the **MODE** button to cycle through available operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **Temperature Adjustment:** Use the **TEMP UP** (▲) and **TEMP DOWN** (▼) buttons to set your desired temperature. Remember, the display is in Celsius.
- **Fan Speed:** Press the **FAN** button to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Function:** If your AC unit supports it, use the**SWING** button to activate or deactivate the louver swing function.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote control's range decreases, the display becomes dim, or it stops responding.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage to the device. Store the remote in a cool, dry place away from direct sunlight.

6. Troubleshooting

- **Remote control not working:**
  - Check if the batteries are inserted with correct polarity (+/-).
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Verify that the remote control is compatible with your specific CHIGO AC model.
- **Display issues (e.g., dim, no display):**
  - Ensure batteries are properly installed and have sufficient charge.
  - Note that the temperature display is in Celsius.
- **Limited range:**
  - Replace batteries.
  - Ensure a clear line of sight to the AC unit.

7. Specifications

Model	ZC/LW-01
Brand	xingzhihua
Use	Air Conditioning AC Remote Control
Connectivity Technology	Infrared
Maximum Range	10 Meters
Controller Type	Button Control
Max Number of Supported Devices	1

Rated Voltage	3V DC
UPC	738944979778

8. Warranty and Support

This product is covered by the standard warranty provided by the retailer or manufacturer. For specific warranty details, product support, or technical assistance, please contact your point of purchase or the manufacturer, xingzhihua, directly. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question