

Vivo T3 5G Smartphone User Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Vivo T3 5G smartphone. It covers device setup, operational guidelines, maintenance procedures, and troubleshooting tips. The Vivo T3 5G is equipped with a MediaTek Dimensity 7200 processor, a Sony IMX882 OIS camera sensor, and a 16.94 cm (6.67 inch) 120 Hz Ultra Vision AMOLED display. It also features dual stereo speakers and a 5000 mAh battery with 44 W FlashCharge capability.

2. PACKAGE CONTENTS

Please verify that all the following items are included in your product package:

- Vivo T3 5G Smartphone
- Power Adapter
- Phone Case
- SIM Tray Ejector
- Screen Protector (pre-applied or in box)
- USB Cable

3. DEVICE OVERVIEW

Familiarize yourself with the physical components and layout of your Vivo T3 5G smartphone.



Image 3.1: Vivo T3 5G smartphone, front and rear view. This image displays the Vivo T3 5G smartphone from both the front and rear. The front shows the display with a punch-hole camera, while the rear highlights the triple camera module and the device's finish.

Key physical features include the power button, volume rocker, USB-C port, speaker grille, microphone, SIM card tray, front camera, and rear camera module.

4. SETUP

4.1. Inserting the SIM Card

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card (if applicable) into the tray with the gold contacts facing down.
4. Carefully reinsert the tray into the device until it clicks into place.

4.2. Initial Power On and Configuration

1. Press and hold the Power button until the Vivo logo appears on the screen.
2. Follow the on-screen prompts to select your language, region, and connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one to access Google services and the Play Store.
4. Set up screen lock methods such as PIN, pattern, password, fingerprint, or face unlock for security.

5. OPERATING

5.1. Display and Navigation

The Vivo T3 5G features a 16.94 cm (6.67 inch) Full HD+ 120 Hz Ultra Vision AMOLED display. Navigate the interface using touch gestures: tap to select, swipe to scroll, pinch to zoom. Access quick settings by swiping down from the top of the screen.

5.2. Camera Functions

The device is equipped with a 50MP main camera with OIS and a 16MP front camera. Open the Camera application to access various modes including Photo, Portrait, Night, and Video. The camera supports ultra-stable 4K video recording and Super Night Portrait mode for enhanced low-light photography.

5.3. Battery and Charging

The Vivo T3 5G includes a 5000 mAh battery. Use the provided 44 W FlashCharge adapter and USB cable for optimal charging speed. Avoid using non-certified chargers to prevent damage to the device or battery.

5.4. Connectivity

The smartphone supports 5G cellular networks, Wi-Fi (2.4 GHz and 5 GHz), and Bluetooth for wireless connections. Access these settings via the Quick Settings panel or the main Settings application.

6. MAINTENANCE

6.1. Cleaning Your Device

To clean your Vivo T3 5G, power it off and gently wipe the screen and body with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid using harsh chemicals or abrasive materials.

6.2. Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Updates can be found in **Settings > System > System update**

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Vivo T3 5G.

- **Device not turning on:** Ensure the battery is charged. Connect the device to the charger for at least 10 minutes, then try pressing and holding the Power button again.
- **Charging issues:** Verify that the charger and USB cable are securely connected and undamaged. Try a different power outlet or charger.
- **Network connectivity problems:** Check if Airplane Mode is off. Restart the device. Ensure your SIM card is properly inserted and your mobile data plan is active.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the issue persists, restart the phone.
- **Slow performance:** Close unnecessary background apps. Clear cache and temporary files. Consider performing a factory reset if performance issues continue after other troubleshooting steps (back up your data first).

8. SPECIFICATIONS

Model Number	V2334
Operating System	Android 14
Processor	MediaTek Dimensity 7200 (CPU Speed: 2.8 GHz)
RAM	8 GB
Internal Storage	128 GB
Display	16.94 cm (6.67 inch) Full HD+ AMOLED, 120 Hz, 1080 x 2400 pixels
Rear Camera	50MP + 2MP
Front Camera	16MP
Battery Capacity	5000 mAh
Charging	44W FlashCharge
Connectivity	5G, Bluetooth, Wi-Fi
Dimensions (LxWxH)	16.6 x 7.6 x 0.8 cm
Weight	186 g
Special Features	Dust Resistance, GPS
Audio Jack	No headphone jack

9. WARRANTY AND SUPPORT

Your Vivo T3 5G smartphone is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use conditions.

For technical assistance, warranty claims, or service inquiries, please contact Vivo customer support through their official website or authorized service centers. Keep your proof of purchase for warranty validation.