

xingzhihua ZH/TY-01

xingzhihua ZH/TY-01 Air Conditioner Remote Control Instruction Manual

Model: ZH/TY-01 | Brand: xingzhihua

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your xingzhihua ZH/TY-01 Air Conditioner Remote Control. This remote is designed as a replacement for specific Chigo air conditioning units. Please review this manual thoroughly to ensure proper usage and to maximize the lifespan of your remote control.

2. PRODUCT OVERVIEW

The ZH/TY-01 remote control features a clear LCD display and intuitively placed buttons for easy operation of your air conditioner. Its ergonomic design ensures comfortable handling.



Figure 1: Front view of the ZH/TY-01 remote control, showing the LCD screen, power button, mode button, fan speed button, and temperature adjustment buttons.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.



Figure 2: Back view of the ZH/TY-01 remote control with the battery compartment open, showing the slots for two AAA batteries.

3.2 Initial Use

The ZH/TY-01 remote control is designed as a direct replacement for compatible Chigo air conditioning units. No complex pairing or programming is typically required. Once batteries are installed, point the remote at your air conditioner and begin operation.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions for optimal control of your air conditioner.

4.1 Button Functions

- **Power Button (U):** Turns the air conditioner ON or OFF.
- **M Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).

- **Fan Button (s):** Adjusts fan speed (e.g., Low, Medium, High, Auto).
- **Temperature Up/Down Buttons (t / u):** Increases or decreases the set temperature.
- **SWING Button:** Controls the vertical louver movement for air distribution.
- **TURBO Button:** Activates rapid cooling or heating for a short period.
- **TIMER Button:** Sets a timer for the air conditioner to turn ON or OFF automatically.
- **AIR FLOW Button:** Adjusts the horizontal louver direction.
- **SLEEP Button:** Activates sleep mode, which adjusts temperature and fan speed for comfortable sleep.
- **HOLD Button:** May be used to maintain current settings or for specific functions depending on the AC unit.
- **CLEAN Button:** Initiates a self-cleaning function for the indoor unit (if supported by AC).
- **LAMP Button:** Controls the display light on the indoor unit.
- **°C/°F Button:** Toggles the temperature display between Celsius and Fahrenheit. Note: The remote's display is in Celsius.
- **RST Button:** Resets the remote control to default settings.
- **CLK Button:** Sets the current time on the remote's display.

5. MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's display becomes dim or when the remote no longer responds to commands. Always replace both batteries simultaneously with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

6. TROUBLESHOOTING

- **Remote not responding:** Check battery orientation and ensure batteries are not depleted. Replace batteries if necessary. Ensure there are no obstructions between the remote and the air conditioner's receiver.
- **Display is dim or blank:** This indicates low battery power. Replace the batteries.
- **Air conditioner not responding to commands:** Verify that the remote is pointed directly at the air conditioner's infrared receiver. Ensure the air conditioner is powered on. Confirm that the remote control model ZH/TY-01 is compatible with your specific Chigo air conditioning unit.

7. SPECIFICATIONS

- **Model:** ZH/TY-01
- **Brand:** xingzhihua
- **Compatible Devices:** Chigo Air Conditioners (specific models)
- **Power Source:** 3V DC (2 x AAA batteries)
- **Connectivity Technology:** Infrared



Figure 3: Back view of the ZH/TY-01 remote control, displaying the model number 'ZH/TY-01' and rated voltage '3V.DC'.

8. WARRANTY AND SUPPORT

This remote control is designed to be compatible with most functions of the original remote control for specific Chigo air conditioning units. For specific warranty information or technical support, please refer to the documentation provided with your original air conditioning unit or contact the seller directly. Ensure the model number ZH/TY-01 matches your original remote for full compatibility.

