

Blufree BT601

Blufree Bluetooth Pool Speaker User Manual

Model: BT601 | Brand: Blufree

INTRODUCTION

Thank you for purchasing the Blufree Bluetooth Pool Speaker. This portable, waterproof speaker is designed to provide high-fidelity audio and vibrant light shows, perfect for pools, spas, and outdoor environments. Please read this manual carefully before use to ensure proper operation and maintenance.



Image: The Blufree Bluetooth Pool Speaker, blue on top and clear on the bottom, floating in water with a vibrant, multi-colored light display visible through its lower half.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Blufree Bluetooth Pool Speaker
- Charging Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls:




Image: A detailed diagram highlighting the various buttons and ports on the Blufree speaker, including the light mode button, microphone, volume/track controls, multifunction button, and DC 5V charging jack.

1. **Light Mode Button:** Press to cycle through light modes.
2. **Microphone:** For hands-free calling.

3. **Vol-/Previous:** Short press for volume down, long press for previous track.
4. **Multifunction Button:** Power ON/OFF, Play/Pause, Answer/End Call.
5. **Vol+/Next:** Short press for volume up, long press for next track.
6. **DC 5V Charging Jack:** For connecting the charging cable.

CHARGING THE SPEAKER

Before first use, fully charge the speaker. A full charge provides up to 8 hours of playtime.

- Connect the supplied charging cable to the DC 5V charging jack on the speaker.
- Connect the other end of the charging cable to a USB power adapter (not included) or a computer's USB port.
- The charging indicator light will illuminate during charging and turn off when fully charged.
- Charging time is approximately 2-3 hours.

SETUP AND BLUETOOTH PAIRING

Follow these steps to pair your speaker with a Bluetooth-enabled device:

1. **Power On:** Press and hold the Multifunction Button for 3 seconds until you hear a power-on tone and the LED indicator flashes blue, indicating it's in pairing mode.
2. **Activate Bluetooth:** On your smartphone, tablet, or other Bluetooth device, enable Bluetooth.
3. **Select Speaker:** Search for "BT601" in the list of available Bluetooth devices and select it to connect.
4. **Connection Confirmation:** Once successfully paired, you will hear a confirmation tone, and the LED indicator will turn solid blue.
5. **Reconnection:** The speaker will automatically attempt to reconnect to the last paired device when powered on.

Hands-Free Calling



Image: This image demonstrates the hands-free calling capability of the speaker, showing a phone screen with an incoming call and the speaker positioned nearby, allowing for convenient communication.

OPERATING INSTRUCTIONS

Basic Audio Playback

- **Play/Pause:** Short press the Multifunction Button.
- **Volume Up:** Short press the Vol+/Next button.
- **Volume Down:** Short press the Vol-/Previous button.
- **Next Track:** Long press the Vol+/Next button.
- **Previous Track:** Long press the Vol-/Previous button.

Hands-Free Calling

- **Answer Call:** Short press the Multifunction Button when a call comes in.

- **End Call:** Short press the Multifunction Button during a call.
- **Reject Call:** Long press the Multifunction Button when a call comes in.

Light Modes

The speaker features 7 different color changing themes and various flashing modes.

- Press the Light Mode Button to cycle through the available light patterns and colors.
- Continue pressing until you find your desired light effect.



Image: This image displays two Blufree speakers illuminating with different RGB LED colors, highlighting the customizable light show feature of the product.

Floating Bluetooth Speaker



Image: The Blufree speaker floats effortlessly in a pool, providing entertainment for swimmers, showcasing its waterproof and floatable design.



Image: The speaker enhances a relaxing bath experience, emitting musical notes and demonstrating its suitability for indoor water environments like hot tubs and spas.

Ultra Portable -- Enjoy Music Everywhere !



Image: This collage illustrates the speaker's versatility, showing it used for various activities such as playing lullabies, at a party, during driving, and during yoga, highlighting its ultra-portable design.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Waterproof Care:** While IP68 rated, ensure the charging port cover is securely closed before submerging in water. After use in chlorinated or saltwater, rinse the speaker with fresh water and dry thoroughly.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** To preserve battery life, charge the speaker at least once every 3 months if not used regularly.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the charging cable and try again.
Cannot pair with Bluetooth device.	Ensure the speaker is in pairing mode (flashing blue LED). Make sure Bluetooth is enabled on your device. Move the speaker closer to your device (within 15 meters). Forget "BT601" from your device's Bluetooth list and try pairing again. Ensure no other devices are currently connected to the speaker.
No sound or low volume.	Increase volume on both the speaker and your connected device. Ensure the speaker is properly paired. Check if water has entered the speaker grille; if so, gently shake it out.
Lights are not working.	Press the Light Mode Button to activate or cycle through light modes. Ensure the speaker has sufficient battery charge.

SPECIFICATIONS

Feature	Detail
Model	BT601
Bluetooth Version	5.0
Wireless Range	Up to 15 meters (49 feet)
Waterproof Rating	IP68 (Immersion up to 3 feet for 30 minutes)
Battery Capacity	1600 mAh
Playtime	Up to 8 hours (varies with volume and light usage)
Charging Time	Approx. 2-3 hours
Dimensions (D x W x H)	5" x 5" x 3.4"
Weight	0.634 ounces (approx. 18 grams)
Speaker Output Power	10 Watts
Input Voltage	3.7 Volts

IMPORTANT SAFETY INFORMATION

- Do not disassemble, repair, or modify the speaker. This may cause damage, electric shock, or fire.
- Keep the speaker away from extreme temperatures, direct sunlight, and open flames.
- Do not expose the speaker to strong magnetic fields.
- Ensure the charging port is completely dry before charging.
- Use only the provided charging cable.
- Keep out of reach of children.

WARRANTY AND SUPPORT

Blufree products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Blufree website. For further assistance, please contact Blufree customer service.

© 2024 Blufree. All rights reserved.