

[Manuals.plus](#) /

> [Braun](#) /

> Braun MultiServe Coffee Machine KF9150BK Instruction Manual

## Braun KF9150BK

# Braun MultiServe Coffee Machine Instruction Manual

Model: KF9150BK

## 1. INTRODUCTION

The Braun MultiServe Coffee Machine KF9150BK is designed to provide a superior coffee experience, offering flexibility from a single cup to a full carafe. Its advanced features ensure consistent brewing quality and allow for personalized coffee preferences. This manual will guide you through the proper setup, operation, and maintenance of your new coffee machine to ensure optimal performance and longevity.



Figure 1: Braun MultiServe Coffee Machine KF9150BK in Stainless/Black.

## 2. WHAT'S INCLUDED

Upon unpacking your Braun MultiServe Coffee Machine, please ensure all the following components are present:

- Braun MultiServe Coffee Machine Unit
- Glass Carafe (10-Cup)
- Gold Tone Permanent Filter
- Charcoal Water Filter
- Measuring Scoop
- Instruction Manual (this document)
- Quick Start Guide



Figure 2: All components included with the Braun MultiServe Coffee Machine.

## 3. SETUP

Before first use, follow these steps to prepare your coffee machine:

1. **Unpack and Clean:** Remove all packaging materials. Wash the glass carafe, permanent filter, and water reservoir with warm, soapy water. Rinse thoroughly and dry.
2. **Install Charcoal Filter:** If included, soak the charcoal filter in cold water for 5 minutes. Insert it into the filter holder within the water reservoir.
3. **Fill Water Reservoir:** Remove the water reservoir from the unit. Fill it with fresh, cold water up to the desired level, or to the 'MAX' line for a full carafe. Reinsert the reservoir securely.



Figure 3: Filling the removable water reservoir.

4. **Place Filter Basket:** Insert the permanent filter (or a paper filter) into the filter basket. Place the filter basket into its designated slot.



Figure 4: The permanent filter and filter basket assembly.

5. **First Clean Cycle:** Before brewing coffee, run a full carafe cycle with only water to clean the internal components. Discard the water after the cycle.

## 4. OPERATING INSTRUCTIONS

---

Your Braun MultiServe Coffee Machine offers various brewing options:

### 4.1. Brewing Coffee

1. **Add Coffee Grounds:** Use the included measuring scoop to add your desired amount of coffee grounds to the filter. Refer to the scoop markings for recommended amounts based on brew size.
2. **Select Brew Size:** Use the MultiServe Dial System to select your desired brew size, ranging from 5 oz, 8 oz, 12 oz, 16 oz, 20 oz, Half Carafe, or Full Carafe.



Figure 5: Available brewing sizes on the MultiServe Dial System.

3. **Choose Brew Style (BrewChoice Plus):** Select your preferred coffee strength using the BrewChoice Plus buttons:

- **Light:** For a milder coffee.
- **Gold:** Certified by the Specialty Coffee Association for optimal flavor.
- **Bold:** For a stronger, more intense coffee.
- **Over Ice:** Specifically designed for brewing concentrated coffee over ice.



Figure 6: BrewChoice Plus options including Light, Gold, Bold, and Over Ice.

4. **Place Carafe/Cup:** For carafe brewing, ensure the glass carafe is placed on the warming plate. For single-serve brewing, slide down the Cup Shelf and place your mug directly underneath the dispenser.



Figure 7: Single-serve brewing with the adjustable Cup Shelf.

5. **Start Brewing:** Press the 'Brew' button to begin the brewing process. The machine will automatically calculate the precise water flow, temperature, and speed using the ExactBrew System.



Figure 8: Illustration of ExactBrew Technology and TempSensor System for optimal brewing.

6. **Freshness Indicator:** The display will show a Freshness Indicator, letting you know how long the brewed coffee has been sitting on the warming plate.

#### 4.2. Hot Water Dispensing

The machine features a separate hot water spout to prevent coffee taste transfer when preparing tea or other hot beverages.

1. **Place Cup:** Place your cup under the dedicated hot water spout.
2. **Select Water:** Press the 'Water' button on the control panel.
3. **Dispense:** The machine will dispense hot water.

### 5. MAINTENANCE

Regular cleaning and maintenance will ensure your Braun MultiServe Coffee Machine continues to perform

optimally.

## 5.1. Daily Cleaning

- **Carafe and Filter:** After each use, wash the glass carafe, carafe lid, permanent filter, and filter basket with warm, soapy water. These parts are also top-rack dishwasher safe.
- **Exterior:** Wipe down the exterior of the machine with a damp cloth. Do not use abrasive cleaners.

## 5.2. Descaling

Over time, mineral deposits can build up in your coffee machine, affecting performance. The machine has a 'Clean' button to initiate a descaling cycle.

- Follow the instructions in the detailed user manual for the specific descaling procedure using a descaling solution.
- The 'Clean' indicator light will illuminate when descaling is recommended.

## 5.3. Charcoal Water Filter Replacement

- The charcoal water filter should be replaced approximately every 2 months, or after 60 uses, whichever comes first.
- Refer to the full user manual for detailed instructions on replacing the filter.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Braun MultiServe Coffee Machine, please refer to the following common solutions. For more complex problems, consult the full User Manual (PDF) linked in the 'Warranty & Support' section.

- **Coffee Not Brewing:** Ensure the machine is plugged in, the water reservoir is filled, and the filter basket is correctly inserted. Check if the 'Brew' button was pressed.
- **Weak Coffee:** Increase the amount of coffee grounds or select the 'Bold' brew strength setting. Ensure the charcoal filter is not clogged and is replaced regularly.
- **Overflowing Filter Basket:** Do not overfill the filter basket with coffee grounds. Ensure the carafe is properly placed on the warming plate and the drip stop is not engaged if brewing a carafe.
- **Error Codes (e.g., E21):** Specific error codes indicate internal issues. Please refer to the detailed User Manual for a list of error codes and their corresponding troubleshooting steps.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	Braun
Model Number	KF9150BK
Color	Stainless / Black
Product Dimensions	7.1"D x 13"W x 15"H
Item Weight	10 pounds

Coffee Maker Type	Drip Coffee Machine
Filter Type	Reusable (Gold Tone Permanent Filter)
Coffee Input Type	Pod-free
Operation Mode	Fully Automatic
Human Interface Input	Buttons, Dial
Special Features	Freshness Indicator, Unique Carafe Design, TempSensor System, BrewChoice Plus, MultiServe Dial System, Hot Water Spout

## 8. WARRANTY & SUPPORT

---

The Braun MultiServe Coffee Machine KF9150BK comes with a **3-year limited warranty**. Please retain your proof of purchase for warranty claims.

For detailed information on warranty terms, troubleshooting, and product support, please refer to the official user manuals:

- [User Guide \(PDF\)](#)
- [User Manual \(PDF\)](#)

For further assistance, please contact Braun customer service.