

## Brigii Y120



# Brigii Mini Vacuum Cleaner

MODEL: Y120 USER MANUAL

## Introduction

Thank you for choosing the Brigii Mini Vacuum Cleaner, Model Y120. This compact and versatile device is designed for efficient cleaning of small spaces, offering both vacuuming and blowing functions. Its lightweight and portable design makes it ideal for use in cars, on desktops, keyboards, and other hard-to-reach areas. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new vacuum cleaner.



Image: The Brigii Mini Vacuum Cleaner shown with its included crevice tool and brush attachment.

### Key Features:

- **Lightweight and Portable:** Weighing only 356g, designed for easy carrying and storage.
- **Suction and Blowing Dual Function:** Capable of both vacuuming dust and blowing debris.
- **Reliable Lithium Battery:** Built-in 2000 mAh\*2 battery providing up to 20 minutes of runtime.
- **Three Crevice Tools:** Includes interchangeable nozzles for various cleaning needs.
- **Reusable and Washable HEPA Filter:** Easy to clean and maintain for sustained performance.

### Safety Instructions

Please read all safety instructions carefully before using the Brigii Mini Vacuum Cleaner to prevent injury or damage to the device.

- Do not immerse the vacuum cleaner or its charging cable in water or other liquids.
- Keep the device away from heat sources, direct sunlight, and flammable materials.
- Do not use the vacuum cleaner to pick up large objects, sharp objects, liquids, or burning/smoking materials.
- Ensure the filter is properly installed before operation.
- Do not operate the vacuum cleaner with a damaged cord or plug.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the provided charging cable and adapter (if included) for charging.

## Product Overview and Components

Familiarize yourself with the parts of your Brigii Mini Vacuum Cleaner and its included accessories.



Image: The Brigii Mini Vacuum Cleaner disassembled, showing the main unit, dust cup, and various attachments.

### Included Components:

- Main Vacuum Unit
- USB Charging Cable
- Crevice Tool
- Brush Nozzle

- HEPA Filter (pre-installed)
- Additional Nozzle (for blowing function)

## Setup

Before first use, ensure the vacuum cleaner is fully charged.

### 1. Charging the Battery:

Connect the USB charging cable to the charging port on the vacuum cleaner. Plug the other end into a USB power adapter (not included) or a computer USB port. The indicator light will show charging status (e.g., red for charging, green for fully charged). A full charge takes approximately 3-4 hours.




Image: The Brigii Mini Vacuum Cleaner being charged via its USB port.

### 2. Attaching Accessories:

Select the desired nozzle (crevice tool or brush nozzle) and firmly insert it into the suction opening of the vacuum cleaner. For the blowing function, attach the appropriate nozzle to the exhaust port at the opposite end of the vacuum.

## Operating Instructions

Learn how to effectively use your Brigii Mini Vacuum Cleaner for various cleaning tasks.

### 1. Powering On/Off:

Press the power button located on the main unit to turn the vacuum cleaner on. Press it again to turn it off.

### 2. Vacuuming Function:

Attach the desired suction nozzle (crevice tool for narrow gaps, brush nozzle for surfaces like keyboards). Point the nozzle towards the area to be cleaned and move it slowly to pick up dust and debris. The powerful

suction is effective for small particles.



Image: The Brigii Mini Vacuum Cleaner being used to clean a car interior with the brush attachment.

### 3. **Blowing Function:**

To use the blowing function, attach the blowing nozzle to the exhaust port (the end opposite to the suction opening). This function is useful for blowing dust out of crevices, keyboard keys, or other hard-to-reach areas where vacuuming might not be ideal.



Image: Illustration showing the dual suction and blowing capabilities of the vacuum cleaner.

## Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 1. Emptying the Dust Container:

When the dust container is full or suction power decreases, it's time to empty it. Twist the dust container counter-clockwise to detach it from the main unit. Dispose of the collected debris. Reattach by twisting clockwise until secure.

### 2. Cleaning the HEPA Filter:

The HEPA filter is located inside the dust container. Gently remove it. Tap the filter to dislodge dust. For a more thorough cleaning, rinse the filter under running water. Ensure the filter is completely dry before reinserting it into the dust container and reassembling the vacuum. Do not use detergents or hot water.

### 3. Cleaning the Exterior:

Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.

### 4. Storage:

Store the vacuum cleaner in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully charged before long-term storage to maintain battery health.

## Troubleshooting

If you encounter any issues with your Brigii Mini Vacuum Cleaner, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum cleaner for 3-4 hours.
Weak suction power.	Dust container is full.	Empty the dust container.
	HEPA filter is clogged.	Clean or replace the HEPA filter.
	Nozzle or hose is blocked.	Check and clear any blockages in the nozzle or air pathways.
Charging indicator light not working.	Charging cable or adapter is faulty.	Try a different USB cable or power adapter.
	Charging port is damaged.	Contact customer support.

If the problem persists after trying these solutions, please contact Brigii customer support for further assistance.

## Specifications

Detailed technical specifications for the Brigii Mini Vacuum Cleaner Y120.

## Small Size

Portable and easy to storage



Image: Visual representation of the Brigii Mini Vacuum Cleaner's compact size and dimensions.

Feature	Specification
Model Number	Y120
Brand	Brigii
Product Dimensions	7.3"L x 2.5"W x 2.5"H
Item Weight	12.8 ounces (356g)
Power (Wattage)	40W
Battery Type	Lithium Polymer (2000 mAh*2)
Runtime	Up to 20 minutes
Charging Time	3-4 Hours
Filter Type	HEPA Filter (Reusable and Washable)
Dust Cup Capacity	500 Milliliters
Noise Level	75 dB
Connectivity Technology	USB
Special Feature	Bagless, Cordless, Suction and Blowing Dual Function

## Warranty and Support

Brigii products are manufactured with high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Brigii website.

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact Brigii customer service. You can often find contact information on the product packaging or the brand's official website.

An electronic version of this user guide is also available for download:[Brigii Mini Vacuum Cleaner Y120 User Guide \(PDF\)](#)

© 2024 Brigii. All rights reserved.

## Related Documents

--	--

# Brigii

Cordless Vacuum Cleaner  
User Guide  
Y120



Before using the product, please read this user guide carefully, and strictly follow the instructions of the user guide after reading. Please read it properly to ensure safety.

## Important safety instructions

TO AVOID SAFETY ACCIDENTS OR MACHINE FAILURE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED WHEN USING YOUR BRIGII CORDLESS VACUUM CLEANER, INCLUDING THE FOLLOWING:

- 1 Never use this product as a toy. Be extra cautious when children or pets are around. It should be used after the children and pets are not in the room. Do not use this product as a toy.
- 2 Never use the cordless vacuum cleaner on wet surfaces. Avoid using it on wet floors, carpets, or other wet surfaces. Do not use it on wet surfaces.
- 3 Do not use it on stairs or other high places. Make sure the machine is on a flat surface. Do not use it on stairs or other high places.
- 4 Do not use it on surfaces that are slippery or uneven. Do not use it on surfaces that are slippery or uneven.
- 5 Do not use it on surfaces that are flammable or explosive. Do not use it on surfaces that are flammable or explosive.
- 6 Do not use it on surfaces that are hot or near a fire. Do not use it on surfaces that are hot or near a fire.
- 7 Do not use it on surfaces that are near water. Do not use it on surfaces that are near water.
- 8 Do not use it on surfaces that are near electrical outlets. Do not use it on surfaces that are near electrical outlets.
- 9 Do not use it on surfaces that are near power lines. Do not use it on surfaces that are near power lines.
- 10 Do not use it on surfaces that are near children or pets. Do not use it on surfaces that are near children or pets.
- 11 Do not use it on surfaces that are near fire. Do not use it on surfaces that are near fire.
- 12 Do not use it on surfaces that are near water. Do not use it on surfaces that are near water.
- 13 Do not use it on surfaces that are near electrical outlets. Do not use it on surfaces that are near electrical outlets.
- 14 Do not use it on surfaces that are near power lines. Do not use it on surfaces that are near power lines.
- 15 Do not use it on surfaces that are near children or pets. Do not use it on surfaces that are near children or pets.
- 16 Do not use it on surfaces that are near fire. Do not use it on surfaces that are near fire.
- 17 Do not use it on surfaces that are near water. Do not use it on surfaces that are near water.
- 18 Do not use it on surfaces that are near electrical outlets. Do not use it on surfaces that are near electrical outlets.
- 19 Do not use it on surfaces that are near power lines. Do not use it on surfaces that are near power lines.
- 20 Do not use it on surfaces that are near children or pets. Do not use it on surfaces that are near children or pets.

## Product Diagram



## Product Specifications

Product Name	Cordless Vacuum Cleaner	Model Number	Y120
Charging Voltage	5V DC	Battery Capacity	2000mAh
Charging Current	1.0A	Product Weight	1.0kg
Rated Power	10W	Dimensions	100x100x100mm

## Main Usage



## Function Descriptions

- 1 Power switch: Press and hold to turn on, and press to turn off.
- 2 Mode: Three modes are available for adjustment.
- 3 Dust container: Rotate to open for dust collection and take out the dust, and then close the cover.
- 4 Charging indicator light status: When the battery is full, the red light will flash. When charging, the red light will be on. When the light is off, the battery is fully charged and is in working status. Do not charge for too long.

## Troubleshooting

- Turn off the power before troubleshooting.
- 1 During use, abnormal noise is heard. The filter may not be placed. Check the location of the filter. Turn off the power, remove the filter, and replace it.
  - 2 In case of red and yellow light, check if the suction port or filter is clogged.
  - 3 If the motor does not start, check if the switch is pressed or there is no power.

Brigii  
Website: www.brigii.com  
Email: support@brigii.com

## Brigii Y120 Cordless Vacuum Cleaner User Guide

User guide for the Brigii Y120 Cordless Vacuum Cleaner, detailing important safety instructions, product diagram, specifications, main usage scenarios, function descriptions, and troubleshooting tips.

**Brigii**  
Mini Vacuum  
User Guide  
Y120 Pro



Before using the product, please read the user guide carefully, and strictly follow the requirements of the user guide. After reading, please keep it properly for future reference.

Brigii

**Important safety instructions**


TO AVOID SAFETY ACCIDENTS OR MACHINE FAILURE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED WHEN USING YOUR BRIGII CORELESS VACUUM CLEANER, INCLUDING THE FOLLOWING:

1. Read all the product use key features to pay attention when it's used or stored. Please read after the delivery and make sure they are all well understood.
2. Keep your hair, loose clothing, fingers and body parts away from the rotating parts to avoid entanglement or injury. Do not use the product on the face or neck.
3. Do not use the product on the machine or inside. Never use the machine when the power is charged, remove dust, cotton, hair, or other items that may be inside.
4. Turn off the vacuum cleaner before removal or installation of the filter.
5. The filter should be cleaned at least once a month, and should be changed up a time when there is dust on the filter.
6. The vacuum cleaner shall not be operated when the filter is not installed properly.
7. When use, check the filter for proper installation or damage.
8. Avoid use, approaching high temperature objects, and disassemble the unit.
9. Do not use with any liquid or particles.
10. It is forbidden to handle energy objects, burning or smoldering objects such as cigarettes, candles, incense, or other flammable items.
11. Please do not professional are prohibited from opening it for repair or modifying internal wiring.

3

Brigii

**Product Diagram**



**Product Specifications**

Product Name	Mini Vacuum	Model Number	Y120 Pro
Charging Voltage	DC 5V	Battery Capacity	2500mAh
Charging Current	200mA	Product Weight	0.4kg
Rated Power	20W	Dimensions	120x120x120mm

2

Brigii

**Main Usage**



1

Brigii

**Function Description**

1. Power switch: Press and hold to turn on, and press 3 again to turn off.
2. Filter: Three models are available for replacement.
3. Rotate the entrance: Rotate to open the dust cap and take out the dust which will be used and disposable.
4. When it's working or charging, it displays red light. When it's fully charged, it shows green light.

**Troubleshooting**


- (Turn off the power before troubleshooting)
1. If during use, abnormal noise is heard, the user may be blocked. Check the suction of the bag or motor, immediately turn off the power, remove the bag, and check the motor.
  2. In case of reduced suction, check if the suction port or filter is clogged.
  3. If the motor fails to operate, check if the switch is pressed or there is no power.


4

**Brigii**  
Website: www.brigii.com  
Email: support@brigii.com

[Brigii Y120 Pro Mini Vacuum, Air Duster & Hand Pump User Guide](#)

User guide for the Brigii Y120 Pro, a 3-in-1 Mini Vacuum, Air Duster, and Hand Pump. Details safety, features, specifications, usage, maintenance, and troubleshooting.

 <p><b>Brigii M2</b> Handheld Vacuum Cleaner User Guide</p> <p><small>Always plug the product, please read the user guide carefully, and follow the instructions on safety, if you have any questions, please contact the customer service for more information. Please do not use the product if you are not sure about the safety. After reading, please keep it properly for later reference.</small></p>	<p><a href="#">Brigii M2 Handheld Vacuum Cleaner User Guide</a></p> <p>User guide for the Brigii M2 Handheld Vacuum Cleaner, covering important safety instructions, product diagrams, specifications, and troubleshooting.</p>
 <p><b>Brigii MX30</b></p> <p>Dust Cup Filter Indicator On-Off Switch Charging Port Air Outlet Multi-Surface Tool 2 in 1 Stick Nozzle Type-C Charging Cable Base</p>	<p><a href="#">Brigii MX30 Cordless Handheld Vacuum Cleaner User Manual</a></p> <p>Official user manual for the Brigii MX30 cordless handheld vacuum cleaner. Includes operation, display status, troubleshooting, and cleaning and maintenance instructions for optimal performance.</p>





[pdf] User Manual Instructions Guide Warranty Accessories

Miele Triflex HX2 Cordless Vacuum Cleaner User Guide Manuals 71szZ TrdKL ref dp product quick view m media amazon images I |||

Skip to content Manuals User Manuals Simplified. Miele Triflex HX2 Cordless Vacuum Cleaner User Gui ... ay vary from model to model. www.aeg.com support.emea.aeg.com Please handle battery pack... Brigii Y120 Cordless Vacuum Cleaner User Guide Brigii Y120 Cordless Vacuum Cleaner User Guide Important Saf...

lang:en score:42 filesize: 184.08 K page\_count: 4 document date: 2022-09-19



Rated Power:	35W	Dimensions:	65 X 85 X 285 mm
--------------	-----	-------------	------------------

## [Brigii Y120 Cordless Vacuum Cleaner User Guide](#)

User guide for the Brigii Y120 Cordless Vacuum Cleaner, detailing important safety instructions, product diagram, specifications, main usage scenarios, function descriptions, and troubleshooting tips.

lang:en score:21 filesize: 2.04 M page\_count: 1 document date: 2020-05-09

**Brigii**

**Main Usage:** //



Keyboard cleaning



Car health cleaning



Sofa cleaning



Gap cleaning



Pet hair cleaning



Cabinet cleaning

**Brigii**

**Function Description:** //

- 1 Power switch: Press and hold it to turn on, and press it again to turn off.
- 2 Nozzle: Three nozzles are available for replacement.
- 3 Roll-lee maintenance: Rotate to open the dust cap and take out the filter, wash it with water and dry naturally.
- 4 Charging indicator light status: When the battery is used up, the red light flashes quickly. When charging, the red light flashes quickly. The red light not flashing means full charging and is in working status (full charging takes about 4 hours).

**Troubleshooting:** //

(Turn off the power before troubleshooting)

- 1 If, during use, abnormal noise is found, the filter may not be placed, causing suction of foreign matter. Immediately turn off the power, remove the foreign matter and replace the filter.
- 2 In case of reduced suction, check if the suction port or filter is clogged.
- 3 If the motor fails to operate, check if the switch is pressed or there is no power.




Website: [www.brigii.com](http://www.brigii.com)  
Email: [support@brigii.com](mailto:support@brigii.com)

**Brigii**

**Mini Vacuum**

**User Guide**

Y120 Pro





Before using the product, please read the user guide carefully, and strictly follow the requirements of the user guide. After reading, please keep it properly for future reference.

Brigii

### Important safety instructions: //


TO AVOID SAFETY ACCIDENTS OR MACHINE FAILURE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED WHEN USING YOUR BRIGII CORDLESS VACUUM CLEANER, INCLUDING THE FOLLOWING:

- 1 Never use this product as a toy. Be sure to pay attention when children use or approach it. Please look after the children and make sure they will not use this product as a toy.
- 2 Keep your hair, loose clothing, fingers and body parts away from running parts such as the machine air intake and brush roll. Do not point the nozzle, the dust collection rod or the tip at the eyes or ears, or put it in the mouth.
- 3 Do not put items in the machine air intake. Never use the machine when the air intake is clogged; remove dust, cotton, hair, or other items that may reduce airflow.
- 4 Turn off the vacuum cleaner before removal or installation of the filter.
- 5 The filter should be cleaned at least once a month, and should be cleaned up in time when there is obvious dust on the filter.
- 6 The vacuum cleaner shall not be operated when the filter is not installed properly.
- 7 Before reuse, check the filter for proper installation or damage.
- 8 Avoid rain, approaching high temperature objects, and direct exposure to sunlight.
- 9 Contact with any liquid is prohibited.
- 10 It is forbidden to inhale sharp objects, burning or smelly objects (such as glass, carbon fiber, cigarettes, or aerosolized ash).
- 11 Those other than professionals are prohibited from opening it for repair or modifying internal wiring.

1

Brigii

### Product Diagram: //



### Product Specifications: //

Product Name:	Mini Vacuum	Model Number:	Y120 Pro
Charging Voltage:	DC 5V	Battery Capacity:	2500mAh x 2
Charging Current:	1500mA	Product Net Weight:	About 420g
Rated Power:	50W	Dimensions:	85x65x115mm

2

Brigii

### Main Usage: //



Keyboard cleaning



Car interior cleaning



Sofa cleaning



Gap cleaning



Vacuum storage bags pumping



Cabinet cleaning

3

Brigii

### Function Description: //

- 1 Power switch: Press and hold it to turn on, and press it again to turn off.
- 2 Nozzle: Three nozzles are available for replacement.
- 3 Routine maintenance: Rotate to open the dust cap and take out the filter, wash it with water and dry naturally.
- 4 When it is working or charging, it displays a red light. When it is fully charged, it shows a green light.

## [Brigii Y120 Pro Mini Vacuum, Air Duster & Hand Pump User Guide](#)

User guide for the Brigii Y120 Pro, a 3-in-1 Mini Vacuum, Air Duster, and Hand Pump. Details safety, features, specifications, usage, maintenance, and troubleshooting.

lang:en score:19 filesize: 718.52 K page\_count: 1 document date: 2020-07-09

## Troubleshooting: //

(Turn off the power before troubleshooting)

- 1 If dusting was abnormal noise is heard, the filter may not be placed, causing suction of foreign matter. Immediately turn off the power, remove the foreign matter and replace the filter.
- 2 In case of reduced suction, check if the suction port or filter is clogged.
- 3 If the motor fails to operate, check if the switch is pressed or there is no power.


4

# Brigii

Website: [www.brigii.com](http://www.brigii.com)  
Email: [causpo@brigii.com](mailto:causpo@brigii.com)

## Brigii

ミニ クリーナー  
ユーザー ガイド  
Y120 Pro



ご使用前に、この取扱説明書をよくお読みください。お読み直しをお願いいたします。お読みになった後は、お使いになる方が必要な時にいつでも見ることでお困りへ大切に保管してください。

[\[pdf\]](#)

Brigii Y120pro Brigii Y120 Pro @ DC 5V 2500mAhX2  
1500mA B1g3tR4IJ1S m media amazon images I |||

...

lang:en score:10 filesize: 2.07 M page\_count: 5 document date: 2021-08-24