

Braven 604203553

Braven BRV-Mini Waterproof Portable Wireless Speaker User Manual

Model: 604203553 | Brand: Braven

INTRODUCTION

The Braven BRV-Mini is a compact, rugged, and waterproof portable wireless speaker designed for outdoor adventures and everyday use. It delivers powerful audio with boosted bass and offers up to 12 hours of playtime. Its IPX7 waterproof rating means it can be submerged in water and even floats, making it ideal for poolside or beach use. The speaker also supports wireless pairing for an immersive stereo experience and includes a built-in microphone for hands-free calls.



Image: The Braven BRV-Mini speaker in black, featuring its top controls and a durable red and black lanyard.



Image: The Braven BRV-Mini speaker positioned on a rock in an outdoor setting, demonstrating its rugged and portable nature.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Braven BRV-Mini Speaker
- USB-C Charging Cable
- Owners Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the buttons and ports on your BRV-Mini speaker:

- **Power Button:** Located on the top surface, typically indicated by a power symbol (⏻). Press and hold to power on/off.
- **Volume Up (+) Button:** Increases audio volume.
- **Volume Down (-) Button:** Decreases audio volume.

- **Play/Pause/Bluetooth Button:** Multifunction button for playing/pausing music and initiating Bluetooth pairing.
- **USB-C Charging Port:** Located under a protective flap, used for charging the speaker.
- **Microphone:** Integrated for speakerphone functionality.
- **Lanyard:** Attached for easy carrying or hanging.

SETUP

1. Charging Your Speaker

1. Locate the USB-C charging port, usually protected by a rubber flap to maintain waterproofing.
2. Open the flap and connect the included USB-C charging cable to the speaker.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The LED indicator on the speaker will show charging status (e.g., solid red for charging, off or green for fully charged).
5. Ensure the rubber flap is securely closed after charging to maintain the speaker's waterproof rating.

2. Powering On/Off

- **To Power On:** Press and hold the Power button () for approximately 2-3 seconds until you hear an audible tone and the LED indicator lights up.
- **To Power Off:** Press and hold the Power button () for approximately 2-3 seconds until you hear an audible tone and the LED indicator turns off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within close proximity to your Bluetooth-enabled device (e.g., smartphone, tablet).
2. The speaker will automatically enter Bluetooth pairing mode when first powered on, indicated by a flashing LED light (e.g., blue). If not, press and hold the Play/Pause/Bluetooth button for 2-3 seconds to enter pairing mode.
3. On your device, go to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. You should see "BRV-Mini" (or similar) in the list.
5. Select "BRV-Mini" to connect. Once connected, the LED indicator will typically turn solid blue, and you may hear a confirmation tone.

OPERATING

Playing Audio

- Once paired, start playing audio from your connected device.
- Use the Volume Up (+) and Volume Down (-) buttons on the speaker to adjust the volume.
- Press the Play/Pause/Bluetooth button once to play or pause audio.

Wireless Pairing (Stereo Experience)

To achieve an immersive stereo sound, you can pair two BRV-Mini speakers together:

1. Ensure both BRV-Mini speakers are powered on and not connected to any other Bluetooth device.
2. On the first speaker, press and hold the Play/Pause/Bluetooth button until it enters pairing mode

(flashing LED).

3. Repeat the same step for the second speaker.
4. The two speakers will automatically search for each other and connect. You will hear a confirmation tone when they are successfully paired for stereo sound.
5. Once the two speakers are paired together, connect your device to one of the BRV-Mini speakers via Bluetooth as described in the "Bluetooth Pairing" section.

Speakerphone Functionality

The BRV-Mini features an integrated microphone for hands-free phone calls:

- When a call comes in, the music will pause.
- Press the Play/Pause/Bluetooth button once to answer the call.
- Speak towards the speaker for clear communication.
- Press the Play/Pause/Bluetooth button once again to end the call.
- To reject an incoming call, press and hold the Play/Pause/Bluetooth button for 2 seconds.

MAINTENANCE

Waterproofing (IPX7)

The BRV-Mini is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. To maintain its waterproof integrity:

- Always ensure the rubber flap covering the USB-C charging port is securely closed before exposing the speaker to water.
- Do not attempt to charge the speaker if it or the charging port is wet.
- Rinse the speaker with fresh water after exposure to saltwater or chlorinated water.

Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these may damage the finish or waterproof seals.
- Ensure the speaker is completely dry before storing or charging.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on	<ul style="list-style-type: none">• Ensure the speaker is charged. Connect it to a power source using the USB-C cable.• Press and hold the Power button for 3-5 seconds.

Problem	Possible Solution
Cannot pair with Bluetooth device	<ul style="list-style-type: none">• Ensure the speaker is in pairing mode (flashing LED). If not, press and hold the Play/Pause/Bluetooth button.• Make sure Bluetooth is enabled on your device and it is within range (approx. 30 feet).• Forget/remove "BRV-Mini" from your device's Bluetooth list and try pairing again.• Restart both the speaker and your Bluetooth device.
No sound or low volume	<ul style="list-style-type: none">• Increase the volume on both the speaker and your connected device.• Ensure the speaker is properly paired and connected to your device.• Check if the audio source on your device is playing.
Stereo pairing not working	<ul style="list-style-type: none">• Ensure both speakers are fully charged and not connected to any other device.• Follow the "Wireless Pairing (Stereo Experience)" steps carefully.• Try resetting both speakers and attempting stereo pairing again.

SPECIFICATIONS

Feature	Detail
Model Name	Braven BRV-Mini - Waterproof Speaker - Rugged Portable Wireless Speaker - 12 Hours of Playtime - Black
Speaker Type	Outdoor
Special Feature	Portable
Recommended Uses	For Smartphones or Tablets
Compatible Devices	Smartphone, Tablet
Color	Black
Product Dimensions	4.21"D x 4.21"W x 4.02"H
Item Weight	0.32 Kilograms (11.3 ounces)
Water Resistance Level	Waterproof (IPX7)
Warranty Type	Full Warranty
Control Method	Touch

Feature	Detail
Wireless Communication Technology	Bluetooth
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Audio Driver Type	Dynamic Driver
Speaker Maximum Output Power	5 Watts
Connectivity Technology	USB (for charging)
Audio Output Mode	Stereo (with wireless pairing)
Manufacturer	BRAVEN
Item Model Number	604203553
UPC	848467098891



Image: A visual representation of the Braven BRV-Mini speaker's dimensions, indicating its compact size.

WARRANTY AND SUPPORT

The Braven BRV-Mini comes with a Full Warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included in your product packaging or visit the official Braven support website.

For technical support, troubleshooting assistance, or to inquire about warranty claims, please contact Braven Customer Service:

- **Website:** www.braven.com/support (example link, please verify official support page)
- **Email:** support@braven.com (example email, please verify official contact)
- **Phone:** Refer to your product documentation for regional contact numbers.

Please have your product model number (604203553) and proof of purchase ready when contacting support.