W-KING D8

W-KING D8 Bluetooth Speaker User Manual

Model: D8

Introduction

The W-KING D8 Bluetooth Speaker is a portable, high-fidelity audio device designed for robust sound performance in various environments. It features powerful subwoofers and tweeters, IPX6 waterproofing, and extended battery life, making it suitable for both indoor and outdoor use.



Image: The W-KING D8 Bluetooth Speaker, showcasing its rugged design and integrated strap.

Package Contents

- W-KING D8 Bluetooth Speaker
- USB Charging Cable
- 3.5mm AUX Cable
- Adjustable Strap
- User Manual (this document)

Setup

1. Initial Charging

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and a compatible 5V 2.0A power adapter (not included). The charging indicator lights will illuminate. Charging time is approximately 40 hours for a full charge. Ensure to charge the speaker once a month to maintain battery health if not in regular use.



Image: The W-KING D8 speaker connected via USB cable, illustrating its charging capability and power bank function for external devices.

2. Powering On/Off

Press and hold the power button for 2-3 seconds to turn the speaker on or off. A sound indicator will confirm the action.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "W-KING D8" from the list.
4. Once connected, the LED indicator will turn solid blue, and a confirmation sound will play.



Image: The W-KING D8 speaker highlighting its Bluetooth 5.0 connectivity and Bass EQ button for sound customization.

2. True Wireless Stereo (TWS) Pairing

To achieve 180W peak stereo sound, you can pair two W-KING D8 speakers together:

1. Ensure both W-KING D8 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button. The speaker will enter TWS pairing mode.
3. The primary speaker will automatically search for and connect to the second speaker.
4. Once successfully paired, both speakers will play audio in stereo, with one acting as the left channel and the other as the right.
5. Connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.



Image: Two W-KING D8 speakers wirelessly connected, demonstrating the True Wireless Stereo feature for enhanced sound.

3. Audio Playback and Controls

- **Volume Control:** Use the '+' and '-' buttons on the speaker to adjust the volume.
- **Play/Pause:** Press the Play/Pause button to play or pause audio.
- **Next/Previous Track:** Long press the '+' button for the next track, and long press the '-' button for the previous track.
- **Bass EQ:** Press the EQ button to toggle between different sound modes, enhancing bass or optimizing for clear vocals.



Image: Close-up of the W-KING D8 speaker's control panel, highlighting the Bass Boost EQ button.

4. Hands-Free Calling

When connected via Bluetooth, the speaker's built-in microphone allows for hands-free calling:

- **Answer Call:** Press the Play/Pause button once to answer an incoming call.
- **End Call:** Press the Play/Pause button once during a call to end it.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.
- **Voice Assistant:** Double-press the Play/Pause button to activate your device's voice assistant (Siri, Google Assistant, Cortana).



Image: A person riding a motorcycle with the W-KING D8 speaker strapped, demonstrating its hands-free calling capability and voice assistant integration.

5. Power Bank Function

The W-KING D8 can act as a power bank to charge your smart devices. Connect your device's charging cable to the USB output port on the speaker.

6. Other Input Modes (AUX, TF Card, NFC)

- **AUX Input:** Connect an audio device using the provided 3.5mm AUX cable to the AUX port. The speaker will automatically switch to AUX mode.
- **TF Card:** Insert a TF (microSD) card with audio files into the TF card slot. The speaker will automatically play music from the card.
- **NFC Connection (Android Only):** For compatible Android devices, simply touch your device to the NFC area on the speaker to initiate Bluetooth pairing.



Image: The W-KING D8 speaker displaying its NFC function and other connectivity options including Bluetooth, AUX-IN, and TF Card.

Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the speaker's exterior. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the speaker before long periods of inactivity and recharge it at least once a month.
- **Water Resistance:** While IPX6 waterproof, avoid submerging the speaker in water. Ensure all port covers are securely closed before exposure to water.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the power button for 2-3 seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker.	Ensure speaker is flashing blue LED. Enable Bluetooth on device. Move device closer (within 100ft). Forget previous pairings on device.
No sound or low volume.	Volume too low on speaker/device; Incorrect input mode.	Increase volume on both speaker and device. Check if AUX or TF card is inserted and remove if not intended.
TWS pairing fails.	Speakers already connected to other devices; Too far apart.	Disconnect both speakers from any Bluetooth devices. Ensure speakers are close to each other during TWS pairing.
NFC connection not working.	NFC not enabled on device; Device not Android; Incorrect NFC area.	Ensure NFC is enabled on your Android device. Touch the device directly to the NFC logo on the speaker.

SPECIFICATIONS

Feature	Detail
Model Name	D8
Speaker Type	Subwoofer
Speaker Maximum Output Power	90 Watts (Peak)
Frequency Response	60 Hz
Connectivity Technology	Bluetooth 5.0, Auxiliary (3.5mm), TF Card, NFC
Wireless Communication Range	Up to 100 Feet
Water Resistance Level	IPX6 Waterproof
Battery Life	Up to 40 Hours (at lowest volume)
Battery Capacity	4000 mAh
Charging Time	Approximately 40 Hours (for full charge)
Power Source	Battery Powered
Input Voltage	5 Volts
Material	Metal, Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	4.65"D x 12.57"W x 4.65"H
Item Weight	5.3 Pounds
Built-in Microphone	Yes

Feature	Detail
Special Features	Bass Boost, Portable, Waterproof, USB Port (Power Bank), Shockproof, Stereo Pairing (TWS)

Warranty and Support

The W-KING D8 Bluetooth Speaker comes with a limited warranty. For detailed warranty information, technical support, or service inquiries, please contact W-KING customer service through their official channels or visit their brand store on Amazon.
W-KING Brand Store: https://www.amazon.com/stores/W-KING/page/53F588DF-203C-472F-92FD-04278FC0D595

© 2024 W-KING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question