

Lighting EVER 3200008-2

Lighting EVER LE 3200008-2 LED Headlamp Instruction Manual

Model: 3200008-2 | Brand: Lighting EVER

1. INTRODUCTION

Thank you for choosing the Lighting EVER LE 3200008-2 LED Headlamp. This instruction manual provides essential information for the safe and efficient use of your new headlamp. Designed for outdoor activities such as camping, hiking, running, and more, this rechargeable headlamp offers powerful illumination and versatile lighting modes.

2. PRODUCT FEATURES

- **2x Brighter LED Headlamp:** Features XPE LED technology for a powerful, long-lasting beam, illuminating up to 500FT/150m. Ideal for jogging, camping, fishing, hiking, backpacking, and hunting.
- **USB Rechargeable:** Provides up to 30 hours of continuous lighting on a single charge. Eliminates the need for disposable batteries.
- **Multi-Mode for All Scenarios:** Offers 3 levels of white light (High/Low/Strobe) and 2 levels of red light (steady/flash) for various outdoor or indoor activities.
- **Adjustable Headband & Lightweight:** Weighs only 2.85 oz. The removable, washable, and elastic headband adjusts for a comfortable fit on adults and children, and accommodates hard hats or helmets.
- **Waterproof and Shockproof:** IPX4 waterproof rating ensures resistance to heavy rain and splashing water. Polyethylene coating provides protection against accidental drops and scratches.

3. PACKAGE CONTENTS

Your package should contain the following items:

- 2 x Rechargeable LED Headlamps
- 2 x Adjustable Headbands
- 2 x USB Charging Cables

4. SETUP

4.1 Initial Charging

Before first use, fully charge your headlamp. The headlamp provides up to 30 hours of continuous lighting on a single charge.

1. Locate the micro-USB charging port on the bottom of the headlamp, protected by a rubber flap.
2. Open the rubber flap and connect the provided USB charging cable to the port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer, wall adapter, power bank).
4. A red indicator light will illuminate during charging. The light will turn green when the headlamp is fully charged.



Figure 1: Headlamp connected to a USB charging cable, with a red light indicating charging status.

4.2 Adjusting the Headband

The elastic headband is adjustable to ensure a comfortable and secure fit for various head sizes, including over hats or helmets.

1. Place the headlamp on your head with the light unit positioned at the front.
2. Use the adjustable buckle on the headband to tighten or loosen it until it feels snug but comfortable.
3. The headlamp unit can be tilted up to 45 degrees to direct the light beam as needed.

Adjustable Headband

Fits your head well and avoids shaking



45°Tilt

Better see obstacles beneath your feet

Charging Reminder

Red light --- charging

Green light --- fully charged



Figure 2: Demonstrating the adjustable headband and the tiltable headlamp unit.

5. OPERATING MODES

The headlamp features 5 distinct lighting modes, accessible via the power button.

5 Lighting Modes with White & Red Light




Figure 3: Overview of the 5 lighting modes.

5.1 White Light Modes

1. **High Brightness:** Provides maximum illumination for clear visibility over long distances (up to 500FT/150m).
2. **Low Brightness:** Offers reduced light output for closer tasks or to conserve battery life.
3. **Strobe:** A flashing white light mode for signaling or emergency situations.

5.2 Red Light Modes

Red light is useful for preserving night vision and for discreet illumination.

1. **Stay on Red Light:** Continuous red light.
2. **Red Light Flash:** A flashing red light for increased visibility or emergency signaling.

5.3 Switching Modes

Press the power button repeatedly to cycle through the white light modes. To activate red light modes, press and hold the power button for 2 seconds. Subsequent presses will cycle through red light modes. Press and hold again to turn off the headlamp.

6. MAINTENANCE

- **Cleaning:** Wipe the headlamp with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headlamp in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care:** To prolong battery life, recharge the headlamp regularly, even if not used frequently. Avoid fully discharging the battery for extended periods.

7. TROUBLESHOOTING

- **Headlamp not turning on:** Ensure the battery is charged. Connect to a USB power source and check the charging indicator.
- **Light output is dim:** The battery may be low. Recharge the headlamp.
- **Buttons unresponsive:** Ensure the headlamp is not exposed to extreme temperatures or moisture. If issues persist, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	3200008-2
Brand	Lighting EVER
Light Source Type	LED
Power Source	USB rechargeable
Battery Cell Composition	Lithium Ion
White Brightness	150 Lumens
Light Output Maximum	150 Lumens
Water Resistance Level	IPX4 Waterproof
Item Weight	2.85 ounces
Product Dimensions	2.16"D x 1.37"W x 1.57"H
Included Components	2 Pack Rechargeable Headlamp, Head Band, USB Cable

9. SAFETY INFORMATION

- Do not look directly into the LED light beam to avoid eye injury.
- Keep out of reach of children.
- Do not attempt to disassemble or modify the headlamp, as this may void the warranty and pose a safety risk.
- Avoid exposing the headlamp to extreme heat or open flames.

10. WARRANTY AND SUPPORT

This Lighting EVER LED Headlamp comes with a **Limited Warranty** for a period of **1 year** from the date of purchase. For warranty claims, technical support, or any inquiries, please refer to the contact information provided on the product packaging or

visit the official Lighting EVER website.

11. PRODUCT VIDEOS

Product Overview and Charging

Your browser does not support the video tag.

This video provides a brief overview of the headlamp, demonstrating its physical features and the USB charging process. It shows how to connect the charging cable and the indicator light.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question