

[manuals.plus](#) /› [Timex](#) /› [Timex Men's Expedition Gallatin 45mm Watch User Manual](#)**Timex TW2U303009J**

## Timex Men's Expedition Gallatin 45mm Watch User Manual

**Brand:** Timex**Model:** TW2U303009J

### INTRODUCTION

This user manual provides essential information for the proper setup, operation, and maintenance of your Timex Men's Expedition Gallatin 45mm Watch. Designed for durability and reliability, this solar-powered timepiece is built to accompany you on various adventures. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.



Figure 1: Front view of the Timex Expedition Gallatin 45mm Watch, showcasing its black dial, orange accents, and fabric strap.

## SETUP

### 1. Initial Charging

Your Timex Expedition Gallatin watch is powered by light. Before initial use, or if the watch has stopped, expose the dial to a strong light source (natural sunlight is ideal) for several hours. A full charge can provide a two-month power reserve.

## 2. Setting Time and Date

1. **Pull the Crown:** Gently pull the crown (the knob on the side of the watch) out to position 2. The second hand will stop.
2. **Set the Time:** Rotate the crown to move the hands clockwise until the correct time is displayed. Ensure you set the correct AM/PM by observing if the date changes when passing midnight.
3. **Set the Date:** Push the crown in halfway to position 1. Rotate the crown to adjust the date.
4. **Push the Crown In:** Once time and date are set, push the crown fully back into position 0 to start the watch.

## 3. Strap Adjustment

The watch features an adjustable fabric double-layer strap. Adjust the strap length by sliding the buckle to fit your wrist comfortably. Ensure it is snug but not too tight to allow for proper blood circulation and comfort.



Figure 2: The Timex Expedition Gallatin 45mm Watch worn on a wrist, demonstrating its fit and appearance.

## OPERATING INSTRUCTIONS

### Solar Power Functionality

The Timex Expedition Gallatin is equipped with a solar cell that converts light into electrical energy, which is then stored in a rechargeable battery. For optimal performance, ensure the watch is regularly exposed to light. Avoid prolonged storage in dark places.

### Water Resistance

This watch is water resistant to 50 meters (165 feet). This rating means it is suitable for short periods of recreational swimming. It is *not* suitable for diving or snorkeling. Do not operate the crown or pushers when the watch is wet or submerged.

### Luminous Hands

The watch features luminous hands for improved visibility in low-light conditions. The luminosity is activated by exposure to light. The brighter and longer the exposure, the more intense and prolonged the glow will be.

## MAINTENANCE

### Cleaning Your Watch

- **Case and Crystal:** Wipe the watch case and crystal with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and drying thoroughly.

- **Strap:** The fabric strap can be cleaned with mild soap and water. Allow it to air dry completely before wearing the watch again. Avoid harsh chemicals or abrasive cleaners.

## Storage

When not in use, store your watch in a location where it can receive some light to maintain its charge. Avoid extreme temperatures, direct sunlight for prolonged periods (which can fade the strap), and strong magnetic fields.



Figure 3: The Timex watch box, suitable for safe storage when the watch is not in use.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is losing time.	Insufficient light exposure; crown not fully pushed in.	Expose watch to strong light for several hours. Ensure crown is fully pushed into position 0.
Date does not change at midnight.	Time set incorrectly (AM/PM).	Advance the time by 12 hours. Reset the date if necessary.
Moisture or condensation inside the watch.	Exposure to excessive moisture or temperature changes.	Seek professional watch service immediately to prevent damage.

If you encounter issues not listed here, or if the suggested solutions do not resolve the problem, please contact Timex customer support.

## SPECIFICATIONS

---

- **Model Number:** TW2U303009J
- **Product Dimensions:** 8 x 1.73 x 0.51 inches
- **Weight:** 1.44 ounces
- **Department:** Men's
- **Power Source:** Solar (1 Lithium Metal battery included)
- **Water Resistance:** 50 meters (165 feet)
- **Case Material:** Resin
- **Lens Material:** Acrylic
- **Strap Material:** Nylon

## WARRANTY AND SUPPORT

---

Timex watches are manufactured to high standards and are covered by a limited warranty against manufacturing defects. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Timex website. For customer support, service, or to inquire about repairs, please visit the [Timex Store on Amazon](#) or the official Timex support channels.



Figure 4: Timex Expedition branding, emphasizing the watch's robust design for outdoor activities.



## Rain or Shine, Inland or Coast- Expedition Goes the Distance

Engineered for exploration, with highly durable construction and premium materials that keep pace with your adventures.



Figure 5: A visual representation of the Timex Expedition watch's suitability for various environments, from rain to shine, inland to coast.

© 2024 Timex. All rights reserved.