

- Manuals.plus /
- › PHONSUN /
- › PHONSUN Replacement USB Charging Port for Amazon Kindle Fire HD 10 (7th Generation) SL056ZE Instruction Manual

PHONSUN SL056ZE

PHONSUN Replacement USB Charging Port for Amazon Kindle Fire HD 10 (7th Generation) SL056ZE

Instruction Manual

INTRODUCTION

This manual provides essential information for the installation and proper use of the PHONSUN Replacement USB Charging Port for the Amazon Kindle Fire HD 10 (7th Generation), model SL056ZE. This component is designed to replace a defective or damaged USB charging port in compatible devices. Please read these instructions carefully before proceeding with installation.

PRODUCT OVERVIEW

The PHONSUN Replacement USB Charging Port is a critical component for restoring charging functionality to your Amazon Kindle Fire HD 10 (7th Generation). Each package contains two replacement ports, providing a spare for future needs.



Image 1: Front view of the PHONSUN Replacement USB Charging Port, showing the connector pins and mounting tabs.



Image 2: Angled view of the PHONSUN Replacement USB Charging Port, highlighting its compact design and metallic housing.

INSTALLATION INSTRUCTIONS

Warning: This installation requires soldering and advanced technical skills. Professional installation is highly recommended. Attempting this repair without proper tools and expertise may result in damage to your device or personal injury.

1. **Preparation:** Ensure your Amazon Kindle Fire HD 10 (7th Generation) is powered off and disconnected from all power sources. Gather necessary tools, including a soldering iron, solder, desoldering wick or pump, flux,

precision tweezers, and a magnifying glass or microscope.

2. **Disassembly:** Carefully disassemble your Kindle Fire HD 10 to access the main circuit board where the USB charging port is located. Refer to a device-specific disassembly guide if unfamiliar with the process.
3. **Remove Old Port:** Using appropriate desoldering techniques, carefully remove the damaged USB charging port from the circuit board. Exercise caution to avoid damaging surrounding components or traces on the PCB.
4. **Clean Area:** Clean the solder pads and surrounding area on the circuit board thoroughly to remove any old solder residue or flux.
5. **Position New Port:** Carefully align the new PHONSUN USB charging port with the solder pads on the circuit board. Ensure all pins and mounting tabs are correctly seated.
6. **Solder New Port:** Solder the new port into place. Begin by soldering the mounting tabs for structural stability, then carefully solder each data and power pin. Use minimal solder to prevent bridging connections.
7. **Inspect Connections:** Visually inspect all solder joints under magnification to ensure they are clean, strong, and free of shorts or cold joints.
8. **Test Functionality:** Before reassembling the device completely, perform a preliminary test to ensure the new charging port functions correctly. Connect a charger and verify that the device begins to charge.
9. **Reassembly:** If the port functions correctly, carefully reassemble your Amazon Kindle Fire HD 10, ensuring all connectors are properly seated and screws are tightened appropriately.

OPERATION

Once the PHONSUN Replacement USB Charging Port is successfully installed, its operation is integrated with your device's normal functionality. Connect a standard USB charging cable to the port and a power source to charge your Amazon Kindle Fire HD 10. The port also facilitates data transfer when connected to a computer.

MAINTENANCE

- **Cleaning:** Keep the USB port free from dust, lint, and debris. Use a soft, dry brush or compressed air to gently clean the port if necessary. Avoid using liquids or sharp objects.
- **Cable Handling:** Always insert and remove USB cables gently and straight into the port. Avoid forcing cables or applying excessive sideways pressure, which can damage the internal pins or the port's physical structure.
- **Environmental Conditions:** Avoid exposing the device to extreme temperatures or high humidity, which can affect the longevity of electronic components, including the charging port.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging after port replacement.	Poor solder connections, incorrect port alignment, or a faulty charging cable/adaptor.	Re-inspect solder joints for shorts or cold connections. Ensure the port is correctly aligned. Test with a known good charging cable and adaptor.
Charging is intermittent.	Loose connection, debris in the port, or a partially damaged cable.	Clean the port carefully. Try a different charging cable. Check for any physical damage to the port or cable.

Problem	Possible Cause	Solution
Device not recognized by computer.	Data pins not properly soldered, or a faulty data cable.	Verify solder connections for data pins. Test with a different USB data cable.

If issues persist after troubleshooting, it is recommended to seek assistance from a qualified electronics repair technician.

SPECIFICATIONS

- Model Number:** SL056ZE (Compatible with Amazon Kindle Fire HD 10, 7th Generation)
- Connector Type:** USB
- Color:** Silver
- Item Weight:** Approximately 0.05 Kilograms
- Number of Ports:** 1 (per unit)
- Package Quantity:** 2 units
- Manufacturer:** Gen
- Brand:** PHONSUN

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the retailer or the original point of purchase. Due to the nature of this component requiring specialized installation, warranty terms may vary. Always retain your proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07WRDSZ5T>

More documents and user manuals: <https://manuals.plus/>