

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nacon](#) /

› [Nacon Revolution Unlimited Pro Controller User Manual](#)

Nacon 2200630016367

Revolution Unlimited Pro Controller User Manual

Model: 2200630016367

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Nacon Revolution Unlimited Pro Controller. Designed for competitive gaming, this controller offers both wired and wireless connectivity, advanced customization options, and enhanced ergonomics. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. SAFETY INFORMATION

To prevent damage to the controller or injury to yourself or others, observe the following precautions:

- Do not expose the controller to extreme temperatures, humidity, or direct sunlight.
- Avoid dropping or subjecting the controller to strong impacts.
- Do not attempt to disassemble or modify the controller. Unauthorized modifications can void your warranty and cause damage.
- Keep the controller away from liquids and small children.
- Use only the provided or recommended accessories.
- If the controller malfunctions, discontinue use immediately and contact customer support.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Nacon Revolution Unlimited Pro Controller
- USB Type-C Braided Cable (3m)
- Weight Compartment with Adjustable Weights (2x10g, 2x14g, 2x16g)
- Stick Heads (Concave and Convex)
- Stick Shafts (30°, 38°, 46°)
- Storage Case

- Cleaning Cloth



Image: The retail box of the Nacon Revolution Unlimited Pro Controller, showcasing the controller and its branding.

4. CONTROLLER FEATURES OVERVIEW

Familiarize yourself with the various components and features of your controller:



Image: A detailed diagram highlighting key features of the Nacon Revolution Unlimited Pro Controller, including removable stick heads, USB Type-C port, OMRON® switches, LED player indicator, soft-touch texture, 4 shortcut buttons, and weight compartments.

- **Removable Stick Heads:** Customize your analog sticks with different concave or convex caps.
- **Stick Shafts:** Adjust the stick amplitude with 30°, 38°, or 46° shafts.
- **ALPS Control Sticks:** High-quality analog sticks for precise control.
- **Directional Pad (8-Way):** For accurate directional input.
- **L1/R1 OMRON® Switches:** Durable and responsive shoulder buttons.
- **Smart LED Indicator:** Displays profile, battery, and mute status.
- **Soft-Touch Texture:** Enhanced grip and comfort.
- **LED Player Status Indicator:** Indicates player number.
- **3.5mm Headset Jack:** For audio and microphone connection.
- **Connection Mode Switch:** Easily switch between wired and wireless modes.
- **Shortcut Buttons (x4):** Programmable buttons on the rear for quick access to functions.
- **Headphone Volume Controller & MUTE Button:** Convenient audio controls.

- **Ergonomic Rubber Grip:** For comfortable and secure handling.
- **Weight Compartments:** Customize the controller's weight for personalized feel.

5. SETUP

5.1 Initial Connection

The Nacon Revolution Unlimited Pro Controller can be used in both wired and wireless modes.

Wired Mode:

1. Ensure the connection mode switch on the controller is set to wired mode.
2. Connect the USB Type-C end of the provided cable to the controller.
3. Connect the USB-A end of the cable to an available USB port on your PlayStation 4 console or PC.
4. The controller will automatically be recognized and ready for use.



Image: The Nacon Revolution Unlimited Pro Controller connected to a device via its USB Type-C cable, illustrating wired mode setup.

Wireless Mode:

1. Ensure the connection mode switch on the controller is set to wireless mode.
2. Plug the wireless receiver dongle into an available USB port on your PlayStation 4 console or PC.
3. Press the PS button on the controller to turn it on. The controller will automatically pair with the receiver.
4. The LED player status indicator will illuminate to confirm successful connection.

5.2 Customization via PC Software

The Nacon Revolution Unlimited Pro Controller offers extensive customization through dedicated PC software. This software allows you to:

- Remap buttons and assign macros to the shortcut buttons.

- Adjust stick sensitivity and dead zones.
- Configure trigger sensitivity.
- Customize vibration intensity.
- Manage up to 4 custom profiles, which can be switched on the fly using the controller's profile button.
- Adjust LED lighting patterns and colors.

Download the latest version of the customization software from the official Nacon website. The software is compatible with Windows 7/8/10 and macOS 10.11 (El Capitan) to 10.14 (Mojave).

5.3 Adjusting Weights

The controller includes removable weights to customize its feel and balance. To adjust the weights:

1. Locate the weight compartments on the underside of the controller's grips.
2. Open the compartments and insert or remove the desired weights (10g, 14g, or 16g).
3. Close the compartments securely.

6. OPERATING THE CONTROLLER

Once connected and configured, your Nacon Revolution Unlimited Pro Controller is ready for use. The controller features standard PlayStation layout buttons, along with additional customizable elements.

6.1 Basic Controls

- **Analog Sticks:** Use for movement and camera control.
- **Directional Pad:** For precise directional input, often used in fighting games or menu navigation.
- **Action Buttons (Triangle, Circle, Cross, Square):** Standard game actions.
- **Shoulder Buttons (L1, R1) & Triggers (L2, R2):** For various in-game actions like aiming, shooting, or interacting.
- **PS Button:** Access the PlayStation menu.
- **Share Button:** Share gameplay moments.
- **Options Button:** Access in-game menus or pause.



Image: A user holding the Nacon Revolution Unlimited Pro Controller, demonstrating its ergonomic design and the illuminated LED light bar.

6.2 Advanced Features

- **Shortcut Buttons:** The four programmable buttons on the rear of the controller can be assigned to any standard button input or complex macros via the PC software. This allows for quicker reactions and more efficient gameplay.
- **Profile Switching:** Use the dedicated profile button on the controller to cycle through your pre-configured custom profiles, adapting to different games or play styles instantly.
- **Headset Controls:** Adjust headset volume and mute your microphone directly from the controller using the dedicated buttons.

7. MAINTENANCE

Proper care will extend the life of your Nacon Revolution Unlimited Pro Controller:

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the controller in its provided case to protect it from dust and accidental damage.
- **Cable Care:** Avoid sharp bends or kinks in the USB cable. Store it neatly when not connected.
- **Battery:** For optimal battery life, avoid fully discharging the controller frequently. Charge it regularly.

8. TROUBLESHOOTING

If you encounter issues with your controller, try the following solutions:

Problem	Possible Cause / Solution
Controller not responding.	<p>Ensure the controller is fully charged (wireless mode) or the USB cable is securely connected (wired mode).</p> <p>Verify the connection mode switch is set correctly (wired/wireless).</p> <p>For wireless mode, ensure the receiver dongle is properly inserted into the console/PC.</p> <p>Try connecting to a different USB port.</p> <p>Restart your console/PC.</p>
Buttons or sticks are unresponsive/drifting.	<p>Clean around the buttons and sticks to remove any debris.</p> <p>Recalibrate the sticks and triggers using the PC customization software.</p> <p>Ensure the controller firmware is up to date via the PC software.</p>
Wireless connection issues.	<p>Ensure no strong interference sources (e.g., Wi-Fi routers, other wireless devices) are too close to the receiver.</p> <p>Re-pair the controller with the wireless receiver.</p> <p>Try using the controller in wired mode to confirm functionality.</p>
PC software not recognizing controller.	<p>Ensure the controller is connected via USB cable to the PC.</p> <p>Run the software as administrator.</p> <p>Check for driver updates for the controller.</p>

9. SPECIFICATIONS

Feature	Detail
Model Number	2200630016367
Connectivity	Wired (USB Type-C), Wireless (Bluetooth via receiver)
Battery	2 Lithium Polymer batteries (included)
Dimensions (Package)	22.3 x 20.7 x 9.4 cm
Weight (Package)	870 g
Release Date	September 6, 2019
Compatibility	PlayStation 4, PC (Windows 7/8/10, macOS 10.11-10.14)

10. WARRANTY AND SUPPORT

The Nacon Revolution Unlimited Pro Controller typically comes with a 2-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, warranty service, or further inquiries, please visit the official Nacon support website or contact their customer service department. Refer to the product packaging or Nacon's official website for the most up-to-date contact information.

Note: Warranty terms and conditions may vary by region.

© 2024 Nacon. All rights reserved. PlayStation is a registered trademark of Sony Interactive Entertainment Inc.

Related Documents - 2200630016367

	<p>Nacon Revolution Unlimited Pro Controller User Manual</p> <p>This manual provides detailed instructions for the Nacon Revolution Unlimited Pro Controller, covering setup, features, modes, customization, and safety precautions for PlayStation 4 and PC gaming.</p>
	<p>NACON REVOLUTION Unlimited Pro Controller - User Manual</p> <p>Comprehensive user manual for the NACON REVOLUTION Unlimited Pro Controller, detailing features, modes, setup, charging, and maintenance for enhanced gaming experiences on PS4 and PC.</p>
	<p>Nacon Revolution 5 Pro Controller Quick Start Guide</p> <p>A quick start guide for the Nacon Revolution 5 Pro controller, covering setup, wired/wireless connection, charging, vibration, trigger stoppers, and Bluetooth pairing for PlayStation 5 and PlayStation 4 consoles.</p>
	<p>Nacon Revolution 5 Pro Controller - Start Guide</p> <p>Comprehensive start guide for the Nacon Revolution 5 Pro controller, covering setup, features, modes, audio controls, and troubleshooting for PlayStation and PC.</p>
	<p>Nacon Revolution 5 Pro : Guide de Démarrage Rapide pour PS5 et PS4</p> <p>Découvrez la manette Nacon Revolution 5 Pro avec ce guide de démarrage rapide. Apprenez à configurer, personnaliser et utiliser votre contrôleur pour PlayStation 5, PlayStation 4 et PC, et explorez ses fonctionnalités avancées.</p>



[Nacon Revolution 5 Pro Controller Start Guide](#)

This guide provides essential information for setting up and using the Nacon Revolution 5 Pro controller, including features, customization options, connectivity for PS5, PS4, and PC, and technical support.