

[manuals.plus](#) /› [FINTIE](#) /› [FINTIE 10-inch Bluetooth Wireless AZERTY Keyboard \(Model EB00055EU\) User Manual](#)

FINTIE EB00055EU

FINTIE 10-inch Bluetooth Wireless AZERTY Keyboard User Manual

Model: EB00055EU

1. INTRODUCTION

Thank you for choosing the FINTIE 10-inch Bluetooth Wireless AZERTY Keyboard. This lightweight and slim keyboard is designed for enhanced productivity with your iPad, Android tablet, or other Bluetooth-enabled devices. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.



Image: The FINTIE 10-inch Bluetooth Wireless AZERTY Keyboard, showcasing its compact and sleek design.

2. PACKAGE CONTENTS

- FINTIE 10-inch Bluetooth Wireless AZERTY Keyboard
- USB Charging Cable
- User Manual (this document)

3. PRODUCT SPECIFICATIONS

Brand	FINTIE
Model Number	EB00055EU

Layout	AZERTY (French)
Connectivity Technology	Bluetooth
Operating System Compatibility	Android, iOS
Power Source	Battery Powered (Rechargeable)
Material	Acrylonitrile Butadiene Styrene (ABS)
Dimensions (L x W x H)	24.6 x 14.9 x 0.6 cm (9.7 x 5.9 x 0.24 inches)
Weight	225 Grams (0.5 lbs)
Special Features	Lightweight, Portable, Multimedia Shortcuts, Rechargeable, Scissor-switch keys

Design Minimisé



Image: Diagram illustrating the precise dimensions of the FINTIE Bluetooth keyboard.

4. SETUP

4.1 Charging the Keyboard

Before initial use, fully charge the keyboard. Use the provided USB charging cable to connect the keyboard to a USB power source (e.g., computer, USB wall adapter). The charging indicator light will illuminate during charging and turn off once fully charged. A full charge typically takes approximately 2 hours.



Recharge
Type-C

Clavier Rechargeable
Vous pouvez complètement
recharger le clavier
pendant 2 heures

Image: Close-up view of the keyboard's charging port, indicating where to connect the USB Type-C cable for recharging.

4.2 Bluetooth Pairing

Follow these steps to pair your FINTIE keyboard with your device:

1. Turn on the keyboard by sliding the **ON/OFF** switch to the 'ON' position. The power indicator light will briefly illuminate.
2. Press the '**Connect**' button (usually located near the ON/OFF switch). The Bluetooth indicator light will start blinking, indicating the keyboard is in pairing mode.
3. On your device (iPad, Android tablet, etc.), go to **Settings > Bluetooth**.
4. Ensure Bluetooth is enabled on your device.
5. Your device will search for available Bluetooth devices. Locate and select '**Bluetooth Keyboard**' (or a similar name) from the list.
6. If prompted, enter the displayed pairing code on the FINTIE keyboard and press **Enter**.

- Once successfully paired, the Bluetooth indicator light on the keyboard will stop blinking and turn off. Your device will show the keyboard as 'Connected'.



Image: Diagram illustrating the Bluetooth connection process between the FINTIE keyboard and a tablet and smartphone.

5. OPERATING INSTRUCTIONS

5.1 Optimized Function Keys

The FINTIE keyboard features a row of optimized function keys for quick access to common commands. These keys are typically accessed by pressing the **Fn** key in combination with the desired function key.

Icon/Key	Function
Home	Returns to the home screen.
Brightness Down	Decreases screen brightness.
Brightness Up	Increases screen brightness.
Search	Opens the device's search function.
Keyboard Display	Toggles the on-screen keyboard display.
Screenshot	Captures a screenshot.
Previous Track	Skips to the previous media track.
Play/Pause	Plays or pauses media playback.
Next Track	Skips to the next media track.
Mute	Mutes or unmutes audio.
Volume Down	Decreases audio volume.
Volume Up	Increases audio volume.
Screen Lock	Locks the device screen.
Delete	Deletes characters.
Power Display	Displays the current battery level.

Touches de Fonction Optimisées



Image: Detailed view of the FINTIE keyboard highlighting the optimized function keys and their corresponding actions.

5.2 Compatibility Notes

The FINTIE Bluetooth keyboard is broadly compatible with:

- **iPad:** iPad 11 A16 11-inch, iPad 10th Generation 10.9-inch, iPad 10.2-inch (9th/8th/7th Generation), iPad 9.7-inch (6th/5th Generation), iPad Air 11-inch, iPad Air 10.9-inch (5th/4th Generation), iPad Air 3 10.5-inch, iPad Air 2/1 9.7-inch, and iPad Pro 11-inch/10.5-inch/9.7-inch.
- **Android Tablets:** Samsung Galaxy Tab A/Tab S series, Xiaomi/Redmi Pad, Huawei/Honor Pad, and other Android tablets.

Note: This keyboard is **NOT** compatible with televisions.

Clavier AZERTY Compatible avec Système Android / iOS




Image: Visual representation of the FINTIE keyboard's wide compatibility with various tablets, including iPad, Samsung Galaxy Tab, Lenovo, and Xiaomi/Redmi Pad.

6. MAINTENANCE

To ensure the longevity and optimal performance of your FINTIE keyboard, follow these maintenance guidelines:

- Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard. Avoid harsh chemicals, abrasive cleaners, or excessive moisture.
- Storage:** When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- Protection:** Avoid dropping the keyboard or exposing it to impacts, which can damage internal components.
- Liquid Exposure:** Keep the keyboard away from liquids. In case of accidental spills, immediately power off the keyboard and allow it to dry completely before attempting to use it again.

7. TROUBLESHOOTING

If you encounter issues with your FINTIE keyboard, refer to the following troubleshooting steps:

7.1 Keyboard Not Connecting/Pairing

- Check Power:** Ensure the keyboard is turned on and has sufficient battery charge. Recharge if necessary.
- Bluetooth On:** Verify that Bluetooth is enabled on your device (tablet, smartphone).
- Re-enter Pairing Mode:** Press the 'Connect' button on the keyboard to re-enter pairing mode.
- Forget Device:** On your device, go to Bluetooth settings, 'forget' or 'unpair' the keyboard if it was previously connected, then attempt to pair again.
- Restart Devices:** Restart both your keyboard (turn off and on) and your device, then try pairing again.
- Distance:** Ensure the keyboard is within the effective range of your device (typically up to 10 meters or 33 feet).

7.2 Keys Not Responding

- Check Connection:** Ensure the keyboard is properly connected via Bluetooth to your device.
- Battery Level:** A low battery can cause intermittent key responses. Charge the keyboard fully.
- Restart:** Turn the keyboard off and then on again.

- **Clean Keys:** Check for any debris or obstructions under the keys.

7.3 Incorrect Characters Typed (AZERTY Layout)

- **Device Language Settings:** Ensure your device's keyboard input language is set to 'French (AZERTY)' or the appropriate AZERTY layout. If it's set to QWERTY, the characters will not match.

8. WARRANTY AND SUPPORT

FINTIE products are designed for reliability and performance. For specific warranty information, please refer to the warranty card included with your purchase or visit the official FINTIE website. For technical support or further assistance, please contact FINTIE customer service through their official channels.

You can often find support resources and contact information on the FINTIE brand store page:[FINTIE Amazon Store](#)