LogiLink BP0074

LogiLink BP0074 Dual Monitor Desk Mount User Manual

Model: BP0074 | Brand: LogiLink

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient installation, operation, and maintenance of your LogiLink BP0074 Dual Monitor Desk Mount. Please read this manual thoroughly before beginning installation to ensure correct setup and to prevent damage to the product or injury. Keep this manual for future reference.

Safety Information

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or defective.
- Verify that the desk surface can support the combined weight of the mount and two monitors.
- Do not exceed the maximum load capacity of 6 kg (13.22 lbs) per arm.
- Use appropriate tools and follow all steps carefully. Improper installation may result in product failure or personal injury.
- Keep children and pets away during installation.

PACKAGE CONTENTS

Please check the package to ensure all items listed below are included:

- 1 x Dual Monitor Desk Mount Assembly
- 2 x VESA Monitor Plates
- 1 x Desk Clamp Assembly
- 1 x Hardware Kit (screws, washers, spacers, Allen keys)
- 1 x Instruction Manual

Image: All components of the LogiLink BP0074 Dual Monitor Desk Mount.

SETUP INSTRUCTIONS

Step 1: Attach Desk Clamp to Desk

Position the desk clamp assembly on the edge of your desk. Tighten the clamp screws securely until the mount is stable. Ensure the clamp is flush with the desk surface for maximum stability.

Image: Close-up of the desk clamp mechanism securely attached to a desk.

Step 2: Assemble Monitor Arms

Slide the monitor arms onto the main pole of the desk clamp assembly. Adjust their height to your desired position and secure them using the provided locking mechanisms. Ensure both arms are at a similar height for ergonomic viewing.

Step 3: Attach VESA Plates to Monitors

Align the VESA monitor plates with the mounting holes on the back of your monitors. Use the appropriate screws, washers, and spacers from the hardware kit to secure the plates to each monitor. Ensure the screws are tightened firmly but do not overtighten.

Image: VESA plate attached to the back of a monitor.

Step 4: Mount Monitors to Arms

Carefully slide the monitors (with VESA plates attached) onto the ends of the monitor arms. Secure them in place using the quick-release or locking mechanisms on the arms. Ensure both monitors are firmly attached before releasing them.

Image: Two monitors mounted on the LogiLink BP0074 desk mount.

OPERATING INSTRUCTIONS

Adjusting Monitor Position

The LogiLink BP0074 mount offers full motion capabilities:

- **Tilt:** Adjust the monitor vertically (up/down) to reduce glare and optimize viewing angles.
- **Swivel:** Rotate the monitor horizontally (left/right) to share your screen or change viewing direction.
- **Rotation:** Rotate the monitor 360 degrees to switch between landscape and portrait orientation.

Loosen the adjustment screws slightly with the provided Allen key before making adjustments, then tighten them once the desired position is achieved.

Image: Demonstrating the flexible positioning of monitors on the mount.

Cable Management

Utilize the integrated cable management clips on the monitor arms to route and organize your cables. This helps maintain a tidy workspace and prevents cable damage.

Image: Cable management clips on the monitor arm.

Image: Detail of cables routed through the clips for organization.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your monitor mount:

- **Cleaning:** Wipe the mount with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Check Tightness:** Periodically check all screws and bolts, especially the desk clamp and VESA plate attachments, to ensure they remain tight. Retighten if necessary.
- **Lubrication:** No lubrication is typically required for this type of mount.

TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Monitor is unstable or sags	Screws are loose; monitor weight exceeds capacity	Tighten all connection screws. Verify monitor weight is within 6 kg per arm.
Difficulty adjusting monitor position	Adjustment screws are too tight	Slightly loosen the relevant adjustment screws with the Allen key.
Mount slides on desk	Desk clamp is not tight enough	Ensure the desk clamp is fully tightened and flush against the desk surface.

SPECIFICATIONS

| Feature	Detail
Model Number	BP0074
Supported Screen Size	13 - 26 inches (per monitor)
Number of Monitors	2
Maximum Load Capacity	6 kg (13.22 lbs) per arm
VESA Compatibility	75x75mm, 100x100mm
Motion Range	Full Motion (Tilt, Swivel, Rotation)
Material	Metal
Product Dimensions (LxWxH)	55.3 x 79.2 x 11.6 cm (overall package/product dimensions)
Item Weight	4.1 kg
Arm Length	Each 358 mm

## ● Schreibtisch Bildschirmhalterungen / Desktop mounts

Art.-Nr. Part no.	Passend für Suitable for	Funktion Function	VESA VESA
BP0074 **2** Screens	**13"-26"** Max. 5 kg/ 11 lbs per arm	Neigung: -90° / +90° Schwenkung: -90° / +90° Drehung: -180° / +180° Armlänge: 358 mm Tilt: -90° / +90° Swivel: -90° / +90° Rotation: -180° / +180° Arm length: Each 358 mm	75x75, 100x100
BP0023	**13"– 27"** Max. 6 kg/ 13.2 lbs	Neigung: -90° / +90° Schwenkung: -90° / +90° Drehung: -180° / +180° Armlänge: 442 mm Tilt: -90° / +90° Swivel: -90° / +90° Rotation: -180° / +180° Arm length: 442 mm **Mit Gasdruckfeder** With gas spring	75x75, 100x100
BP0041 **2** Screens	**13"– 27"** Max. 6 kg/ 13.2 lbs per arm	Neigung: -90° / +90° Schwenkung: -90° / +90° Drehung: -180° / +180° Armlänge: Jeweils 442 mm Tilt: -90° / +90° Swivel: -90° / +90° Rotation: -180° / +180° Arm length: Each 442 mm **Mit Gasdruckfeder** With gas spring	75x75, 100x100
BP0020	**13"– 27"** Max. 8 kg/ 17.6 lbs	Neigung: -45° / +45° Schwenkung: -90° / +90° Drehung: 360° Armlänge: 274 mm Tilt: -45° / +45° Swivel: -90° / +90° Rotation: 360° Arm length: 274 mm	75x75, 100x100

Individual Height Adjustment

Image: Technical drawing showing key dimensions and VESA patterns.

Warranty and Support

LogiLink products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official LogiLink website. Please retain your proof of purchase for warranty claims.