



Manuals.plus /

› Wendry /

› Wendry 12-inch Portable Digital TV Model D12 User Manual

Wendry D12

Wendry 12-inch Portable Digital TV Model D12 User Manual

Your guide to setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the Wendry 12-inch Portable Digital TV Model D12. This device is designed to provide high-definition digital television viewing on a portable 12-inch LCD screen. It supports ATSC digital TV signals and offers various connectivity options for versatile use in your car or home. Please read this manual carefully before operating the device to ensure proper use and to maximize its performance.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Wendry 12-inch Portable Digital TV Model D12
- Remote Control
- Batteries for Remote Control
- Power Adapter
- Car Charger
- AV Cable
- Antenna
- Suction Cup Mount
- User Manual (this document)



Image: All included accessories for the Wendry Portable Digital TV, including the TV unit, remote control, antenna, power adapters, and mounting accessories.

3. PRODUCT FEATURES

- **12-inch LCD Screen:** Large display for comfortable viewing.
- **Full HD 1080P Vision:** Supports 1280x800 resolution for clear picture quality.
- **ATSC Digital TV Tuner:** High-sensitivity tuner for enhanced signal reception, supporting both digital TV and ATV.
- **Multiple External Sources:** Connectivity options include AV in/out, Memory/MMC card slot, USB port, VGA, HDMI, and a headset plug.
- **Portable Design:** Features a foldable stand for desktop use and includes accessories for car mounting.



Image: The Wendry 12-inch Portable Digital TV showcasing its display with a scenic image.

4. SETUP

4.1 Powering On

1. **For Home Use:** Connect the power adapter to the DC 12V input port on the TV and plug it into a standard wall outlet.
2. **For Car Use:** Connect the car charger to the DC 12V input port on the TV and plug it into your vehicle's cigarette lighter socket.
3. Press the **POWER** button on the TV or remote control to turn on the device.

4.2 Antenna Connection

For receiving digital TV channels:

1. Connect the included antenna to the **ANT IN** port on the TV.
2. Position the antenna for optimal signal reception. You may need to adjust its placement during channel scanning.

4.3 Initial Channel Scan

Upon first use or after moving to a new location, you will need to scan for available channels:

1. Turn on the TV.
2. Press the **MENU** button on the remote control.

3. Navigate to the **CHANNEL** or **SETUP** menu.
4. Select **AUTO SCAN** or **AUTO TUNE**.
5. The TV will search for and store all available digital and analog channels. This process may take several minutes.

High Sensitivity TV Tuner

A high sensitivity tuner strengthens signal receiving ability to make TV playing smoother and more stable.



Image: The portable TV with an active display, illustrating its high-sensitivity tuner for stable signal reception.

5. OPERATING INSTRUCTIONS

5.1 Basic Functions

- **Power On/Off:** Press the **POWER** button on the TV or remote.
- **Volume Control:** Use the **VOL+** and **VOL-** buttons on the remote or side panel.
- **Channel Selection:** Use the **CH+** and **CH-** buttons or the number pad on the remote.
- **Input Source:** Press the **INPUT** or **SOURCE** button on the remote to switch between TV, AV, HDMI, VGA, USB, and Card Reader modes.
- **Menu Navigation:** Use the **MENU** button to access settings, and the arrow keys (**UP/DOWN/LEFT/RIGHT**) and **ENTER** button to navigate and confirm selections.

Remote Control

Remote control makes operation more convenient and easier.



Image: The portable TV, remote control, and antenna, demonstrating the convenience of remote operation in different settings.

6. CONNECTIONS

The Wendry Portable Digital TV offers a variety of ports for connecting external devices:

- **AV In/Out:** Connect external video sources (e.g., DVD player) or output video to another display.
- **USB Port:** Play media files (photos, music, videos) from a USB flash drive.
- **Memory/MMC Card Slot:** Play media files from a compatible memory card.
- **HDMI Input:** Connect high-definition devices such as gaming consoles, laptops, or Blu-ray players.
- **VGA Input:** Connect a computer or laptop for use as a monitor.
- **Headset Plug:** Connect headphones for private listening.



Multiple External Sources

The car digital TV supports AV in/out, SD/MMC card, USB port, VGA, HDMI, headset plug.



Image: A detailed view of the side panel of the portable TV, highlighting the multiple external source connection ports.

7. MAINTENANCE

7.1 Cleaning

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and exterior.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray liquid directly onto the screen or unit.
- Avoid using harsh chemicals, solvents, or abrasive cleaners.

7.2 Storage

- Store the TV in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove batteries from the remote control.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected; Power outlet faulty; TV not turned on.	Ensure power adapter is securely connected and plugged into a working outlet. Press the POWER button.
No picture/sound (TV mode)	No signal; Antenna not connected/positioned correctly; Channel scan not performed.	Check antenna connection and position. Perform an Auto Scan for channels.
No picture/sound (External source)	Incorrect input source selected; Cable not connected properly.	Press INPUT/SOURCE button to select the correct input. Check all cable connections.
Remote control not working	Batteries depleted or incorrectly inserted; Obstruction between remote and TV.	Replace batteries, ensuring correct polarity. Remove any obstructions. Point remote directly at the TV's IR sensor.
Poor picture quality	Weak signal; Interference.	Adjust antenna position. Check for sources of interference (e.g., other electronic devices).

9. SPECIFICATIONS

Screen Size:

12 Inches

Display Technology:

LED

Resolution:

1280 x 800 (supports 1080p input)

Aspect Ratio:

16:9

Tuner Type:

ATSC Digital Tuner, Analog TV (ATV)

Connectivity:

HDMI, USB, VGA, AV In/Out, Headset Jack, Memory/MMC Card Slot

Power Input:

DC 12V

Product Dimensions:

Approximately 12.09 x 7.8 x 0.98 inches (30.7 x 19.8 x 2.5 cm)

Item Weight:

Approximately 3.19 pounds (1.45 kg)




Image: The rear of the portable TV, showing the integrated foldable stand and product labeling including the model number D12.

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or contact Wendry customer support. If you encounter any issues or have questions regarding your Wendry 12-inch Portable Digital TV Model D12, please reach out to the seller or manufacturer for assistance.