

[manuals.plus](#) /

› [HADEN](#) /

› [Haden HERITAGE 1.7 Liter Stainless Steel Retro Electric Kettle with Auto Shut-Off and Boil Dry Protection in Light Blue Turquoise - User Manual](#)

## **HADEN 75004**

# **Haden HERITAGE 1.7 Liter Electric Kettle User Manual**

Model: 75004

## **1. INTRODUCTION**

---

Thank you for choosing the Haden HERITAGE 1.7 Liter Stainless Steel Retro Electric Kettle. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.



Image 1.1: The Haden Heritage 1.7 Liter Electric Kettle in Light Blue Turquoise, showcasing its retro design and stainless steel finish.

## 2. IMPORTANT SAFETY INFORMATION

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before use.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The kettle is equipped with a **Boil-Dry Protection** feature. If the kettle is accidentally switched on without water, or with insufficient water, the boil-dry protection will automatically switch off the heating element. Allow the kettle to cool down before refilling with cold water.
- All internal plastic components that come in contact with water are BPA-free.

### 3. PRODUCT COMPONENTS

---

Familiarize yourself with the parts of your Haden Heritage Electric Kettle:


- **Kettle Body:** The main stainless steel vessel.
- **Lid:** Removable lid for filling and cleaning.
- **Handle:** Ergonomically designed for pouring. Note: The handle may become warm during operation.
- **Spout:** For pouring water.
- **Water Level Window:** Transparent window to monitor water volume.
- **Power Switch:** Lever to turn the kettle on/off.
- **Indicator Light:** Illuminates when the kettle is boiling.
- **Power Base (360-Degree):** Cordless base for easy placement and removal of the kettle.
- **Removable Filter:** Located behind the spout, helps remove limescale.



Premium coated  
stainless steel  
housing.



Automatic shut off upon  
reaching boiling point  
with boil-dry protection.



Removable filter for  
convenient cleaning  
and maintenance.



360-Degrees Base  
ensures stability and  
prevents tipping.

Image 3.1: Close-up view highlighting the premium coated stainless steel housing, automatic shut-off with boil-dry protection, removable filter, and the 360-degree power base.

## 4. SETUP AND FIRST USE

- Unpack:** Carefully remove the kettle and all accessories from the packaging. Retain the packaging for future storage or disposal.
- Clean:** Before first use, fill the kettle with clean water to the MAX fill line. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.
- Position:** Place the power base on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure the power cord is not dangling or touching hot surfaces.

## 5. OPERATING INSTRUCTIONS

- Fill the Kettle:** Remove the kettle from its power base. Open the lid and fill the kettle with the desired amount of fresh, cold water. Do not fill below the MIN mark or above the MAX mark (1.7 liters). Overfilling may cause boiling.

water to spill out.

2. **Close Lid:** Securely close the lid after filling.
3. **Place on Base:** Place the kettle firmly onto the power base.
4. **Connect Power:** Plug the power cord into a standard 120V AC electrical outlet.
5. **Start Boiling:** Push the power switch lever downwards. The indicator light will illuminate, indicating that the kettle is heating.
6. **Automatic Shut-Off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off, and the power switch will return to the upright position.
7. **Pour Water:** Carefully lift the kettle from the base and pour the hot water. Be cautious of steam escaping from the spout and lid.
8. **Re-boiling:** If you need to re-boil, wait a few moments for the thermostat to reset before pushing the switch down again.



## HERITAGE TURQUOISE & CHROME ELECTRIC KETTLE



1.7-liter (6-cup)  
ample capacity  
for boiling water.



Water gauge allows  
easy monitoring of  
water level for accuracy.



Indicator light  
illuminates when the  
water is boiling.



Boasts 1500W of  
power with a 30"  
power cord.

Image 5.1: Visual representation of key operational features: 1.7-liter capacity, water gauge for monitoring, indicator light during boiling, and 1500W power for rapid boiling.

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will prolong the life of your kettle.

### 6.1. Cleaning the Exterior

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
- Ensure the power base and the bottom of the kettle remain dry.

### 6.2. Cleaning the Filter

- The removable filter, located behind the spout, can be cleaned to prevent limescale buildup from affecting water quality.
- Remove the filter by gently pulling it upwards or unlatching it (refer to diagram if available, otherwise general instruction).
- Rinse the filter under running water and brush gently with a soft brush if necessary.
- Reinsert the filter securely after cleaning. A spare filter is included for convenience.

### 6.3. Descaling

Limescale buildup can affect the kettle's performance and taste of water, especially in hard water areas. Descaling regularly (e.g., monthly or bi-monthly).

- Fill the kettle with a solution of white vinegar and water (1:2 ratio) or a commercial descaling solution according to product instructions.
- Bring the solution to a boil and let it stand for at least 30 minutes, or longer for heavy buildup.
- Discard the solution and rinse the kettle thoroughly several times with fresh water.
- Boil fresh water once or twice and discard to remove any residual vinegar taste.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in. Power switch not engaged. Boil-dry protection activated. No power at outlet.	Ensure kettle is properly plugged into a working outlet. Push the power switch lever fully downwards. Allow kettle to cool down for 10-15 minutes, then refill with cold water and try again. Check household fuse/circuit breaker.

Problem	Possible Cause	Solution
Water not boiling or taking too long.	Lid not closed properly. Excessive limescale buildup.	Ensure the lid is securely closed. Descale the kettle as per Section 6.3.
Water tastes unusual.	New appliance residue. Limescale buildup.	Perform first-use cleaning steps (boil and discard water several times). Descale the kettle as per Section 6.3.
Handle gets hot during use.	Normal operation.	This can be a characteristic of the design. Always use caution when handling the kettle after boiling. Consider using an oven mitt or cloth if the handle is uncomfortably hot.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	HADEN
Model Number	75004
Colour	Turquoise
Capacity	1.7 Liters (approx. 7 cups)
Power/Wattage	1500W
Voltage	120 Volts
Material	Stainless Steel
Product Dimensions (L x W x H)	24.13 x 17.78 x 26.67 cm
Item Weight	1.36 kg
Auto Shut-off	Yes
Special Features	Boil-Dry Protection, Removable Filter, 360-Degree Swivel Base, BPA-Free internal components



Image 8.1: Product dimensions for the Haden Heritage Electric Kettle.

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official HADEN website. Keep your proof of purchase for any warranty claims.

You can visit the HADEN Store online for more information: [HADEN Official Store](#)

	<p><a href="#"><u>Haden Heritage Kettle HK01010-US Instruction Manual &amp; User Guide</u></a></p> <p>Comprehensive instruction manual and user guide for the Haden Heritage Kettle (Model HK01010-US), covering safety, operation, cleaning, and warranty information.</p>
	<p><a href="#"><u>Haden Heritage Kettle Instruction Manual &amp; User Guide (Model 75004, 75012)</u></a></p> <p>Comprehensive user manual for the Haden Heritage Kettle (models 75004 &amp; 75012). Includes setup, operation, safety precautions, cleaning instructions, and warranty details.</p>
	<p><a href="#"><u>Haden Dorchester Kettles Instruction Manual: Usage, Care, and Warranty</u></a></p> <p>Comprehensive instruction manual for the Haden Dorchester Kettles (Product Codes 201270 &amp; 201300). Learn about setup, operation, temperature control, keep warm function, cleaning, descaling, technical specifications, and warranty.</p>
	<p><a href="#"><u>Haden Heritage Kettle HK01010-US Instruction Manual</u></a></p> <p>Comprehensive instruction manual for the Haden Heritage Kettle (Model HK01010-US), covering safety precautions, components, usage, care, cleaning, descaling, technical details, and limited warranty.</p>
	<p><a href="#"><u>Haden Heritage Kettle HK01010-US Instruction Manual</u></a></p> <p>Instruction manual for the Haden Heritage Kettle Model HK01010-US, covering setup, usage, care, cleaning, and warranty information.</p>
	<p><a href="#"><u>Haden Salcombe Kettle (191113) - Instruction Manual and User Guide</u></a></p> <p>Official instruction manual for the Haden Salcombe Kettle (Product Code: 191113). Includes important safety information, operating instructions, cleaning, maintenance, descaling, technical details, and warranty information.</p>

