



Manuals.plus /

› Wendry /

› Wendry Smart Projector User Manual (Model: Wendry0fw4c39u5i-01)

## Wendry Wendry0fw4c39u5i-01

# Wendry Smart Projector User Manual

Model: Wendry0fw4c39u5i-01

## 1. INTRODUCTION

---

Thank you for purchasing the Wendry Smart Projector. This portable LED projector is designed to provide a versatile viewing experience for both indoor and outdoor entertainment. This manual will guide you through the setup, operation, and maintenance of your new projector to ensure optimal performance.

## 2. PACKAGE CONTENTS

---

Please verify that all items listed below are included in your package:

- Wendry Smart Projector Unit
- Remote Control
- Power Adapter
- AV Cable (3-in-1 RCA)
- HDMI Cable
- User Guide
- Cleaning Cloth
- 100-inch Projection Screen
- Wall Mount Hooks for Screen



Figure 2.1: Wendry Smart Projector and included accessories.

### 3. PRODUCT FEATURES

---

- **High-Definition Display:** Supports 720P and 1080P resolution for clear and natural images.
- **Portability:** Small and lightweight design for easy transport and setup.
- **Brightness:** 3000 lumens for vibrant presentations.
- **Multiple Connectivity Options:** Includes HDMI, AV, VGA, USB, and Micro SD card slots.
- **Integrated Audio:** Features a built-in speaker and a headphone jack for external audio.
- **Adjustable Projection:** Manual focus adjustment, aspect ratio selection (16:9 to 4:3), and a projection distance of 1.0-2.8 meters.
- **Long-Life Lamp:** Equipped with RGB lamps offering up to 30,000 hours of operational life.

## Support 1080P HD Displaying

Support 720P, 1080P display, allows you to enjoy clear and natural images and videos in a large screen



Figure 3.1: High-definition display capabilities.

# Multiple Input Interface

• 1 x HDMI • AV • 1 x USB • VGA • Micro SD



Figure 3.2: Multiple input interfaces for diverse media devices.

## 4. SETUP

---

### 4.1. Initial Placement

Place the projector on a stable, flat surface. Ensure there is adequate ventilation around the unit.

### 4.2. Power Connection

1. Connect the power adapter to the DC IN port on the projector.
2. Plug the power adapter into a suitable electrical outlet.

### 4.3. Connecting Input Sources

Connect your desired media device (e.g., laptop, TV box, game console, USB drive) to the projector using the appropriate port:

- **HDMI:** For high-definition video and audio.

- **USB:** For playing media files directly from a USB flash drive.
- **AV:** For standard definition video and audio using the included AV cable.
- **VGA:** For connecting older computers or devices.
- **Micro SD:** For playing media files directly from a Micro SD card.

#### 4.4. Setting Up the Projection Screen

The included 100-inch projection screen can be mounted using the provided hooks and adhesive stickers. Follow the instructions on the screen packaging for proper installation.



Figure 4.1: Example of outdoor projection setup.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Power On/Off

Press the power button on the projector or the remote control to turn the unit on or off.

### 5.2. Adjusting Focus

Rotate the focus ring located on the projector lens until the image on the screen appears clear and sharp.

## 30000 hours long life RGB lamps

Harmless and no radiation, environmental-friendly and durable to use



Figure 5.1: Adjusting projection for optimal viewing.

### 5.3. Selecting Input Source

Use the 'Source' button on the remote control or the projector's control panel to cycle through available input sources (USB, TF, HDMI, AV, VGA).

### 5.4. Menu Navigation and Volume Control

Use the arrow keys and 'OK' button on the remote control or projector to navigate through menus and make selections. Adjust the volume using the dedicated volume buttons on the remote.

### 5.5. Aspect Ratio Adjustment

The projector supports aspect ratio adjustments from 16:9 to 4:3. Refer to the on-screen menu for specific settings.

## 6. MAINTENANCE

---

### 6.1. Cleaning the Lens

Gently wipe the projector lens with the provided cleaning cloth or a soft, lint-free cloth. Avoid using abrasive materials or harsh chemicals that could damage the lens.

### 6.2. General Cleaning

Wipe the exterior of the projector with a soft, dry cloth. Ensure ventilation vents are clear of dust and debris to prevent overheating.

## 7. TROUBLESHOOTING

---

If you encounter issues with your projector, please refer to the following common solutions:

- **No Power:** Ensure the power adapter is securely connected to both the projector and the electrical outlet.
- **No Image:** Verify that the correct input source is selected. Check all cable connections (HDMI, AV, VGA, USB).
- **Blurry Image:** Adjust the focus ring on the projector lens. Ensure the projection surface is flat and the projector is at an appropriate distance.
- **No Sound:** Check the volume settings on both the projector and the connected media device. If using external speakers, ensure they are properly connected.
- **Remote Control Not Working:** Ensure batteries are correctly inserted and functional. Point the remote directly at the projector's IR receiver.

For further assistance, please consult the full user guide or contact customer support.

## 8. SPECIFICATIONS

---

Feature	Specification
Product Dimensions	5 x 3.21 x 1.91 inches
Item Weight	1.01 pounds
Model Number	Wendry0fw4c39u5i-01
Display Resolution	320 x 240 (Native), Supports 720P/1080P
Connectivity Technology	HDMI, USB, VGA, AV, Micro SD
Special Feature	Lightweight, Portable
Recommended Uses	Gaming, Home Cinema, Outdoor Recreation
Lamp Life	30,000 hours (RGB LED)
Brightness	3000 lumens

