

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Rokform](#) /

› [Rokform Slim Crystal Series Magnetic Case for iPhone 11 Pro Instruction Manual](#)

Rokform 306020P

Rokform Slim Crystal Series Magnetic Case for iPhone 11 Pro

Model: 306020P

INTRODUCTION

Thank you for choosing the Rokform Slim Crystal Series Magnetic Case for your iPhone 11 Pro. This case is engineered to provide robust protection, magnetic mounting capabilities, and a secure RokLock twist mount system, enhancing the functionality and safety of your device.

Please read this manual thoroughly to understand the features and proper usage of your new case.

PACKAGE CONTENTS

- Rokform Slim Crystal Series Case for iPhone 11 Pro
- Integrated Magnet
- Optional Magnetic Plug

KEY FEATURES

- **Magnetic Integration:** Features a powerful industrial-grade magnet built into the case, along with an optional magnetic plug. This allows attachment to any magnetic surface without affecting credit cards, Wi-Fi, GPS, or Bluetooth functionality.
- **RokLock Twist Mount System:** The integrated RokLock enables secure mounting of your iPhone 11 Pro to various optional Rokform mounts for motorcycles, UTVs/ATVs, bicycles, or strollers. Mounts are sold separately.
- **Advanced Protection:** Constructed from high-impact polycarbonate armor with reinforced corners. This design provides dual-layer protection that surpasses Military Grade Drop Test Standards (MIL-STD 801G-516.6), absorbing shocks and drops.
- **Precision Design:** Engineered in California for a perfect fit, this lightweight yet durable case includes a raised bezel for six-sided, 360-degree protection of your smartphone.
- **Easy-Press Buttons:** Unique design cutouts ensure feather-light operation of phone buttons.

- **Lanyard Attachment:** Includes a point for attaching a Rokform detachable lanyard (not included) to help prevent accidental drops.

SETUP

Installing the Case

1. Ensure your iPhone 11 Pro is clean and free of dust or debris.
2. Align the iPhone 11 Pro with the case, starting with the top edge.
3. Gently press the phone into the case, ensuring all corners and edges are securely seated. Verify that all buttons and ports align correctly with the case cutouts.

Optional Magnetic Plug Installation

The case includes an optional magnetic plug for enhanced magnetic holding power. This plug can be inserted into the central RokLock port on the back of the case.

1. Locate the circular RokLock port on the back of the case.
2. Insert the optional magnetic plug into this port, ensuring it sits flush with the case surface.

MAGNETIC MOUNTING



Image: Illustration of the magnetic mounting system, showing the powerful magnet and optional dual magnet for enhanced grip.

Using the Magnetic Mounting Feature

The integrated magnet allows you to securely attach your iPhone 11 Pro to any magnetic surface. This is ideal for hands-free viewing in various environments.

- Simply place the back of the case onto a magnetic surface. The strong magnet will hold your device in place.
- The magnet is designed not to interfere with your phone's functions, including credit cards, Wi-Fi, GPS, or Bluetooth.

Using the RokLock Twist Mount System

The RokLock system provides a secure mechanical connection to compatible Rokform mounts (sold separately).

1. Align the RokLock port on the back of your case with the corresponding RokLock mechanism on your chosen mount.
2. Insert the case into the mount and twist clockwise until you feel a secure click. This indicates the phone is locked into place.
3. To remove, twist counter-clockwise and pull the phone away from the mount.

ROKLOCK TWIST LOCK SYSTEM



ROKLOCK TWIST

Securely mount your phone to a variety of optional mounts for bikes, cars, motorcycles, and more.



CARE AND MAINTENANCE

- To clean your Rokform case, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the case material.
- Regularly inspect the case for any signs of wear or damage, especially around the corners and ports, to ensure continued protection.

TROUBLESHOOTING

Issue: iPhone Lock Button Not Responding or Glitching

Some users may experience issues with the iPhone's side button (lock/power button) not functioning correctly or the screen automatically turning off when the case is installed. This can occur because the iPhone's sensors may interpret the case's magnet as a folio cover, triggering certain behaviors.

Solution 1: Adjust iPhone Settings

- Navigate to your iPhone's **Settings**.
- Go to **Display & Brightness**.
- Check for settings related to 'Lock / Unlock' or 'Cover Lock'. Ensure that any automatic screen lock/unlock features related to covers are disabled if they are causing interference.

Solution 2: Remove the Optional Magnetic Plug

If you have installed the optional magnetic plug in the RokLock port, removing it may resolve the issue. The case still retains magnetic capabilities with its integrated magnet.

1. Carefully pry out the optional magnetic plug from the RokLock port on the back of the case.
2. Test the lock button functionality.

If issues persist, please contact Rokform customer support for further assistance.

SPECIFICATIONS

Product Dimensions	5.88 x 3 x 0.52 inches
Item Weight	1.8 ounces
Item Model Number	306020P
Compatible Phone Models	iPhone 11 Pro
Material	Polycarbonate, Thermoplastic Polyurethane
Color	Clear
Special Features	Magnetic, Protective, Rugged, Twist Lock

MAXIMUM PROTECTION WITHOUT THE BULK



Image: Case dimensions for iPhone 11 Pro.

WARRANTY INFORMATION


Rokform offers a 2-year warranty on its entire product catalog. This warranty covers manufacturing defects and ensures product quality.

For any issues with your purchase or to claim warranty service, please contact Rokform customer support directly. Provide your purchase details and a description of the issue for prompt assistance.

SAFETY INFORMATION

WARNING: This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Related Documents - 306020P

<p>SHELTER ASSEMBLY MANUAL Model: 304020P/W9.15x11.2mxH6.1m Model: 306020P/W9.15x11.8m xH6.1m Model: 308020P/W9.15x12.4m xH6.1m</p> 	<p>Shelter Assembly Manual for Models 304020P, 306020P, 308020P</p> <p>Comprehensive assembly manual for SHELTER structures, detailing parts lists, specifications, tools required, and step-by-step instructions for frame and cover installation for models 304020P, 306020P, and 308020P.</p>
 <p>Look around for the date and the date code</p> <p>DATE CODE: 20250101 DATE CODE: 20250102 DATE CODE: 20250103 DATE CODE: 20250104 DATE CODE: 20250105 DATE CODE: 20250106 DATE CODE: 20250107 DATE CODE: 20250108 DATE CODE: 20250109 DATE CODE: 20250110 DATE CODE: 20250111 DATE CODE: 20250112 DATE CODE: 20250113 DATE CODE: 20250114 DATE CODE: 20250115 DATE CODE: 20250116 DATE CODE: 20250117 DATE CODE: 20250118 DATE CODE: 20250119 DATE CODE: 20250120 DATE CODE: 20250121 DATE CODE: 20250122 DATE CODE: 20250123 DATE CODE: 20250124 DATE CODE: 20250125 DATE CODE: 20250126 DATE CODE: 20250127 DATE CODE: 20250128 DATE CODE: 20250129 DATE CODE: 20250130 DATE CODE: 20250131</p>	<p>ROKFORM G-Rok Pro Bluetooth Golf Speaker: Date Coding and Specifications</p> <p>Detailed information on the ROKFORM G-Rok Pro Bluetooth Golf Speaker, including its design, FCC ID, model number, input/output specifications, and a guide to understanding its manufacturing date coding system.</p>