

ReplacementScrews RSAZN206941

Product Manual

REPLACEMENTSCREWS WALL MOUNT SCREW KIT

Compatible with Toshiba 50LF621U19 TV (Model: RSAZN206941)

1. Overview

This manual provides detailed instructions for the installation and proper use of the ReplacementScrews Wall Mount Screw Kit. This kit is specifically designed to ensure secure mounting of your Toshiba 50LF621U19 television to a compatible VESA wall mount. It includes all necessary hardware for a reliable and stable installation.

2. Kit Components

The ReplacementScrews Wall Mount Screw Kit includes the following components:

- **4 x M6 Screws:** Specifically sized for the Toshiba 50LF621U19 TV's VESA mounting points.
- **4 x Split Lock Washers:** Designed to exert pressure, preventing screws from loosening due to vibrations.
- **4 x Extra Large Flat Washers:** Distribute the load evenly and protect the TV's mounting surface.
- **8 x Nylon Spacers:** Provide additional length configurations and create space for cables, enhancing installation flexibility.

All screws are black oxide plated for corrosion resistance and a sleek appearance that matches most TV and mount components.



Figure 1: Complete set of ReplacementScrews wall mount components.

3. Setup and Installation

Follow these general steps to install your Toshiba 50LF621U19 TV using the ReplacementScrews kit. *Always consult your TV's original manual for specific VESA mounting instructions and safety guidelines before proceeding.*

1. **Prepare the TV:** Carefully place your Toshiba 50LF621U19 TV face down on a soft, clean surface to protect the screen. Locate the VESA mounting holes on the back of the TV.
2. **Select Screws and Spacers:** The kit includes M6 screws. Determine if spacers are needed to achieve the correct screw length and to provide adequate clearance for cables. The 8 Nylon spacers offer various length options.
3. **Assemble Hardware:** For each mounting point, place a flat washer onto an M6 screw, followed by a split lock washer. If using a spacer, place it between the TV and the wall mount bracket.
4. **Attach to Wall Mount:** Align the TV with your VESA-compatible wall mount bracket. Insert the assembled screws through the wall mount bracket, through any chosen spacers, and into the TV's VESA mounting holes.

5. **Secure the TV:** Hand-tighten all four screws initially to ensure proper alignment. Then, use a screwdriver to tighten them securely. *Do not overtighten, as this can damage the TV or the screws.* Ensure the TV is firmly attached to the mount.



Figure 2: Screws with spacers attached, illustrating proper assembly for mounting.



Figure 3: VESA compliant screw and spacer set for Toshiba 50LF621U19.

4. Usage Guidelines

Once installed, ensure the TV is stable and level. The combination of flat washers and split lock washers provides optimal grip and prevents loosening over time. Periodically check the tightness of the screws to maintain a secure mount, especially after moving the TV or mount.

5. Maintenance

The black oxide plating on the screws offers resistance to corrosion, ensuring long-term durability. No special maintenance is required for the screws themselves. However, it is recommended to:

- Periodically inspect the mounting hardware for any signs of wear or loosening.
- Gently clean any dust or debris from the screws and washers with a dry cloth if necessary.



Figure 4: Black oxide plated screws for enhanced durability and appearance.

6. Troubleshooting

- **Screws do not fit:** Ensure you are using the correct M6 screws for your Toshiba 50LF621U19 TV. If the length is incorrect, adjust with the provided spacers. Refer to your TV's manual for exact screw specifications.
- **TV feels unstable after mounting:** Verify that all screws are tightened securely (but not overtightened). Check that the wall mount itself is properly installed according to its manufacturer's instructions. Ensure the correct washers and spacers are used in the proper order.
- **Cables are pinched:** Utilize the nylon spacers to create sufficient distance between the TV and the wall mount, allowing for proper cable management without pinching.

7. Specifications

Feature	Detail
Model Number	RSAZN206941
Compatibility	Toshiba 50LF621U19 TV (M6 VESA standard)
Material	Alloy Steel, Carbon Steel
Exterior Finish	Black Oxide
Thread Size	M6 (Metric)
Head Style	Flat, Pan

Feature	Detail
Number of Pieces	4 screws, 4 flat washers, 4 split lock washers, 8 nylon spacers
Item Weight	1.92 Ounces
Product Dimensions	6.5 x 3.75 x 0.5 inches (packaging)

8. Warranty Information

No specific warranty information for this product is provided in the available documentation. Please refer to the retailer or manufacturer's website for any applicable warranty details.

9. Support

For further assistance, questions regarding installation, or product inquiries, please contact ReplacementScrews customer support through their official channels or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07WWYCWRP>

More documents and user manuals: <https://manuals.plus/>