

Noma B07X2LJ3QP

Noma LED Net Christmas Lights User Manual

Model: B07X2LJ3QP

INTRODUCTION

This manual provides instructions for the safe and effective use of your Noma LED Net Christmas Lights. Please read all instructions carefully before installation and operation. Retain this manual for future reference.



Image: Noma LED Net Christmas Lights installed on outdoor shrubbery during winter.

SAFETY INFORMATION

- **Electrical Safety:** Always ensure the power outlet is suitable for outdoor use and protected by a Ground Fault Circuit Interrupter (GFCI) when used outdoors.
- **Installation:** Do not install lights in a manner that could damage the wire insulation. Avoid placing lights where they can be stepped on or damaged.
- **Overloading:** Do not exceed the maximum connectable sets. This product allows connection of up to 30 sets.
- **Damage Check:** Inspect the lights for any damage to the wire, bulbs, or plugs before each use. Do not use if damaged.
- **Bulb Replacement:** These LED bulbs are not user-replaceable. Do not attempt to remove or replace individual bulbs.
- **Storage:** Unplug the lights when not in use. Store in a cool, dry place.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the net lights from their packaging.
2. **Placement:** Position the net lights over the desired area, such as shrubs, bushes, or other outdoor greenery. The 4 ft x 4 ft mesh design is ideal for covering uniform surfaces.
3. **Connecting Multiple Sets:** If using multiple sets, locate the plug-ins at both ends of each strand. Connect the male plug of one set into the female receptacle of another. You can connect up to 30 sets together for extended coverage.
4. **Secure Installation:** Ensure the net is evenly spread and secured to prevent tangling or displacement by wind.
5. **Power Connection:** Plug the main power cord into a suitable 120V AC outdoor-rated electrical outlet. Ensure the outlet is protected by a GFCI.



100 Energy-Efficient LEDs

Go green with our long-lasting energy-efficient LED bulbs

Indoor & Outdoor

Simple to install on shrubs, bushes, and other outdoor greenery

Connect 30 Strands

Plug-ins at both ends allow you to connect up to 30 sets

Image: Detailed view of the net light structure, highlighting the LED bulbs and connection points.

OPERATING INSTRUCTIONS

The Noma LED Net Christmas Lights are designed for simple operation. Once properly installed and plugged into a power source, the lights will illuminate. This model features a basic on/off functionality controlled by the power source.

- **To Turn On:** Plug the power cord into an active electrical outlet.
- **To Turn Off:** Unplug the power cord from the electrical outlet.

For automated operation, consider using an external timer (sold separately) with your electrical outlet.

MAINTENANCE

- **Cleaning:** Disconnect from power before cleaning. Wipe the lights gently with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully unplug the lights and coil them neatly to prevent tangling. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the wiring and bulbs for any signs of wear, cuts, or damage. Discontinue use if damage is found.

TROUBLESHOOTING

- **Lights Not Illuminating:**

- Ensure the power cord is securely plugged into a functional electrical outlet.
- Check if the GFCI outlet has tripped. Reset if necessary.
- Verify that the power source is active. Test with another appliance.
- Inspect the entire strand for any visible damage to the wires or plugs.

- **Partial Section Not Lighting:**

- This product uses non-replaceable LED bulbs. If a section fails, it may indicate internal wiring damage. Discontinue use and contact customer support.

- **Flickering Lights:**

- Ensure all connections are secure, especially if multiple sets are linked.
- Avoid overloading the circuit by connecting too many sets beyond the recommended limit.

SPECIFICATIONS

Feature	Detail
Brand	Noma
Model Number	B07X2LJ3QP
Light Color	Pure White
Number of Lights	100 LED Bulbs

Net Dimensions	4 ft x 4 ft (1.2 x 1.2 m)
Indoor/Outdoor Usage	Indoor, Outdoor
Power Source	Plug-in (Corded)
Voltage	120 Volts (AC)
Wattage	7.2 watts
Connectivity	End-to-end, up to 30 sets
Material	Plastic
Item Weight	1.25 pounds
UPC	029944571056

WARRANTY INFORMATION

This Noma LED Net Christmas Lights product is covered by a **3-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, or to initiate a warranty claim, please contact Noma customer support.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about warranty services, please visit the official Noma store or contact their customer service department.

Noma Store: [Visit the Noma Store on Amazon](#)