

Manuals.plus /

> KYODOLED /

> KYODOLED 40-Key Combination Lock Wall Mount Key Cabinet (Model P0073)

KYODOLED P0073

KYODOLED 40-Key Combination Lock Wall Mount Key Cabinet

Model: P0073 | Brand: KYODOLED

INTRODUCTION

Thank you for choosing the KYODOLED 40-Key Combination Lock Wall Mount Key Cabinet. This manual provides essential information for the proper installation, operation, and maintenance of your key cabinet. Designed for organized and secure key storage, this cabinet is ideal for homes, offices, apartment complexes, car lots, rental agencies, and businesses. Please read this manual thoroughly before use and retain it for future reference.

PRODUCT OVERVIEW

The KYODOLED 40-Key Combination Lock Wall Mount Key Cabinet is constructed from heavy-duty steel, ensuring durability and reliable protection for your keys. It features a resettable 3-digit combination lock for enhanced security and comes with all necessary accessories for efficient key organization.

Key Features:

- **40-Key Storage Capacity:** Includes 40 key rings, identification tags, and labels for easy sorting and identification. (Note: Not designed for bulky remote car keys.)
- **Resettable 3-Digit Combination Lock:** Offers 1,000 possible codes for secure, customizable access.
- **Heavy-Duty Steel Construction:** Provides long-lasting durability and robust security.
- **Wall-Mounted Design:** Saves space and keeps keys securely in a fixed location.

Included Components:

- Key Cabinet
- 40 Key Hooks
- 40 Key Tags
- Mounting Hardware (screws and wall anchors)

Product Size & Accessories



Image: Product dimensions (12.1" H x 8.1" W x 2.5" D) and included accessories like 40 key tags, 40 'out key' tags, and mounting hardware.

Video: Overview of the KYODOLED Key Storage Box with Combination Lock, highlighting its features and organization capabilities.

SETUP & INSTALLATION

The key cabinet is designed for easy wall-mounted installation. Follow these steps to securely mount your cabinet:

1. **Choose a Location:** Select a suitable wall location that is secure and easily accessible.
2. **Mark Drill Points:** Hold the cabinet against the wall at the desired height and use a pencil to mark the positions of the pre-drilled mounting holes on the back of the cabinet.
3. **Drill Holes:** Using an appropriate drill bit for your wall type (e.g., masonry bit for concrete, wood bit for studs), drill holes at the marked positions.
4. **Insert Wall Anchors:** If installing into drywall or masonry, insert the provided wall anchors into the drilled holes.
5. **Mount the Cabinet:** Align the cabinet's mounting holes with the drilled holes (and anchors). Insert the provided screws and tighten them until the cabinet is securely fastened to the wall. Ensure the cabinet is stable and does not wobble.



Image: Visual guide for wall mounting, illustrating marking, drilling, and securing the cabinet.

OPERATING INSTRUCTIONS

Setting Your Combination Code:

The factory default code is "0-0-0". To set your personal 3-digit code:

1. **Open the Lock Box:** Ensure the lock is set to the default code "0-0-0". Twist the knob to the "unlock" position to open the door.
2. **Locate Reset Lever:** Inside the open door, find the small lever on the back of the combination lock mechanism.
3. **Move Reset Lever:** Use your fingers to move the lock slot from position A to the side, then up to position B. *Do not move it directly from A to B, as it may get stuck.*
4. **Set Your New Code:** While the lever is in position B, roll the dials on the front of the lock to your desired 3-digit code (e.g., "3-2-1"). Make sure all numbers are centered in the dial.
5. **Return Reset Lever:** Move the lock slot back from position B to position A to complete the code setting.
6. **Test Your New Code:** Close the door, scramble the dials, then enter your new code and twist the knob to ensure it opens correctly.

Note: After setting your own password, "0-0-0" is no longer the default code. Please do not forget your code, otherwise, it may take considerable time to find it.



Image: Step-by-step instructions for setting and resetting the 3-digit combination lock.

Video: Demonstrates the process of setting the password for the combination lock.

Opening the Lock Box:

To open the key cabinet, align the dials to your set 3-digit combination code and twist the knob to the "unlock" position. The door will then open.

KEY MANAGEMENT

The KYODOLED key cabinet is designed to keep your keys organized and easily identifiable.

1. **Attach Keys to Hooks:** Use the provided key rings to attach your keys to the numbered key tags.
2. **Label Key Tags:** Write down relevant information (e.g., room number, vehicle, owner) on the identification tags and corresponding labels.
3. **Hang Keys:** Hang the key tags on the designated hooks inside the cabinet. The numbered system helps maintain order.
4. **Use 'Out Key' Tags:** Utilize the 'out key' tags to mark when a key has been removed, helping you track key usage.



Image: Illustrates the process of attaching keys to numbered tags and recording information for efficient key management.

Video: Demonstrates how to keep keys organized and safe within the key storage box.

MAINTENANCE

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Hinge Lubrication:** Periodically apply a small amount of lubricant to the door hinges to ensure smooth operation.
- **Lock Mechanism:** Keep the combination lock mechanism clean and free of dust or debris. Do not force the dials if they are stiff.

TROUBLESHOOTING

Forgotten Combination Code:

If you forget your combination code, you will need to reset it. Follow the "Setting Your Combination Code" instructions in the Operating Instructions section. You will need to know the current code (even if forgotten, you might need to try combinations or consult with the manufacturer for advanced reset procedures if the internal reset lever is inaccessible without the code).

Difficulty Opening/Closing:

- Ensure the combination dials are perfectly aligned with your code.
- Check for any obstructions around the door or hinges.
- If the door is stiff, apply a small amount of lubricant to the hinges.

SPECIFICATIONS

Feature	Detail
Brand	KYODOLED
Model Name	P0073
Color	Black Combination Lock
Material	Heavy-Duty Steel
Product Dimensions (D x W x H)	2.5" x 8" x 12"
Key Capacity	40 Keys
Lock Type	3-Digit Resettable Combination Lock
Mounting Type	Wall Mount
Item Weight	3.5 Pounds
Weight Limit	4 Pounds

SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 4 pounds to prevent damage or failure of the key cabinet.
- Ensure the cabinet is securely mounted to a sturdy wall to prevent it from falling.
- Keep the combination code confidential and in a safe place, separate from the cabinet.

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the product packaging or contact KYODOLED customer service directly. Contact details can typically be found on the manufacturer's website or through your point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07X37W4YG>

More documents and user manuals: <https://manuals.plus/>