

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

SMARTSTANDARD SDH00902IBK

SMARTSTANDARD 9ft Barn Door Hardware Kit User Manual

Brand: SMARTSTANDARD | Model: SDH00902IBK

PRODUCT OVERVIEW

The SMARTSTANDARD 9ft Barn Door Hardware Kit is designed to provide a smooth, quiet, and durable sliding solution for your barn door. Crafted from high-quality carbon steel, this heavy-duty kit ensures long-lasting performance and prevents deformation. The nylon rollers are engineered for silent operation, having undergone extensive testing to guarantee reliability. This kit is suitable for various door panel types, including wood, glass, and MDF, and is an excellent choice for optimizing space in living rooms, kitchens, bedrooms, and other areas.




Image: The SMARTSTANDARD 9ft Barn Door Hardware Kit installed with a wooden barn door, showcasing the complete system.

Package Contents:

- 2x 4.5 FT Rails (forming a 9 FT track)
- 7x Rail Spacers
- 2x Rollers (I Shape Hanger)
- 2x Door Stops
- 2x End Caps
- 1x Floor Guide
- 1x Hex Key
- All other necessary hardware for installation (screws, bolts, etc.)

Note: Door panel is NOT included in this hardware kit.

SETUP AND INSTALLATION

This barn door hardware kit is designed for easy installation. Follow these general steps. For detailed, step-by-step instructions, please refer to the included physical manual or the official PDF document available online.



Easy



Image: Visual representation of the installation process, highlighting the ease of assembly.

Before You Begin:

- Ensure your door panel width is 54 inches and thickness is between 1 3/8" and 1 3/4".
- Verify that your wall studs are 16 inches on center for proper rail mounting.
- Gather necessary tools: measuring tape, pencil, drill, level, wrench, screwdriver.
- Consider installing a sturdy header board if your wall studs do not align with the track holes, especially for heavy doors. This ensures maximum safety and stability.



Image: Important dimensions for installation, including maximum door width (54") and required clearance (5" above door).

Installation Steps:

- Measure and Mark:** Determine the desired height for your track. Mark the drilling points for the rail spacers on your wall, ensuring they align with wall studs.
- Install Rail Spacers:** Drill pilot holes and attach the rail spacers securely to the wall.
- Mount the Rail:** Attach the two 4.5 FT rail sections to the installed spacers, ensuring they are level and securely fastened.
- Attach Rollers to Door:** Secure the I-shape hangers (rollers) to the top edge of your barn door panel. Ensure they are properly aligned and tightened.
- Install Door Stops and End Caps:** Slide the door stops onto the rail and position them to prevent the door from sliding too far. Install the end caps on both ends of the rail for a finished look and to prevent rollers from coming off.
- Install Floor Guide:** Position and secure the floor guide at the bottom of the door opening to keep the door stable and prevent it from swinging out.
- Hang the Door:** Carefully lift the door panel and hook the rollers onto the mounted rail.

8. **Adjust and Test:** Adjust the door stops for desired travel distance. Test the door's movement to ensure it slides smoothly and quietly.



**SMART
STANDARD**

Image: A comprehensive view of all hardware components included in the kit, ready for assembly.

OPERATING INSTRUCTIONS

Operating your SMARTSTANDARD barn door is simple and intuitive. The system is designed for smooth and quiet gliding.

- To open the door, gently push or pull the door panel along the track until it reaches the desired open position.
- To close the door, gently push or pull the door panel back along the track until it covers the opening.
- The door stops will prevent the door from sliding off the ends of the track.
- The floor guide will keep the bottom of the door stable during movement.



Image: A barn door installed in a living room, demonstrating its functional and aesthetic integration into a home environment.



Image: A barn door installed in a bedroom, illustrating its use as a space-saving and stylish room divider.

MAINTENANCE

Regular maintenance will ensure the longevity and smooth operation of your barn door hardware kit.

- **Cleaning:** Wipe down the rail and hardware components periodically with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners that could damage the finish.
- **Lubrication:** The nylon rollers are designed for smooth operation and typically do not require lubrication. However, if you notice any squeaking or stiffness over time, a small amount of silicone-based lubricant can be applied to the roller bearings.
- **Tightness Check:** Periodically check all screws and bolts, especially those securing the rail to the wall and the hangers to the door, to ensure they remain tight. Loose fasteners can affect performance and safety.
- **Floor Guide:** Keep the floor guide clean and free of debris to ensure the door slides without obstruction.

TROUBLESHOOTING

If you encounter any issues with your barn door hardware, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Door does not slide smoothly.	Dirt or debris on the track; loose rollers; damaged rollers.	Clean the track. Check and tighten roller bolts. Inspect rollers for damage and replace if necessary.
Squeaking noise during operation.	Lack of lubrication on rollers; friction between components.	Apply a small amount of silicone-based lubricant to the roller bearings. Ensure all components are properly aligned.
Door stops are not holding securely.	Set screws are loose; improper positioning.	Tighten the set screws on the door stops. Ensure they are positioned correctly to prevent over-travel. For added security, consider adding a small screw directly into the track near the stop.
Door lifts off the track.	Anti-jump discs not installed or improperly adjusted; track not level.	Ensure anti-jump discs are installed on top of the door and positioned correctly to prevent the rollers from lifting off the track. Verify the track is perfectly level.
Door swings out at the bottom.	Floor guide not installed or improperly positioned.	Install or adjust the floor guide to properly engage the bottom of the door panel, keeping it stable.

SPECIFICATIONS

Detailed specifications for the SMARTSTANDARD 9ft Barn Door Hardware Kit:




Image: Detailed view of the heavy-duty raw steel rail, smooth nylon pulleys with bearings, and the maximum weight capacity of 220 lbs.

Feature	Detail
Brand	SMARTSTANDARD
Model Number	SDH00902IBK
Track Length	9 Feet (composed of 2x 4.5 FT rails)
Material	High-quality Carbon Steel (track), Nylon (rollers)
Color	Multicolor (typically black hardware)
Style	Modern

Feature	Detail
Item Weight	18.71 Pounds
Product Dimensions	1.63 x 54 x 54 inches (packaging/overall)
Door Panel Width Compatibility	Up to 54 inches
Door Panel Thickness Compatibility	1 3/8 inches to 1 3/4 inches
Door Weight Capacity	150 lbs - 220 lbs
Assembly Required	Yes

WARRANTY INFORMATION

SMARTSTANDARD is committed to providing high-quality products. For specific warranty details regarding your barn door hardware kit, please refer to the documentation included with your purchase or visit the official SMARTSTANDARD website. Warranty terms typically cover manufacturing defects and material flaws under normal use.

Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT




If you have any questions, require assistance with installation, or need to report an issue, please contact SMARTSTANDARD customer support. Our professional team is available to help you resolve any problems promptly.

- **Online Support:** Visit the official SMARTSTANDARD store on Amazon for FAQs and additional resources: [SMARTSTANDARD Amazon Store](#)
- **User Manual PDF:** A detailed user manual in PDF format is often available for download. Check the product page or the manufacturer's website.

We recommend checking the official SMARTSTANDARD website for the most up-to-date contact information and support options.

© 2025 SMARTSTANDARD. All rights reserved.

Related Documents

 <p>Bifold Barn Door Hardware Kit INSTRUCTION MANUAL</p> <p>OPERATION CAUTIONS Please refer to instruction manual for detailed information on safe use.</p>	<p>Bifold Barn Door Hardware Kit: Installation Manual</p> <p>Comprehensive installation manual for the SMARTSTANDARD Bifold Barn Door Hardware Kit, detailing hardware components, tools required, measurements, important notes, and step-by-step assembly instructions for various door sizes.</p>
 <p>Bifold Barn Door Hardware Kit INSTRUCTION MANUAL</p> <p>OPERATION CAUTIONS Please refer to instruction manual for detailed information on safe use.</p>	<p>Bifold Barn Door Hardware Kit Installation Manual</p> <p>Comprehensive installation manual for the SMARTSTANDARD Bifold Barn Door Hardware Kit, detailing parts, measurements, and step-by-step assembly instructions for various door sizes and wall types.</p>
 <p>SmartStandard Sliding Door Hardware Sliding Door Hardware Manual</p> <p>Smart Standard</p>	<p>SmartStandard Sliding Door Hardware Installation Manual</p> <p>Comprehensive guide for installing SmartStandard sliding door hardware, including measurements, tools needed, and step-by-step instructions for a secure and smooth door operation.</p>