

[manuals.plus](#) /

› [Timex](#) /

› [Timex Navi XL 41mm Analog Quartz Watch Instruction Manual](#)

Timex TW2T75500VQ

Timex Men's Navi XL 41mm Analog Quartz Watch Instruction Manual

Model: TW2T75500VQ

INTRODUCTION

This manual provides comprehensive instructions for the Timex Men's Navi XL 41mm Analog Quartz Watch, model TW2T75500VQ. Please read this guide carefully to ensure proper setup, operation, and maintenance of your timepiece. Retain this manual for future reference.



Figure 1: Front view of the Timex Navi XL 41mm Analog Quartz Watch.

GETTING STARTED

Setting the Time

- 1. Locate the Crown:** The crown is the small knob on the right side of the watch case.
- 2. Pull Out the Crown:** Gently pull the crown outwards to position 2. The watch hands will stop moving.
- 3. Adjust the Time:** Rotate the crown in either direction to move the hour and minute hands to the desired time.
- 4. Push In the Crown:** Once the time is set, push the crown back into its original position (position 1). The watch will resume operation.



Figure 2: Side view illustrating the watch crown for time adjustment.

Adjusting the Strap

The Timex Navi XL features an adjustable fabric slip-through strap. To adjust the fit:

- 1. Thread the Strap:** Pass the long end of the strap through the spring bars on the watch case, ensuring the watch face is centered.
- 2. Secure the Buckle:** Adjust the strap length by pulling it through the buckle until it fits comfortably on your wrist.
- 3. Use Keepers:** Utilize the two metal keepers to secure any excess strap length.





Figure 3: Back view demonstrating the fabric slip-through strap and buckle mechanism.

OPERATION

Indiglo Night-Light

Your Timex Navi XL watch is equipped with the Indiglo night-light feature for illumination in low-light conditions.

- **Activation:** Press and hold the crown firmly to activate the Indiglo night-light. The dial will illuminate for a few seconds.
- **Note:** Frequent use of the Indiglo feature may reduce battery life.

Water Resistance

This watch is water-resistant to 100 meters (10 ATM). This rating indicates suitability for various water activities, as detailed in the chart below. To maintain water resistance, ensure the crown is fully pushed in before any contact with water. Do not operate the crown or push buttons while the watch is wet or submerged.




Figure 4: Degree of Water Resistance for Timex Watches.

Water Resistance Guidelines

Rating	Activity	Suitability
30 Meters (3 ATM)	Rain Resistant	Withstands splashes and rain. Not suitable for submersion.
50 Meters (5 ATM)	Light Swimming	Suitable for light swimming. Not for diving.
100 Meters (10 ATM)	Snorkeling, Swimming, Poolside Diving	Suitable for snorkeling, swimming, and poolside diving. Not for high-impact water sports or scuba diving.
200 Meters (20 ATM)	Recreational Scuba Diving	Suitable for recreational scuba diving.

Note: Watches labeled water-resistant without a depth indicated can withstand splashes and rain, but should not be submerged. To maintain water resistance, do not press any buttons under water unless your watch is indicated as 200 meter water resistant.

MAINTENANCE

Battery Replacement

Your watch is powered by a Lithium Metal battery. When the watch stops running or the Indiglo light dims significantly, it indicates that the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

General Care

- Cleaning:** Clean your watch regularly with a soft, damp cloth. For fabric straps, mild soap and water can be used, but ensure the watch head is protected from excessive moisture if not rated for submersion.
- Avoid Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetic sprays, as these can damage the case, strap, or gaskets.
- Temperature Extremes:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect its accuracy and water resistance.
- Magnetic Fields:** Keep the watch away from strong magnetic fields, as they can interfere with the quartz movement.

TROUBLESHOOTING

Watch Not Running

- Check Crown Position:** Ensure the crown is fully pushed into position 1. If it is pulled out, the watch will not run.
- Battery:** If the crown is correctly positioned and the watch is still not running, the battery may need replacement. Refer to the "Battery Replacement" section.

Time Inaccurate

- Reset Time:** Re-set the time as described in the "Setting the Time" section.
- Environmental Factors:** Exposure to strong magnetic fields or extreme temperatures can affect

accuracy. Avoid such conditions.

- **Battery Level:** A low battery can sometimes cause irregular timekeeping before the watch completely stops. Consider battery replacement.

SPECIFICATIONS

Feature	Detail
Model Number	TW2T75500VQ
Case Diameter	41 mm
Case Material	Stainless Steel
Crystal Material	Mineral Glass
Movement	Analog Quartz
Strap Material	Fabric (Slip-through)
Water Resistance	100 meters (10 ATM)
Special Features	Indiglo Night-Light, Luminant Hands, Bottlecap Bezel
Battery Type	Lithium Metal (included)
Package Dimensions	4.2 x 4.1 x 3.1 inches
Item Weight	2.56 ounces
Date First Available	February 12, 2020
ASIN	B07X3TC1GV

WARRANTY AND SUPPORT

Warranty Information

Timex watches are manufactured to high-quality standards and are covered by a limited warranty against manufacturing defects. For specific warranty terms, conditions, and registration, please refer to the warranty card included with your purchase or visit the official Timex website.

Customer Support

For further assistance, product inquiries, or service requests, please visit the official Timex website or contact their customer support directly.

[Visit the Official Timex Store](#)

© 2024 Timex. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - TW2T75500VQ

	<p><u>Timex Analog Watch User Manual - Features, Settings, and Care</u></p> <p>Comprehensive user guide for Timex Analog watches, covering setup, features like INDIGLO® Night-Light, water resistance, alarms, perpetual calendar, and maintenance. Available in multiple languages.</p>
	<p><u>Timex Analog Watch User Manual</u></p> <p>This comprehensive user manual provides detailed instructions for operating and maintaining your Timex Analog watch. It covers setup, feature usage including INDIGLO® night-light and alarms, water resistance guidelines, bracelet adjustment, and warranty details.</p>
	<p><u>Timex Watch User Manual - Instructions and Guides</u></p> <p>Comprehensive user manual for Timex watches, providing detailed instructions, setup guides, and troubleshooting tips in multiple languages. Learn how to operate your Timex timepiece effectively.</p>
	<p><u>Timex Combination Watch User Manual and Instructions</u></p> <p>Comprehensive user manual for the Timex Combination Analog/Digital Watch, detailing features like INDIGLO night-light, various time modes, chronograph, countdown timer, second time zone, water resistance, and warranty information.</p>
	<p><u>Timex Atelier Marine M1a User Manual and International Warranty</u></p> <p>Comprehensive user manual and international warranty details for the Timex Atelier Marine M1a watch. Includes product specifications, instructions for setting the time and adjusting the bracelet, and warranty coverage information.</p>
	<p><u>Timex W217 Analog Watch User Manual and Operating Instructions</u></p> <p>Comprehensive user manual for the Timex W217 Analog watch, covering setup, water resistance, Indiglo night-light, and detailed instructions for setting time, date, day, moon phase, and alarms.</p>