

- Manuals.plus /
- › IRONCK /
- › IRONCK Industrial Coffee Table (Model B07X4DR2S3) Assembly and Care Manual

IRONCK B07X4DR2S3

IRONCK Industrial Coffee Table (Model B07X4DR2S3) Assembly and Care Manual

1. PRODUCT OVERVIEW

The IRONCK Industrial Coffee Table is designed to enhance your living space with its robust industrial aesthetic. Featuring a durable wood-look top, a convenient lower storage shelf, and a distinctive rivet design, this dark brown accent furniture piece combines functionality with style. It is ideal for organizing living room essentials while providing a sturdy surface for beverages and decor.



Image 1: The IRONCK Industrial Coffee Table in a living room, showcasing its design and functionality.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand or sit on the coffee table.
- Place the table on a flat, stable surface to prevent tipping.
- Avoid placing excessively hot or cold items directly on the surface without protective coasters.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact

customer support.

- Top Panel (A)
- Bottom Shelf Panel (B)
- Side Frame (C) x 2
- Connecting Rods (D) x 4
- Legs (E) x 4
- Screws (F) and Allen Wrench (G)
- Adjustable Foot Pads (pre-attached or separate)

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes 15-20 minutes. Follow these steps carefully for proper construction.

Step 1: Assemble the Bottom Shelf Frame

Attach the two Side Frames (C) to the Bottom Shelf Panel (B) using the appropriate screws (F). Ensure the rivet design elements are facing outwards if applicable. Do not fully tighten screws yet.



Image 2: Detail of the metal frame for the bottom storage shelf.

Step 2: Attach Connecting Rods to Top Panel

Secure the four Connecting Rods (D) to the underside of the Top Panel (A) using screws (F). These rods will connect the top panel to the legs.

Step 3: Connect Legs to Top Panel and Bottom Shelf

Important Assembly Tip: The provided instructions may suggest attaching the legs to the top panel first, then trying to fit the bottom shelf. For easier assembly, it is recommended to attach the legs (E) to the connecting rods (D) on the Top Panel (A) and then carefully align and attach the bottom shelf frame (from Step 1) to the lower part of the legs. This ensures a smoother fit for the bottom shelf.

Secure the Legs (E) to the Connecting Rods (D) and the Bottom Shelf Frame using screws (F). Ensure all connections are firm.



Image 3: View of the table's structure, highlighting the leg and shelf connections.

Step 4: Final Tightening

Once all components are in place, fully tighten all screws using the provided Allen Wrench (G). Do not overtighten. Ensure the table is stable and level. Adjust the foot pads if necessary to prevent wobbling.



Image 4: Close-up of a table leg, showing the rivet design and sturdy construction.

5. USAGE

This coffee table is designed for indoor use in living rooms or similar spaces. The top surface can be used for drinks,

books, remote controls, and decorative items. The lower shelf provides additional storage for magazines, small boxes, or other items, helping to keep your living area tidy.

6. MAINTENANCE

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on the wood-look surface.
- **Protection:** Use coasters under drinks and placemats under hot dishes to protect the surface from heat and moisture rings.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Relocation:** When moving the table, lift it rather than dragging it to prevent damage to the legs and floor.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Table is wobbly	Uneven floor; loose screws; uneven leg assembly.	Ensure all screws are tightened. Adjust the foot pads on the bottom of the legs to level the table. Check that legs are installed correctly.
Parts do not fit during assembly	Incorrect orientation of parts; screws not aligned; assembly order issue.	Review the assembly steps, especially the tip regarding the bottom shelf. Ensure parts are oriented as shown in diagrams. Loosen all screws slightly, adjust parts, then re-tighten.
Surface damage (scratches, water rings)	Lack of protective measures; sharp objects; prolonged moisture exposure.	Use coasters and placemats. Avoid dragging objects across the surface. Clean spills immediately. Minor scratches may be touched up with furniture repair markers.

8. SPECIFICATIONS

Feature	Detail
Brand	IRONCK
Model Number (ASIN)	B07X4DR2S3
GTIN / UPC	798825011157
Style Name	Industrial
Table Design	Coffee Table
Shape	Rectangular
Color	Dark Brown
Top Material Type	Wood (Wood Look Accent Furniture)

Feature	Detail
Frame Material	Metal Frame with Wood-Look Panels
Required Assembly	Yes
Base Type	Leg
Dimensions (Approximate)	41.7" L x 23.6" W x 17.7" H (106cm L x 60cm W x 45cm H)

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact IRONCK customer service directly through their official website or the retailer where the product was purchased. Please have your model number (B07X4DR2S3) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07X4DR2S3>

More documents and user manuals: <https://manuals.plus/>