

[Manuals.plus](#) /

› [Arteck](#) /

› Arteck 2.4G Nano USB Receiver Instruction Manual for Wireless Keyboard and Mouse (Model AUSB1)

Arteck AUSB1

Arteck 2.4G Nano USB Receiver Instruction Manual

Model: AUSB1

INTRODUCTION

This manual provides comprehensive instructions for setting up and using your Arteck 2.4G Nano USB Receiver. This receiver is designed to establish a wireless connection between compatible Arteck 2.4G wireless keyboards and mice and your computer.




Image: Front view of the Artek 2.4G Nano USB Receiver.

COMPATIBILITY

The Artek 2.4G Nano USB Receiver is specifically designed for use with Artek 2.4G wireless keyboards and mice. It is not compatible with products from other brands.

Important Compatibility Exclusions: This receiver is **not** suitable for the following Artek models or types:

- Artek GW28-3
- Artek HD323
- Artek K730
- Artek HW197

- Artek HD197
- Artek MD167
- Artek MD172
- Any Artek Bluetooth keyboard or mouse

Ensure your Artek device is a 2.4G wireless model compatible with this specific receiver (AUSB1).

SETUP AND PAIRING INSTRUCTIONS

The USB receiver does not automatically pair with your keyboard or mouse. Manual pairing is required for initial setup or if the connection is lost.

Pairing Method

The USB receiver cannot pair to the keyboard or mouse directly. You need to pair the USB receiver to the keyboard or the mouse manually.

For Artek keyboard:

1. Unplug the USB receiver.
2. Switch the keyboard to be on and press the Esc+k, the indicator is blinking.
3. Move the keyboard close to the USB port and insert the USB receiver.

For Artek mouse:

1. Unplug the USB receiver.
2. Switch the mouse to be off, press the wheel and the right button at the same time and hold.
3. Switch the mouse to be on and after that release the buttons. The mouse is in pairing mode and the indicator is blinking.
4. Move the mouse close to the USB port and insert the USB receiver.

If you still have problem with that, please send mail to the email address printed on the package and you will get prompt solution.

Note: The USB receiver is not suitable for other brands. This USB receiver is not working with Artek HW197, HD197, MD167 or any bluetooth keyboards or mice.

Image: Visual guide for the pairing process of Artek keyboards and mice with the USB receiver.

For Artek Keyboard Pairing:

1. **Unplug the USB Receiver:** Ensure the USB receiver is not currently plugged into your computer's USB port.
2. **Activate Pairing Mode on Keyboard:** Switch the keyboard to the "ON" position. Simultaneously press and hold the **Esc** key and the **K** key. The indicator light on the keyboard will begin blinking, indicating it is in pairing mode.
3. **Insert USB Receiver:** While the keyboard indicator is blinking, move the keyboard close to a USB port on your computer (within 5 cm is recommended). Insert the USB receiver into the USB port.

4. **Confirm Connection:** The keyboard's indicator light should blink three times and then turn off, signifying a successful connection. If the connection fails, unplug and re-insert the USB receiver a few times while the keyboard indicator is blinking.
- For Artek Mouse Pairing:**
1. **Unplug the USB Receiver:** Ensure the USB receiver is not currently plugged into your computer's USB port.
 2. **Prepare Mouse for Pairing:** Switch the mouse to the "OFF" position. Press and hold both the **right-click button** and the **scroll wheel** simultaneously.
 3. **Activate Pairing Mode on Mouse:** While still holding the right-click button and scroll wheel, switch the mouse to the "ON" position. After approximately 2 seconds, release the buttons. The indicator light on the mouse will begin blinking, indicating it is in pairing mode.
 4. **Insert USB Receiver:** While the mouse indicator is blinking, move the mouse close to a USB port on your computer. Quickly insert the USB receiver into the USB port.
 5. **Confirm Connection:** The mouse's indicator light should blink three times and then turn off, signifying a successful connection.

Note: It is recommended to pair the keyboard first, then unplug the receiver, and then pair the mouse.

OPERATING INSTRUCTIONS

Once successfully paired, the Artek 2.4G Nano USB Receiver operates automatically. Simply plug the receiver into an available USB port on your computer, and your paired Artek wireless keyboard and mouse should function without further setup.

For optimal performance, ensure the receiver is not obstructed and is within a reasonable range of your wireless devices.

TROUBLESHOOTING

- **Device Not Responding:** If your keyboard or mouse is not responding, try re-pairing the device using the instructions in the "Setup and Pairing Instructions" section.
- **Intermittent Connection:** Ensure the USB receiver is plugged directly into a USB port on your computer, not a USB hub or extender, which can sometimes cause interference. Also, check for any large metal objects or other wireless devices that might be causing interference.
- **Incorrect Device Paired:** Verify that you are using the correct Artek 2.4G Nano USB Receiver (Model AUSB1) for your specific Artek wireless keyboard or mouse. Refer to the "Compatibility" section for exclusions.
- **Still Having Issues?** If you encounter persistent problems connecting your Artek keyboard or mouse, please contact Artek customer support for assistance. They can provide further guidance on manual pairing or other troubleshooting steps.

SPECIFICATIONS

Model Number	AUSB1
Brand	Artek

Compatible Devices	Arteck 2.4G Wireless Keyboard, Arteck 2.4G Wireless Mouse
Connector Type	USB Type A
Color	Black
Item Weight	0.317 ounces (approx. 9 grams)
Package Dimensions	3.15 x 2.48 x 0.75 inches



Image: Side view of the Arteck 2.4G Nano USB Receiver, showing its compact size.

SUPPORT

For further assistance, technical support, or if you have any questions regarding your Arteck 2.4G Nano USB Receiver, please contact Arteck customer support. Refer to the contact information provided with your product packaging or visit the official Arteck website for support details.

Note: There is no explicit warranty information provided in the product details. Please refer to your purchase documentation or contact Arteck support for warranty specifics.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question