Ariete 1313

Ariete 1313 Espresso Machine User Manual

Model: 1313 | Brand: Ariete

1. Introduction

Welcome to the world of premium coffee with your new Ariete 1313 Espresso Machine. This semi-automatic coffee maker is designed to bring the authentic taste of Italian espresso, cappuccino, and other coffee beverages directly to your home. Featuring a 15-bar pressure system, an integrated coffee grinder, and a versatile milk frother, this machine allows you to enjoy fresh, aromatic coffee from bean to cup. Please read this manual carefully before first use to ensure proper operation, maintenance, and safety.



The Ariete 1313 Espresso Machine ready to brew delicious coffee in a home setting.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Package Contents

Upon unpacking your Ariete 1313 Espresso Machine, please ensure all the following components are present:

- Ariete 1313 Espresso Machine Unit
- Portafilter with Handle
- Single Shot Filter Basket
- Double Shot Filter Basket
- ESE Pod Filter Basket
- Coffee Scoop / Tamper
- Stainless Steel Milk Frothing Jug
- Instruction Manual (this document)



Overview of the included accessories: portafilter, filter baskets, scoop/tamper, and milk jug.

4. Setup

1. **Unpacking:** Carefully remove all packaging materials and place the machine on a stable, flat, and heat-resistant surface. Ensure adequate ventilation around the machine.
2. **Water Tank:** Remove the water tank from the back of the machine. Rinse it thoroughly with fresh water and fill it to the MAX level with cold, fresh water. Reinsert the tank firmly into its position.



The removable water tank located at the back of the machine.

3. **Coffee Bean Hopper:** Open the lid of the coffee bean hopper located on top of the machine and fill it with your desired whole coffee beans. Close the lid securely.



Fresh coffee beans loaded into the integrated grinder hopper.

4. **Initial Rinse:** Before first use, perform an initial rinse cycle without coffee. This primes the system and cleans any manufacturing residues. Refer to the 'Operating Instructions' section for details on running a brew cycle.

5. Operating Instructions

5.1. Grinding Coffee

The Ariete 1313 features an integrated grinder. Adjust the grind setting according to your preference. A finer grind is typically used for espresso, while coarser grinds are suitable for other brewing methods. The machine offers 11 grind settings.

5.2. Preparing Espresso

1. Select the appropriate filter basket (single or double shot) and place it into the portafilter.
2. Place the portafilter under the grinder outlet and activate the grinding function to fill the basket with freshly ground coffee.

3. Tamp the ground coffee firmly and evenly using the provided tamper. Wipe any excess coffee from the rim of the portafilter.
4. Insert the portafilter into the group head of the machine and lock it into place by turning the handle to the right.



Proper insertion of the portafilter into the group head.

5. Place your espresso cup(s) on the drip tray directly under the portafilter spouts.

6. Press the desired espresso button (single or double) to start brewing. The machine will automatically stop when the cycle is complete.

5.3. Using the Maxi Cappuccino Device (Steam Wand)

The Maxi Cappuccino device allows you to froth milk for cappuccinos and lattes, or dispense hot water for teas and infusions.

1. Fill the stainless steel milk jug with cold milk (dairy or non-dairy).
2. Turn the steam knob to activate the steam function. Wait for the machine to reach optimal steam temperature (indicated by the pressure gauge).
3. Submerge the steam wand tip just below the surface of the milk. Open the steam valve slowly to begin frothing. Move the jug up and down to incorporate air and create a creamy foam.



A perfectly frothed milk beverage prepared using the Maxi Cappuccino device.

4. Once desired foam consistency and temperature are reached, close the steam valve and remove the jug.

Immediately wipe the steam wand with a damp cloth to prevent milk residue from drying.

5. For hot water, place a cup under the steam wand and open the steam valve.

6. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Ariete 1313 Espresso Machine.

- **Drip Tray:** The drip tray should be emptied and cleaned daily or when the indicator floats up. Remove the tray, discard the water, and wash with warm, soapy water.



The removable drip tray for easy cleaning.

- **Portafilter and Filter Baskets:** After each use, remove the spent coffee grounds and rinse the portafilter and filter baskets under hot water. Periodically, use a small brush to clean the filter basket holes.
- **Steam Wand:** After each use, purge the steam wand briefly and wipe it clean with a damp cloth to prevent milk residue buildup.
- **Descaling:** Depending on water hardness and frequency of use, the machine will require descaling. Follow the instructions provided with a suitable descaling solution for espresso machines. This typically involves running the descaling solution through the machine's water system.
- **Exterior Cleaning:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or immerse the machine in water.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No coffee dispenses	Water tank empty; Clogged filter; Machine not primed.	Fill water tank; Clean filter; Run initial rinse cycle.
Coffee brews too slowly or drips	Coffee ground too fine; Too much coffee in filter; Machine needs descaling.	Adjust grind coarser; Use less coffee; Perform descaling.
Coffee brews too quickly	Coffee ground too coarse; Not enough coffee; Insufficient tamping.	Adjust grind finer; Use more coffee; Tamp more firmly.
No steam from wand	Steam wand clogged; Machine not at steam temperature.	Clean steam wand; Wait for machine to heat up.
Machine leaks water	Water tank not seated correctly; Drip tray full; Seal issues.	Reseat water tank; Empty drip tray; Contact customer support if persistent.

8. Specifications

Feature	Specification
Brand	Ariete
Model Number	1313
Colour	Silver
Product Dimensions	11D x 12W x 15.6H Centimeters
Special Features	Removable Tank, Milk Frother, Jug
Coffee Maker Type	Espresso Machine
Filter Type	Reusable
Operation Mode	Semi-Automatic
Coffee Input Type	Whole Bean
Item Weight	7 kg 630 g
Country of Origin	Italy



Visual representation of the machine's dimensions.

9. Warranty and Support

Your Ariete 1313 Espresso Machine comes with a 2-Year Warranty, as stated in the product description. For warranty claims, technical support, or any inquiries regarding your product, please contact the official brand distributor or the seller from whom you purchased the machine.
Official Brand Distributor: Silveor Lifestyle India LLP
Address: Plot-82 Patparganj Industrial Area, Patparganj Delhi-110092
Contact: +91-88823-06988
Email: Marketing@silveorindia.com
Extended warranty plans may also be available for purchase:

- 1 Year Extended Warranty
- 2 Year Extended Warranty
- 1 Year Fire Protection Plan

Please refer to your purchase documentation for specific terms and conditions of your warranty and any extended plans.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question