

[manuals.plus](#) /› [LEVO](#) /› [LEVO G2 V16 Rolling Laptop Workstation Stand User Manual](#)

## LEVO G2 V16

# LEVO G2 V16 Rolling Laptop Workstation Stand User Manual

Model: 33742

Brand: LEVO

## 1. INTRODUCTION

This manual provides essential instructions for the safe and efficient assembly, operation, and maintenance of your LEVO G2 V16 Rolling Laptop Workstation Stand. Please read this manual thoroughly before using the product and retain it for future reference.

## 2. SAFETY INFORMATION

To ensure safe operation, please observe the following:

- Do not exceed the maximum weight capacity of 7 lbs (3.17 kg) on the desktop.
- Ensure all quick lock height adjustments are securely fastened before use.
- Use the safety bungee for steep desktop angles to prevent devices from sliding.
- Always lock the casters when the stand is in a stationary position to prevent accidental movement.
- Keep hands clear of moving parts during adjustment.
- Avoid placing hot items directly on the desktop surface without protection.

## 3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Main vertical pole with base and casters
- Desktop platform with adjustable height rests
- Swing arm assembly
- Mouse tray
- Phone holder
- Safety bungee
- Assembly hardware and tools (if applicable)

- Instruction manual

## 4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your LEVO G2 V16 workstation stand. For visual guidance, refer to the official assembly video.

### 4.1. Base and Pole Assembly


1. Attach the vertical pole to the wheeled base. Ensure it is securely tightened.
2. Verify that the casters are properly installed and can roll smoothly.



*Image: Fully assembled LEVO G2 V16 Laptop Stand positioned next to a recliner.*

### 4.2. Attaching the Swing Arm and Desktop


1. Slide the swing arm onto the vertical pole.
2. Attach the desktop platform to the end of the swing arm.
3. Secure all connections using the provided hardware.



*Image: Close-up view of the workstation desktop, highlighting the mouse tray and phone holder attachment points.*

#### **4.3. Installing Mouse Tray and Phone Holder**

1. The mouse tray can be installed on either the left or right side of the desktop. Slide it into the designated slot until secure.
2. Attach the phone holder to the side of the desktop. Adjust its position for optimal viewing.



## SIT OR STAND - SECURELY

Quick lever height locks can quickly go from sitting to standing - holding everything in place

*Image: The LEVO G2 V16 workstation with the mouse tray positioned on the left side and the phone holder attached, demonstrating flexibility for left- or right-handed users.*

### 4.4. Official Assembly Video

For a detailed visual guide on assembly and features, please watch the official LEVO V16 Laptop Stand Demonstration Video:

Your browser does not support the video tag.

*Video: Official LEVO V16 Laptop Stand Demonstration Video. This video provides a comprehensive overview of the product's assembly and various features, including adjustments and usage scenarios.*

## 5. OPERATING INSTRUCTIONS

### 5.1. Height Adjustment

The stand features quick-lock height adjustments, allowing you to easily transition between sitting and standing positions. The height can be adjusted from 22 inches (558 mm) to 45 inches (1143 mm).

1. Loosen the quick-lock levers on the vertical pole.
2. Adjust the pole to your desired height.
3. Securely tighten the quick-lock levers to prevent slippage.



## PRECISE ADJUSTMENTS

The swing arm rotates within the “V” shaped base - simply roll the stand away to exit/stand up

*Image: The LEVO G2 V16 stand demonstrating its quick lever height locks, allowing for easy adjustment between sitting and standing positions.*

### 5.2. Desktop Tilt and Rotation

The desktop platform offers a tilt range of 0 to 70 degrees and a 70-degree rotation, providing optimal viewing angles for various activities.


- To adjust the tilt, loosen the tilt mechanism knob, set the desired angle, and re-tighten.
- The swing arm allows the desktop to rotate 70 degrees, enabling you to position your device directly over your lap while sitting comfortably.



*Image: An overhead view illustrating the 70-degree rotation capability of the swing arm, allowing the desktop to be positioned over a user's lap.*

### 5.3. Using Adjustable Height Rests and Safety Bungee

The desktop includes four independently moving rests to securely hold laptops, tablets, books, or sheet music. For steep angles, use the safety bungee to prevent items from sliding off.



Tablets



Sketchbooks



Sheet Music



## ADJUSTABLE HEIGHT RESTS

Four rests move independently to hold tablets, books and more

*Image: The desktop platform with adjustable height rests configured to hold a tablet, sketchbook, and sheet music, demonstrating versatility.*

### 5.4. Mobility and Stability

The heavy-duty frame and wide base with smooth-rolling casters allow for easy movement between rooms. Lock the casters when the stand is in position to ensure stability.

# SPECIFICATIONS

LEVO 33742



*Image: The LEVO G2 V16 stand being rolled across a room, highlighting its mobility.*

## 6. MAINTENANCE

- Cleaning:** Wipe down the stand with a soft, damp cloth. Avoid abrasive cleaners.
- Inspections:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary.
- Casters:** Keep casters free of debris to maintain smooth rolling.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand wobbles or is unstable.	Loose connections; uneven surface.	Ensure all assembly screws and quick-lock levers are securely tightened. Move to a flat, stable surface.
Desktop slides down after adjustment.	Quick-lock levers not fully tightened.	Firmly tighten all quick-lock levers after adjusting height or tilt.

Problem	Possible Cause	Solution
Device slides off desktop at steep angles.	Safety bungee not used or improperly secured.	Utilize the provided safety bungee to secure your device when using steep desktop angles. Ensure adjustable rests are properly positioned.
Casters do not roll smoothly.	Debris in casters; casters locked.	Check casters for hair or debris and clean if necessary. Ensure casters are unlocked for movement.

## 8. SPECIFICATIONS

**Product Dimensions:** 13 x 13 x 45 inches (330 x 330 x 1143 mm)

**Item Weight:** 17 pounds (7.7 kg)

**Model Number:** 33742

**Brand:** LEVO

**Form Factor:** Laptop Stand

**Compatible Devices:** Laptops, Tablets, Smartphones

**Mounting Type:** Phone Mount, Wheel Mount, Tabletop

**Min Height:** 22 inches (558 mm)

**Max Height:** 45 inches (1143 mm)

**Max Extension to Center of Device:** 15 inches (381 mm)

**Platform Size:** 16.5 x 11.25 inches (419 x 286 mm)

**Mouse Tray Size:** 7.25 x 8 inches (185 x 203 mm)

**Stand Clearance:** 3.75 inches (95 mm)

# SPECIFICATIONS

LEVO 33742



*Image: A diagram illustrating key dimensions and specifications of the LEVO G2 V16 Laptop Workstation Stand.*

## 9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official LEVO website or contact LEVO customer service. Refer to your purchase documentation for specific warranty terms and conditions.

You can also visit the [LEVO Store on Amazon](#) for additional product information and support.