

[Manuals.plus](#) /

› [GROHE](#) /

› GROHE Zedra 33893002 Single-Handle Pull-Out Kitchen Faucet Instruction Manual

GROHE 33893002

GROHE Zedra 33893002 Single-Handle Pull-Out Kitchen Faucet

Instruction Manual

1. PRODUCT OVERVIEW

The GROHE Zedra 33893002 is a single-handle pull-out kitchen faucet designed for modern kitchens. It features a dual-function spray head, allowing users to switch between a regular stream and a powerful shower spray. The faucet incorporates GROHE's advanced technologies for durability and user comfort.





Image 1.1: The GROHE Zedra 33893002 kitchen faucet, showcasing its sleek design and chrome finish.

Key Features:

- **Dual-Function Spray Head:** Easily switch between a regular stream and a shower spray for various tasks.
- **Forward Rotating Lever:** Designed to prevent interference with backsplashes during operation.
- **GROHE SilkMove Technology:** Ensures smooth and precise control of water temperature and volume.
- **GROHE StarLight Finish:** Provides a durable, lustrous chrome surface that resists scratches and tarnishing.
- **Speed Clean Nozzles:** Silicone nozzles that can be wiped clean with a fingertip to remove limescale buildup.
- **360° Swivel Spout:** Offers maximum flexibility and coverage for your sink area.
- **Ceramic Disc Valve:** Guarantees reliable, drip-free performance over time.



Dual Spray with Toggle

Easily switches from regular flow to high-performance spray



Forward Rotating Handle

Prevents interference with the backsplash



Speed Clean

Wipe away limescale on nozzles with your fingertip



GROHE StarLight

Durable coating wipes clean, maintains finish for life



GROHE SilkMove

Smooth, effortless handle operation



Image 1.2: Visual representation of the GROHE Zedra faucet's key technologies and design elements.



Image 1.3: The GROHE Zedra faucet integrated into a kitchen environment.

2. INSTALLATION (SETUP)

This section provides general guidelines for installing the GROHE Zedra 33893002 kitchen faucet. For detailed, step-by-step instructions, please refer to the dedicated installation guide included with your product packaging. Professional installation is recommended.

2.1. Before You Begin:

- Ensure all necessary tools and components are available.
- Turn off the main water supply to your kitchen.
- Clear the area under the sink for easy access.

2.2. General Installation Steps:

1. **Remove Old Faucet:** Disconnect water lines and mounting hardware from the existing faucet.

2. **Prepare Mounting Surface:** Ensure the sink hole is clean and free of debris.
3. **Install Faucet Body:** Insert the faucet body into the mounting hole. Secure it from underneath the sink using the provided mounting hardware.
4. **Connect Water Supply Lines:** Attach the hot and cold water supply lines to the corresponding connections on the faucet and your home's water supply. Ensure connections are tight to prevent leaks.
5. **Connect Pull-Out Hose and Weight:** Attach the pull-out spray hose to the faucet's connection point. Install the counterweight onto the hose at the recommended position to ensure smooth retraction.
6. **Test for Leaks:** Slowly turn on the main water supply and check all connections for any signs of leakage. Operate the faucet to ensure proper water flow and spray function.

Installation Tip: When securing the faucet from underneath the sink, ensure the washer is correctly positioned with the large nut. Incorrect placement of washers can prevent proper tightening and lead to instability.

3. OPERATING INSTRUCTIONS

The GROHE Zedra 33893002 faucet is designed for intuitive and efficient operation.

3.1. Water Flow and Temperature Control:

- **Turn On/Off:** Lift the single handle to turn on the water. Push it down to turn off.
- **Adjust Water Volume:** The height to which the handle is lifted controls the water flow volume.
- **Adjust Water Temperature:** Move the handle left for hot water and right for cold water. The forward-rotating design ensures the handle does not interfere with the backsplash.

3.2. Using the Pull-Out Spray Head:

- **Extend Spray Head:** Gently pull the spray head from the spout to extend the hose.
- **Switch Spray Patterns:** Press the button located on the spray head to toggle between the regular aerated stream and the powerful shower spray.
- **Retract Spray Head:** Once finished, guide the spray head back into the spout. The counterweight on the hose will assist in smooth retraction.



Image 3.1: Demonstrating the pull-out spray function for rinsing items in the sink.

3.3. Swivel Function:

The faucet spout can swivel 360 degrees, allowing you to direct water flow across the entire sink area or to adjacent basins. Gently push the spout to the desired position.

4. MAINTENANCE

Regular cleaning and maintenance will preserve the appearance and functionality of your GROHE Zedra faucet.

4.1. Cleaning the Finish:

- Clean the GROHE StarLight chrome finish with a soft cloth and a mild soap solution.
- Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- Avoid using abrasive cleaners, scouring pads, ammonia-based cleaners, or cleaners containing bleach, as these can damage the finish.

4.2. Cleaning Speed Clean Nozzles:

The silicone Speed Clean nozzles are designed for easy limescale removal. Simply wipe the nozzles with your fingertip to dislodge any mineral buildup and restore optimal spray performance.

5. TROUBLESHOOTING

If you encounter any issues with your GROHE Zedra faucet, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Low Water Flow	◦ Aerator/nozzles clogged with limescale or debris. ◦ Partially closed shut-off valves.	◦ Wipe Speed Clean nozzles with fingertip. For aerator, unscrew and clean. ◦ Ensure hot and cold water shut-off valves are fully open.
Faucet Drips	◦ Debris in ceramic disc valve. ◦ Worn out valve cartridge.	◦ Flush water lines. If problem persists, the cartridge may need inspection or replacement. Contact customer support.
Leaks at Connections	◦ Loose connections. ◦ Damaged O-rings or seals.	◦ Carefully tighten connections. Do not overtighten. ◦ Inspect and replace any damaged O-rings or seals.
Pull-Out Spray Head Does Not Retract Smoothly	◦ Counterweight improperly positioned or obstructed. ◦ Hose kinked or obstructed under the sink.	◦ Check the position of the counterweight and ensure it moves freely. ◦ Inspect the hose for kinks or obstructions and clear them.

If troubleshooting steps do not resolve the issue, please contact GROHE customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	GROHE
Model Name	GROHE Zedra
Part Number	33893002
Material	Stainless Steel / Metal
Finish Type	Polished Chrome (GROHE StarLight)
Color	Chrome
Number of Handles	1 (Single-Handle)
Mounting Type	Deck Mount

Feature	Detail
Installation Type	Deck Mounted
Hole Count	1
Maximum Flow Rate	1.75 Gallons Per Minute (GPM)
Faucet Height	14 15/16 Inches (380 mm)
Spout Reach	8 1/16 Inches (205 mm)
Clearance	13 11/16 Inches (347 mm)
Hose Length	33.43 Inches
Product Dimensions (D x W x H)	8.06" x 6.31" x 14.93"
Item Weight	5.4 Pounds
Special Features	360 Swivel, Dual Function Sprayer, Pull Out Sprayer
Certifications	ADA, CALGreen Compliant, CEC Certified



Image 6.1: Dimensional drawing of the GROHE Zedra faucet.

7. WARRANTY AND SUPPORT

7.1. Warranty Information:

The GROHE Zedra 33893002 faucet is backed by a **Lifetime Limited Warranty**. This warranty covers manufacturing defects and ensures the product's quality and durability under normal use. For specific terms and conditions of the warranty, please refer to the warranty documentation included with your purchase or visit the official GROHE website.

7.2. Customer Support:

For technical assistance, replacement parts, or warranty claims, please contact GROHE customer support.

- **Online Support:** Visit the official GROHE website for FAQs, product registration, and contact forms.
- **Telephone Support:** Refer to your product packaging or the GROHE website for regional contact numbers.

When contacting support, please have your product model number (33893002) and date of purchase available.

