

Vornado Pivot Heat

Vornado Pivot Heat Electric Space Heater User Manual

Model: Pivot Heat

1. INTRODUCTION

The Vornado Pivot Heat Electric Space Heater is designed to provide efficient and comfortable warmth for your home or office. Standing 10-inches tall, this heater features advanced safety mechanisms, two heat settings, an adjustable thermostat, and a 20-degree adjustable axis to direct airflow. Its innovative Vortex Heat Circulation ensures consistent warmth throughout the room.



Figure 1: Vornado Pivot Heat Electric Space Heater

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this heater. Failure to follow these instructions may result in fire, electric shock, or injury.

- **Cool-Touch Exterior:** The heater's exterior remains cool to the touch during operation, reducing the risk of accidental burns.
- **Automatic Shut-Off:** The unit is equipped with automatic shut-off protection if it is tipped over or if internal overheating is detected.
- **Placement:** Always place the heater on a stable, level surface. Do not use on soft surfaces like beds or rugs where openings may become blocked.
- **Clearance:** Maintain at least 3 feet (0.9 meters) of clearance from combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains.
- **Power Cord:** Do not run the power cord under carpeting or cover with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas where it will not be tripped over.
- **Moisture:** Do not use the heater in wet or moist locations, such as bathrooms or laundry areas.
- **Supervision:** Close supervision is necessary when any heater is used by or near children or invalids,

and whenever the heater is left operating and unattended.

Advanced safety features for peace of mind.



Figure 2: Advanced Safety Features

3. PACKAGE CONTENTS

Upon unpacking, please ensure the following items are included:

- Vornado Pivot Heat Electric Space Heater
- Owner's Guide

4. SETUP

Setting up your Vornado Pivot Heat heater is quick and easy:

1. **Unpack:** Carefully remove the heater from its packaging.
2. **Placement:** Place the heater on a firm, level surface in the desired location. Ensure it is at least 3 feet away from walls, furniture, and other objects.
3. **Power Connection:** Plug the power cord directly into a standard 120V AC wall outlet. Do not use extension cords or power strips.

5. OPERATING INSTRUCTIONS

Your Pivot Heat heater offers intuitive controls for personalized comfort.

5.1 Power On/Off

Locate the power button on the control panel. Press once to turn the unit on, and press again to turn it off.

5.2 Heat Settings

The heater features two heat settings: Low (750W) and High (1500W). Use the heat setting selector to choose your preferred output.

5.3 Adjustable Thermostat

Set your desired room temperature using the adjustable thermostat dial. The heater will automatically cycle on and off to maintain the set temperature.




Figure 3: Adjustable Thermostat and Heat Settings

5.4 Adjustable Tilt

The Pivot Heat features a 20-degree adjustable axis, allowing you to direct the warm airflow precisely where it's needed. Gently tilt the heater head to adjust the angle.




Figure 4: 20-Degree Adjustable Tilt

5.5 Whole-Room Heat Circulation

Utilizing Vornado's signature Vortex Heat Circulation, the heater distributes warmth evenly throughout the entire room, eliminating cold spots.

Circulate gentle heat throughout the room.

Heat differently with gentle vortex heat for small to medium-sized rooms without the use of intense heat.




Figure 5: Vortex Heat Circulation

5.6 Official Product Videos

Vornado Pivot Heat Electric Space Heater Overview

Your browser does not support the video tag.

This video provides a detailed overview of the Vornado Pivot Heat Electric Space Heater, highlighting its design and features.

Vornado Pivot Heat Electric Space Heater Review

Your browser does not support the video tag.

A review of the Vornado Pivot Heat Electric Space Heater, demonstrating its functionality and user experience.

Vornado Portable Heater Review

Your browser does not support the video tag.

This video reviews the portability and heating capabilities of the Vornado Pivot Heat heater.

GREAT Heater - Strong and QUIET

Your browser does not support the video tag.

A video highlighting the powerful yet quiet operation of the Vornado Pivot Heat Electric Space Heater.

6. MAINTENANCE

Proper care ensures the longevity and optimal performance of your heater.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to cover it to protect against dust.
- **Air Intake/Outlet:** Keep the air intake and outlet grilles free from dust and debris. Use a vacuum cleaner with a brush attachment to clean these areas regularly.

7. TROUBLESHOOTING

If your Vornado Pivot Heat heater is not operating as expected, consult the following common issues and solutions:

- **Heater not turning on:** Ensure the power cord is securely plugged into a working outlet. Check if the unit has been tipped over, activating the safety shut-off. Reset by placing it upright.
- **No heat output:** Verify that the thermostat is set to a temperature higher than the current room temperature. Ensure the heat setting (Low/High) is selected.
- **Unit shuts off unexpectedly:** This may indicate activation of the overheat protection. Unplug the unit, allow it to cool for 30 minutes, and clear any obstructions from the air intake/outlet.
- **Reduced airflow:** Check for dust or debris blocking the air intake or outlet grilles. Clean as per maintenance instructions.

8. SPECIFICATIONS

Brand	Vornado
Model Number	Pivot Heat
Color	White
Heat Output	1500 Watts
Voltage	120 Volts
Amperage	12.5 Amps
Number of Speeds	2
Product Dimensions	9.2"D x 8.2"W x 9.4"H
Item Weight	4.84 pounds

Special Features	Adjustable Temperature, Adjustable Tilt Head, Cool Touch Exterior, Overheat Protection, Tip-Over Protection
Heating Coverage	Whole Room
Indoor/Outdoor Usage	Indoor
UPC	043765011942

9. WARRANTY AND SUPPORT

The Vornado Pivot Heat Electric Space Heater comes with a **5-year manufacturer's warranty**. Vornado stands by its products and offers superior support. If your product does not meet your expectations, it will be replaced within the warranty period.









**5
YEAR**
SATISFACTION
GUARANTEE

Satisfaction guaranteed.
Backed by a 5 year warranty for peace of mind.

Figure 6: 5-Year Satisfaction Guarantee

For customer support, please refer to the contact information provided in your Owner's Guide or visit the official Vornado website.

Related Documents - Pivot Heat

	<p>Vornado Pivot Heat Whole Room Heater Owner's Guide and Safety Instructions</p> <p>Comprehensive owner's guide for the Vornado Pivot Heat Whole Room Heater. Includes detailed safety warnings, operating instructions, cleaning and storage tips, troubleshooting solutions, and warranty information.</p>
	<p>Vornado VMHi600 Whole Room Heater Owner's Guide</p> <p>Comprehensive owner's guide for the Vornado VMHi600 Whole Room Heater, covering safety instructions, features, operation, troubleshooting, and warranty information.</p>
	<p>Vornado Velocity 5R Whole Room Heater: Owner's Guide, Safety, and Operation</p> <p>Comprehensive owner's guide for the Vornado Velocity 5R Whole Room Heater. Includes important safety instructions, operating procedures, troubleshooting, cleaning, storage, and warranty information.</p>
	<p>Vornado VH5 Personal Heater Owner's Guide: Safety, Operation, and Warranty Information</p> <p>Comprehensive owner's guide for the Vornado VH5 Personal Heater. Includes important safety instructions, operating procedures, cleaning and storage tips, troubleshooting, and warranty details.</p>
	<p>Vornado AVH10+ Whole Room Heater Use & Care Guide</p> <p>Comprehensive use and care guide for the Vornado AVH10+ Whole Room Heater, covering safety features, controls, operation, cleaning, storage, troubleshooting, and warranty information.</p>
	<p>Vornado VH203 Personal Heater Owner's Guide and Safety Instructions</p> <p>Comprehensive owner's guide for the Vornado VH203 Personal Heater. Learn about safe operation, features, cleaning, storage, troubleshooting, and warranty information for your Vornado heater.</p>