

[manuals.plus](#) /› [ZEBRONICS](#) /› [ZEBRONICS Zeb-Envy Bluetooth Wireless Over-Ear Headphones User Manual](#)

ZEBRONICS Zeb-Envy

ZEBRONICS Zeb-Envy Bluetooth Wireless Over-Ear Headphones User Manual

1. INTRODUCTION

This manual provides detailed instructions for the ZEBRONICS Zeb-Envy Bluetooth Wireless Over-Ear Headphones. Please read this guide thoroughly before using the product to ensure correct operation, optimal performance, and longevity. Keep this manual for future reference.

2. SAFETY INFORMATION

- Do not expose the headphones to extreme temperatures, humidity, or corrosive substances.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not attempt to disassemble or modify the headphones. This will void the warranty.
- Clean the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Listen at moderate volume levels to prevent hearing damage. Prolonged exposure to loud sounds can cause irreversible hearing loss.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x ZEBRONICS Zeb-Envy Over-Ear Headphone
- 1 x Detachable Microphone
- 1 x Charging Cable (USB)
- 1 x Aux Cable (3.5mm)
- 1 x User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Zeb-Envy headphones.



Image: Detailed view of the right earcup showing control buttons and ports.

Controls and Ports:

- Volume - / Previous Track:** Short press for volume down, long press for previous track.
- Play / Pause / ON / OFF:** Short press to play/pause music or answer/end calls. Long press to power on/off. Double press for voice assistant.
- Volume + / Next Track:** Short press for volume up, long press for next track.
- Aux / Detachable Mic Input:** Port for 3.5mm audio cable or detachable microphone.
- Charging Port:** USB port for charging the headphones.
- LED Control Switch:** Button to cycle through or turn off RGB lighting modes.



Image: Front view of the ZEBRONICS Zeb-Envoy headphones with the detachable microphone attached.

5. SETUP INSTRUCTIONS

5.1. Charging the Headphones

Before first use, fully charge your Zeb-Envoy headphones.

- Connect the provided USB charging cable to the charging port on the headphones.
- Connect the other end of the USB cable to a USB power adapter (5V DC) or a computer's USB port.
- The LED indicator will show charging status (e.g., red while charging, off when fully charged).
- Charging time is approximately 3 hours for up to 33 hours of playback.

3 LED Modes

Static
Mode

Breathing
LED Mode

RGB
Mode



Image: Visual representation of the charging time and playback duration of the headphones.

5.2. Powering On/Off

- **To Power On:** Long press the Play/Pause/ON/OFF button until the LED indicator lights up.
- **To Power Off:** Long press the Play/Pause/ON/OFF button until the LED indicator turns off.

5.3. Bluetooth Pairing

Pair your headphones with a Bluetooth-enabled device.

- Ensure the headphones are powered off.
- Long press the Play/Pause/ON/OFF button until the LED indicator flashes blue and red alternately, indicating pairing mode.
- Enable Bluetooth on your device (smartphone, tablet, PC, etc.).
- Search for "Zeb-Envy" in the list of available Bluetooth devices and select it to connect.
- Once connected, the LED indicator will flash blue periodically.



Detachable & Flexible Mic

40mm Driver




Image: The Zeb-Envoy headphones shown next to a smartphone, illustrating Bluetooth connectivity.

5.4. Connecting the Detachable Microphone

For enhanced call clarity or gaming, attach the flexible microphone.

- Locate the Aux/Detachable Mic Input port on the headphone earcup.
- Insert the detachable microphone's 3.5mm jack firmly into this port.
- Adjust the microphone's position for optimal voice pickup.

33 Hrs *
Playback time



3 Hrs Charging, Playback time up to 33 Hrs *

Image: A close-up view of the detachable and flexible microphone, highlighting its connection point.

5.5. Wired Connection (Aux Mode)

Use the provided 3.5mm Aux cable for a wired connection, useful when the battery is low or for devices without Bluetooth.

- Connect one end of the 3.5mm Aux cable to the Aux/Detachable Mic Input port on the headphones.
- Connect the other end to the 3.5mm audio output jack of your device.
- The headphones will automatically switch to Aux mode.

6. OPERATING INSTRUCTIONS

6.1. Music Playback

- **Play/Pause:** Short press the Play/Pause/ON/OFF button.
- **Volume Up:** Short press the Volume + button.

- **Volume Down:** Short press the Volume - button.
- **Next Track:** Long press the Volume + button.
- **Previous Track:** Long press the Volume - button.

6.2. Call Functions

- **Answer/End Call:** Short press the Play/Pause/ON/OFF button.
- **Reject Call:** Long press the Play/Pause/ON/OFF button.
- **Redial Last Number:** Double press the Play/Pause/ON/OFF button (in standby mode).

6.3. Voice Assistant

Activate your device's voice assistant (e.g., Siri, Google Assistant).

- Double press the Play/Pause/ON/OFF button to activate the voice assistant.

6.4. LED Control (RGB Lights)

The Zeb-Envy headphones feature breathing RGB lights with multiple modes.

- Press the LED Control Switch to cycle through different lighting modes (Static, Breathing, RGB).
- Press and hold the LED Control Switch to turn the lights off.



Image: The Zeb-Envy headphones showcasing various LED lighting effects.

6.5. Adjusting the Headband

Adjust the headband for a comfortable and secure fit.

- Gently slide the earcups up or down along the headband to find the optimal position.

Foldable Earcups



Adjustable Headband



Image: A detailed view demonstrating how to adjust the headband for a personalized fit.

7. MAINTENANCE

- Cleaning:** Wipe the headphones with a soft, slightly damp cloth. Do not use liquid cleaners directly on the product.
- Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** To preserve battery life, charge the headphones at least once every three months if not used regularly.

8. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair via Bluetooth.	Headphones not in pairing mode; Bluetooth disabled on device; device too far.	Ensure headphones are in pairing mode (flashing red/blue). Enable Bluetooth on your device. Move device closer to headphones (within 10 meters).
No sound.	Volume too low; incorrect input mode; device not connected.	Increase volume on headphones and device. Check if connected via Bluetooth or Aux cable correctly.
Microphone not working.	Microphone not properly connected; device settings.	Ensure detachable microphone is fully inserted. Check microphone input settings on your connected device.

9. SPECIFICATIONS

Technical details of the ZEBRONICS Zeb-Envy headphones:

Feature	Detail
Model Name	Zeb-Envy
Connectivity Technology	Wireless (Bluetooth v4.2+EDR) / Wired (3.5mm Aux)
Headphone Type	Over-Ear
Driver Size	40mm
Frequency Response	20Hz - 20kHz
Speaker Impedance	32Ω
Bluetooth Range	Up to 10 meters (open area)
Charging Time	Approximately 3 hours
Playback Time	Up to 33 hours
Talk Time	Up to 33 hours
Microphone	Detachable, Flexible Mic
Special Features	Breathing RGB Lights, Voice Assistant Support, Adjustable Headband
Item Weight	540 g
Product Dimensions	5.6 x 20.5 x 22.4 cm

10. WARRANTY AND SUPPORT

Your ZEBRONICS Zeb-Envy headphones come with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects. For warranty claims or technical support, please contact ZEBRONICS customer service with your proof of purchase.

For further assistance, visit the official ZEBRONICS website or contact their customer support channels.

© 2023 ZEBRONICS. All rights reserved.

Related Documents - Zeb-Envy

 The image shows the front cover of the Zebronics ZEB-BOOM Wireless Headphone User Manual. It features a blue background with the ZEBRONICS logo at the top, followed by the text 'ZEB-BOOM Wireless Headphone' and 'User Manual'.	<p>Zebronics ZEB-BOOM Wireless Headphone User Manual Comprehensive user manual for the Zebronics ZEB-BOOM Wireless Headphone (Model ZEB-WHP2), covering features, specifications, button functions, connectivity, and LED indicators.</p>
 The image shows the front cover of the Zebronics ZEB-Delight Pro Mini Soundbar User Manual. It features a yellow background with the ZEBRONICS logo at the top, followed by the text 'ZEB-Delight Pro Mini Soundbar' and 'User Manual'.	<p>Zebronics ZEB-Delight Pro Mini Soundbar User Manual - Features, Specifications, and Operation Guide This user manual provides comprehensive details for the Zebronics ZEB-Delight Pro Mini Soundbar. It covers product features, technical specifications, package contents, button descriptions, and step-by-step instructions for various modes including Bluetooth, USB, mSD, AUX, and FM Radio. Learn how to charge the device, use call functions, and set up TWS mode.</p>
 The image shows the front cover of the Zebronics STARLIT Portable BT Speaker User Manual. It features a black background with the ZEBRONICS logo at the top, followed by the text 'STARLIT Portable BT Speaker' and 'User Manual'.	<p>Zebronics STARLIT Portable BT Speaker User Manual Comprehensive user manual for the Zebronics STARLIT Portable BT Speaker (Model: ZEB-DSPK 106), detailing features, specifications, control panel, remote functions, and operating instructions for optimal use.</p>
 The image shows the front cover of the Zebronics ZEB-THUNDER Wireless Headphones User Manual. It features a white background with the ZEBRONICS logo at the top, followed by the text 'ZEB-THUNDER Wireless Headphones' and 'User Manual'.	<p>Zebronics ZEB-THUNDER Wireless Headphones User Manual Comprehensive user manual for Zebronics ZEB-THUNDER wireless Bluetooth headphones. Learn about features, specifications, charging, pairing, and usage.</p>



[Zebronics ZEB-MELO Portable BT Speaker User Manual](#)

Comprehensive user manual for the Zebronics ZEB-MELO portable Bluetooth speaker, covering features, specifications, button functions, pairing instructions, and LED indicators.



[ZEB-FUN Wireless Karaoke Microphone User Manual | Zebronics](#)

Comprehensive user manual for the Zebronics ZEB-FUN Wireless Karaoke Microphone. Learn about features, specifications, button functions, charging, and Bluetooth pairing.

Documents - ZEBRONICS – Zeb-Envy



[\[pdf\] User Manual Specifications Warranty](#)

ZEB ENVY 2 UM cdr Design Index of user manual zeb Audio Headphone BT zebronics info ||| User Manual www.zebronics.com Dear Customer, Thank you for purchasing **ZEB-ENVY 2** BT headphone. Please read this user manual carefully before operation save this user manual for further reference Note: Avoid the use of this product at the high temperature and high humidity environment. Avoid th...
lang:en score:38 filesize: 1.86 M page_count: 6 document date: 2024-11-08