

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Barbie](#) /

› [Barbie Dreamhouse Adventures Chelsea Soccer Playset Instruction Manual](#)

Barbie GHK37

Barbie Dreamhouse Adventures Chelsea Soccer Playset Instruction Manual

Model: GHK37

1. PRODUCT OVERVIEW

The Barbie Dreamhouse Adventures Chelsea Soccer Playset allows young imaginations to engage in sports-themed storytelling. This playset features Chelsea doll, two goals with adjustable scoring boards, a play area, and various accessories to enhance the play experience. The Chelsea doll is designed with a special "kicking" action for interactive play.

- Chelsea doll with kicking action for dynamic play.
- Two soccer goals, each equipped with an adjustable scoring board.
- Includes two puppy figures with bandanas to join the fun.
- A set of bleachers provides seating for spectators.
- Storytelling accessories such as a gold medal, backpack, water bottle, snacks, and a soccer ball are included.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This product is suitable for children aged 3 years and up. Adult supervision is recommended during play, especially with smaller accessories.

3. WHAT'S INCLUDED

The Barbie Dreamhouse Adventures Chelsea Soccer Playset includes the following components:

- 1 Chelsea doll (wearing fashion and accessories)
- 2 Puppy figures
- 2 Puppy bandanas
- 1 Field area (soccer field base)
- 2 Goals (with attached adjustable scoring boards)
- 1 Set of bleachers
- 1 Soccer ball
- 2 Flags
- 2 Puppy bones

- 1 Puppy bowl
- 1 Backpack
- 1 Gold medal
- 1 Water bottle
- 1 Snack accessory



Image: All included components of the playset.

4. SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all items from the packaging. Ensure all listed components from Section 3 are present.
2. **Assemble Goals:** Attach the two soccer goals to the designated slots on the field area base. Ensure they are securely fastened.

3. **Position Bleachers:** Place the bleacher set near the field area as desired for spectators.
4. **Arrange Accessories:** Distribute the flags, puppy accessories, backpack, water bottle, and snacks around the play area to create a soccer scene.



Image: The Chelsea Soccer Playset fully set up.

5. OPERATING INSTRUCTIONS

1. Chelsea Doll Kicking Action:

To make Chelsea doll kick the soccer ball, position her next to the ball. Gently press down on her shoulders. This action will activate her leg mechanism, allowing her to "kick" the ball across the field.

Press doll's shoulders for kicking action!



Image: Demonstrating Chelsea doll's kicking action.

2. Adjusting Scoring Board:

Each goal features an adjustable scoring board. Manually slide the numbers on the board to keep track of goals scored during play.

Adjustable scoring board!



Image: Adjusting the scoring board.

3. Using Accessories:

Utilize the included accessories such as the gold medal, backpack, water bottle, and puppy figures to create diverse play scenarios and enhance storytelling.

6. MAINTENANCE

- **Cleaning:** Wipe dolls and plastic accessories with a damp cloth and mild soap if necessary. Avoid harsh chemicals.
- **Storage:** Store the playset and its components in a clean, dry place away from direct sunlight to prevent damage and discoloration.
- **Hair Care:** For Chelsea doll's hair, gently comb with a wide-tooth comb. Avoid excessive heat or styling products.

7. TROUBLESHOOTING

- **Chelsea Doll Not Kicking:** Ensure the doll's leg mechanism is not obstructed. Press firmly but gently on her shoulders. If the issue persists, check for any debris in the joint.
- **Missing Parts:** If any components are missing upon unboxing, please contact Mattel customer support for assistance.
- **Goals or Bleachers Unstable:** Ensure all parts are correctly snapped into place during assembly.

8. SPECIFICATIONS

Brand:	Barbie
Model Number:	GHK37
UPC:	887961795233
Age Range:	3 years and up (Manufacturer Minimum Age: 36 months)
Material:	Plastic
Item Dimensions (L x W x H):	15.75 x 8.66 x 9.06 inches
Item Weight:	300 Grams
Number of Pieces:	1 (Playset includes multiple accessories)
Manufacturer:	Mattel

9. PRODUCT IMAGES



Image: A child engaging with the Chelsea Soccer Playset.



PLAYSET INCLUDES ONE CHELSEA DOLL. OTHER DOLLS SOLD SEPARATELY. SUBJECT TO AVAILABILITY.

Image: Chelsea doll with a gold medal on the soccer field.



Image: Product packaging for the playset.

10. PRODUCT VIDEOS

Your browser does not support the video tag.

Video: Official demonstration of the Barbie Chelsea Soccer Playset by MATTEL. This video showcases the doll's kicking action, the adjustable scoring board, and the various accessories included in the set.

For customer support, please visit the official Mattel website.