

[Manuals.plus](#) /

› [ALLIMITY](#) /

› ALLIMITY AH59-02533A Replacement Remote Control User Manual for Samsung Home Theater Systems

ALLIMITY AH59-02533A

ALLIMITY AH59-02533A Replacement Remote Control User Manual

For Samsung Blu-ray DVD Home Theater Systems

1. INTRODUCTION

This manual provides instructions for the ALLIMITY AH59-02533A Replacement Remote Control. This remote is designed to function as a direct replacement for the original Samsung AH59-02533A remote, compatible with various Samsung Blu-ray DVD Home Theater Systems. It operates using infrared (IR) technology and requires no programming.





Figure 1: Front view of the AH59-02533A Replacement Remote Control.

2. SETUP

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off in the direction of the arrow.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Ensure batteries are inserted correctly. Incorrect insertion may prevent the remote from functioning or cause battery leakage.






Figure 2: Battery compartment with cover removed, showing AAA battery slots.

3. OPERATING INSTRUCTIONS

This replacement remote control is designed for immediate use with compatible Samsung Blu-ray DVD Home Theater Systems without any programming. Simply insert the batteries and begin operation.

3.1 Basic Operation

- **Aiming:** Point the remote control directly towards the infrared (IR) sensor on your Samsung Home Theater System. Ensure there are no obstructions between the remote and the system.
- **No Programming Required:** This remote is a pre-programmed replacement. No setup codes or pairing procedures are necessary.
- **Button Functions:** All buttons correspond to the functions of the original remote control for your compatible Samsung Home Theater System. Refer to your home theater system's manual for specific button functionalities.

4. COMPATIBLE MODELS

The ALLIMITY AH59-02533A Replacement Remote Control is compatible with the following Samsung Blu-ray DVD Home Theater System models:

- HT-FM45, HT-HM55, HT-JM41, HT-JM41/ZA
- HT-F4500, HT-H4500, HT-H4530, HT-H5200, HT-H5530
- HT-J4100, HT-J4500, HT-J5500, HT-H5500W
- HT-J5500W, HT-J5550W
- HT-FM45/ZA, HT-HM55/ZA, HT-F4500/ZA, HT-H4500/ZA
- HT-H5500WZA, HT-J4100/ZA, HT-J4500/ZA, HT-J5500/2A
- HT-H5500W/ZA, HT-J5500W/ZA

Note: This list may not be exhaustive. If your model is not listed, please verify compatibility with the original remote's model number (AH59-02533A).

5. MAINTENANCE

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control is not working.	<ul style="list-style-type: none">Batteries are dead or inserted incorrectly.Obstruction between remote and device sensor.Remote is out of range.Infrared sensor on the home theater system is blocked or faulty.	<ul style="list-style-type: none">Replace batteries with new AAA batteries, ensuring correct polarity.Remove any objects blocking the line of sight to the home theater system's IR sensor.Move closer to the home theater system.Ensure the home theater system's IR sensor is clean and unobstructed. Test with another remote if available to confirm system functionality.
Some buttons are not responding.	<ul style="list-style-type: none">Low battery power.Button stuck or damaged.	<ul style="list-style-type: none">Replace batteries.Gently press the button multiple times. If it remains unresponsive, the button may be damaged.

7. SPECIFICATIONS

- Model Number:** AH59-02533A
- Product Material:** Plastic
- Connective Technology:** Infrared (IR)
- Power Source:** 2 x AAA Batteries (not included)
- Product Dimensions:** Approximately 5 x 2 x 0.7 inches (12.7 x 5.08 x 1.78 cm)
- Item Weight:** Approximately 2 ounces (56.7 grams)
- Color:** Black
- Special Feature:** Ergonomic design

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt for proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07XBQDKYY>

More documents and user manuals: <https://manuals.plus/>