

[Manuals.plus /](#)

[WisFox /](#)

[WisFox Wireless Keyboard and Mouse Combo User Manual](#)

WisFox B07XDWCLYF

WisFox Wireless Keyboard and Mouse Combo User Manual

Model: B07XDWCLYF

INTRODUCTION

Thank you for choosing the WisFox Wireless Keyboard and Mouse Combo. This product is designed to provide a comfortable and efficient wireless experience for your computer. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new device.



Image: The WisFox wireless keyboard, mouse, and USB receiver, showcasing the complete combo.

PACKAGE CONTENTS

- 1 x WisFox Wireless Keyboard
- 1 x WisFox Wireless Mouse
- 1 x USB Receiver (stored in the mouse battery compartment)
- 1 x User Manual (this document)

SETUP GUIDE

1. Battery Installation

The keyboard requires 1 AAA battery and the mouse requires 1 AA battery (batteries are not included). Please follow these steps:

1. Locate the battery compartment on the back of the keyboard and the bottom of the mouse.
2. Open the battery covers.
3. Insert the batteries, ensuring correct polarity (+/-).
4. Close the battery covers securely.

SMART POWER SAVING



12 Months
Battery Life



8 Min Auto
Sleep



1xAAA Battery(Not included)

1xAAA Battery(Not included)

Image: Illustration of battery insertion for both the keyboard (AAA) and mouse (AA), highlighting the battery compartments.

2. Connecting the USB Receiver

The keyboard and mouse share a single USB receiver for a stable 2.4GHz wireless connection.

1. Remove the USB receiver from the battery compartment of the mouse.
2. Plug the USB receiver into an available USB port on your computer (PC, laptop, smart TV, etc.).

3. Your computer should automatically detect and install the necessary drivers. No additional software is required.

NO DELAY NO DROPOUT

Keyboard mouse connect through 1 usb receiver



33ft Connection Range

Plug and Play

2.4GHz Stable Connection

Image: A visual representation of the USB receiver plugged into a laptop, illustrating its wireless connection to both the keyboard and mouse.




Image: A detailed view of the USB receiver inserted into a laptop's USB port, ready for use.

The effective wireless range is up to 34 feet (approximately 10 meters).

OPERATING INSTRUCTIONS

Keyboard Features

- **Full-Size Layout:** Includes a numeric keypad and function keys for comprehensive input.
- **Silent Keys:** Designed for quiet and comfortable typing.
- **12 Function Hotkeys:** Easy access to multimedia controls and common applications.
- **Ergonomic Design:** Features an ergonomic tilt angle to reduce wrist strain.
- **Splash-Proof:** Protects internal components from accidental liquid spills.



SILENT AND EFFORTLESS TYPING

Image: Hands positioned on the keyboard, illustrating the silent and smooth typing experience.



ERGONOMIC DESIGN

Reduces wrist pressure and fits your palm perfectly




Image: A side profile of the keyboard demonstrating its ergonomic tilt angle, designed for comfortable use.

COMPACT AMBIDEXTROUS COMFORT




Image: An overhead view of the keyboard, with a focus on the 12 dedicated shortcut keys for enhanced productivity.

WISFOX

WIRELESS KEYBOARD AND MOUSE COMBO



Image: A close-up of the keyboard's upper right corner, showing the Num Lock, Caps Lock, and Power LED indicators.

Mouse Features

- **Silent Click:** Reduces click noise for a quieter environment.
- **Compact Design:** Comfortable for both left and right-handed users.
- **Smart Power Saving:** Enters auto-sleep mode after 8 minutes of inactivity to conserve battery.



Image: Two hands, one left and one right, demonstrating the comfortable and ambidextrous grip on the wireless mouse.

Compatibility

This combo is widely compatible with various operating systems and devices:

- Windows 2000 / ME / XP / Vista / 7 / 8 / 10 / 11
- Mac OS
- Chrome OS
- Linux
- Suitable for desktops, laptops, PCs, Chromebooks, and smart TVs.



COMPATIBLE WITH

Windows/Mac OS/ Linux/Chrome OS



PC



Laptop



Smart TV

Image: Three icons representing compatibility with PC, Laptop, and Smart TV setups.




Image: Logos of various operating systems including Mac OS, Windows, Chrome OS, and Linux, indicating broad compatibility.

MAINTENANCE

Battery Replacement

When the keyboard or mouse stops responding or the power indicator on the keyboard blinks, it's time to replace the batteries. Follow the battery installation steps outlined in the Setup Guide.

The mouse has an approximate 12-month battery life, and the keyboard's battery life is also extended by smart power-saving features.

Cleaning

To clean your keyboard and mouse, use a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture and do not immerse the devices in liquid.

TROUBLESHOOTING

• No Response from Keyboard/Mouse:

- Ensure batteries are correctly installed and not depleted. Replace if necessary.
- Check if the USB receiver is securely plugged into a working USB port. Try a different USB port.
- Move the keyboard/mouse closer to the USB receiver to rule out range issues.
- Restart your computer.

• Lag or Intermittent Connection:

- Ensure there are no large metal objects between the keyboard/mouse and the receiver that could interfere with the signal.
- Avoid using the device on a metal surface.
- Other wireless devices (e.g., Wi-Fi routers, cordless phones) might cause interference. Try to minimize their proximity.

• Mouse Cursor Jumps or Moves Erratically:


- Clean the optical sensor on the bottom of the mouse.
- Use the mouse on a clean, non-reflective surface. A mouse pad is recommended.

SPECIFICATIONS

Feature	Detail
Product Dimensions	16.9 x 4.9 x 1 inches (Keyboard)
Item Weight	1.14 pounds
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Keyboard Battery	1 x AAA battery (not included)
Mouse Battery	1 x AA battery (not included)
Compatible Devices	Laptop, Television, Personal Computer
Compatible OS	Windows 2000/ME/XP/Vista/7/8/10/11, Mac OS, Chrome OS, Linux
Manufacturer	WisFox
Model Number	B07XDWCLYF

COMPACT FULL-SIZE KEYBOARD

16.9in/43cm



2.44in/6.2cm



1.18in/3cm



1.57in/4cm



Image: Detailed measurements of both the keyboard and mouse, indicating their compact full-size design.

WARRANTY AND SUPPORT

WisFox products are designed for reliability and performance. For any issues or questions regarding your Wireless Keyboard and Mouse Combo, please refer to the seller's return policy or contact WisFox customer support through the platform where you purchased the product.

Please retain your proof of purchase for warranty claims.



© 2025 WisFox. All rights reserved.