

[Manuals.plus](#) /

› [Audibax](#) /

› Audibax Onyx 130 Plus White Double-Braced Keyboard Stand User Manual

Audibax Onyx 130 Plus

Audibax Onyx 130 Plus White Double-Braced Keyboard Stand User Manual

Model: Onyx 130 Plus (10154055)

Brand: Audibax

INTRODUCTION

Thank you for choosing the Audibax Onyx 130 Plus White Double-Braced Keyboard Stand. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new keyboard stand. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Ensure all components are securely fastened before placing any instrument on the stand.
- Do not exceed the maximum load capacity of 65 kg.
- Always adjust the height with care, ensuring the locking mechanism is fully engaged.
- Keep hands and fingers clear of moving parts during adjustment to prevent pinching.
- Place the stand on a stable, level surface to prevent tipping.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Audibax Onyx 130 Plus White Keyboard Stand (main frame)
- Upper support arms (pre-attached or separate)
- Lower support feet (pre-attached or separate)
- Allen key (if required for assembly)
- User Manual

SETUP INSTRUCTIONS

The Audibax Onyx 130 Plus keyboard stand is designed for quick and easy assembly, typically within 10 minutes.

1. **Unfold the Stand:** Carefully unfold the main X-frame structure of the stand.
2. **Attach Arms (if separate):** If the upper and lower support arms are not pre-attached, align them with the designated holes on the main frame. Use the provided Allen key to securely fasten them. Ensure all screws are tightened to prevent wobbling.
3. **Positioning:** Place the stand on a flat, stable surface.



Figure 1: Fully assembled Audibax Onyx 130 Plus White Keyboard Stand.



OPERATING INSTRUCTIONS

Height Adjustment

The stand features an integrated adjustment system with an Easy Lock spherical joint for quick and secure height changes.

1. **Unlock:** Locate the Easy Lock handle (typically a lever or knob) at the center joint of the X-frame. Loosen or pull the handle to disengage the locking mechanism.
2. **Adjust Height:** Carefully raise or lower the stand to your desired playing height. The stand can be adjusted up to a maximum height of 97 cm.
3. **Lock:** Once the desired height is reached, engage the Easy Lock handle to secure the stand firmly in position. Ensure it is fully tightened and stable before placing your instrument.



Figure 3: Detail of the Easy Lock spherical joint for height adjustment.

Placing Your Instrument

The upper and lower arms of the stand are reinforced with non-slip rubber to ensure maximum stability and protection for your keyboard.

1. Ensure the stand is locked at the desired height.
2. Carefully place your keyboard or digital piano onto the upper support arms.

3. Verify that the instrument is centered and stable on the non-slip rubber pads.




Figure 4: Non-slip rubber feet provide stability and floor protection.



Figure 5: Upper support arm with non-slip rubber padding for instrument protection.

Transport and Storage

This keyboard stand is foldable for easy transport and storage.

1. Remove your instrument from the stand.
2. Unlock the Easy Lock mechanism.

- 3. Fold the X-frame inwards until it is compact.
- 4. Secure the stand in its folded position if a locking strap or mechanism is present.

MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all bolts, screws, and the locking mechanism for tightness and proper function. Tighten any loose fasteners.
- **Rubber Pads:** Ensure the non-slip rubber pads on the arms and feet are intact and not worn, as this affects stability and instrument protection.
- **Storage:** Store the stand in a dry environment when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Loose fasteners; uneven surface; locking mechanism not fully engaged.	Tighten all bolts and screws. Move stand to a level surface. Ensure the Easy Lock handle is fully engaged and tightened.
Difficulty adjusting height.	Locking mechanism is too tight or jammed.	Ensure the Easy Lock handle is fully loosened. Check for any obstructions in the adjustment mechanism. Do not force adjustment.
Instrument slides on the stand.	Worn or missing non-slip rubber pads; stand not level.	Inspect and replace worn rubber pads if necessary. Ensure the stand is on a level surface.

SPECIFICATIONS

Model: Onyx 130 Plus
Model Number: 10154055
Brand: Audibax
Color: White
Material: Steel Alloy
Item Weight: 4.75 kg
Item Dimensions (LxWxH): 102 x 7 x 50 cm (folded)

Maximum Height: 97 cm

Load Capacity: 65 kg

Assembly Required: Yes

Country of Origin: China

WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided by your retailer or the point of purchase. Audibax products are designed for durability and performance.

If you encounter any issues or require technical assistance, please contact Audibax customer support or your authorized dealer. Contact information can typically be found on the official Audibax website or through your retailer.

[Visit Audibax Official Website](#)