

ELECTROPRIME ASHANAM15EB23153

User Manual for ELECTROPRIME ED2F Security Mini Book Safe

Model: ASHANAM15EB23153

1. INTRODUCTION

Thank you for purchasing the ELECTROPRIME ED2F Security Mini Book Safe. This product is designed to provide a discreet and secure storage solution for your valuables, disguised as a common dictionary. It features a durable metal inner box and a key lock mechanism, along with a coin slot for convenient saving. This manual provides important information regarding the setup, operation, and maintenance of your new book safe. Please read it thoroughly before use and retain it for future reference.

2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- 1 x ELECTROPRIME ED2F Security Mini Book Safe
- 2 x Keys for the lock mechanism

Note: The product color may vary as shown in the images (e.g., Blue, Black, Red, Yellow/Brown).

3. PRODUCT OVERVIEW



Figure 1: The ELECTROPRIME ED2F Security Mini Book Safe, designed to resemble a dictionary, shown in blue. Its discreet appearance helps it blend into bookshelves.



Figure 2: This image displays the book safe in a brown color, alongside the two included keys. It also highlights the coin slot located on the top edge of the "pages" for easy deposit of coins without opening the safe.



Figure 3: The book safe is shown open, revealing its anti-impact metal inner box. Various small valuables like jewelry and a watch are placed inside, demonstrating the storage capacity and the secure locking mechanism.

4. SETUP

1. **Unpacking:** Carefully remove the book safe and its accessories from the packaging.
2. **Key Identification:** Locate the two keys provided. Keep one key in a safe, memorable location away from the book safe itself, and the other for immediate use.
3. **Initial Opening:** Insert one of the keys into the lock mechanism located on the side of the book safe (where the "pages" meet the "spine"). Turn the key clockwise to unlock and open the cover.
4. **Placement:** Place the book safe on a bookshelf or in an area where it can blend in with other books for maximum discretion.

5. OPERATING INSTRUCTIONS

5.1. Storing Valuables

1. **Opening the Safe:** Insert the key into the lock and turn it clockwise to unlock. Lift the cover to access the metal storage compartment.
2. **Placing Items:** Carefully place your valuables (e.g., cash, jewelry, small documents) inside the metal compartment. Ensure items do not obstruct the locking mechanism when closing.
3. **Closing and Locking:** Close the cover of the book safe. Insert the key into the lock and turn it counter-clockwise to lock the safe. Remove the key.

5.2. Using the Coin Slot

The book safe features a convenient coin slot on the top edge, allowing you to deposit coins without needing to open the main compartment.

- Simply slide coins into the slot. They will fall into the main storage compartment.
- To retrieve coins or other items, you must open the safe using the key as described in Section 5.1.

6. MAINTENANCE

- **Cleaning:** Wipe the exterior of the book safe with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Key Care:** Keep the keys clean and dry. Do not force the key if it feels stiff; a small amount of graphite lubricant can be applied to the lock mechanism if necessary.
- **Storage:** Store the book safe in a dry environment, away from extreme temperatures or direct sunlight, to preserve its material integrity.

7. TROUBLESHOOTING

- **Cannot open the safe with the key:**
 - Ensure the key is fully inserted and oriented correctly.
 - Try gently wiggling the key while turning.
 - Check if any items inside are obstructing the lock mechanism.
 - If the key is bent or damaged, use the spare key.
- **Key feels stiff or difficult to turn:**
 - Apply a small amount of graphite powder or a specialized lock lubricant into the keyhole. Avoid oil-based lubricants as they can attract dust.
- **Items not fitting inside:**
 - The safe is designed for small valuables. Do not attempt to force oversized items, as this may damage the safe or prevent it from closing properly.

8. SPECIFICATIONS

Attribute	Detail
Brand	ELECTROPRIME
Model Number	ASHANAM15EB23153
Material Type(s)	Plastic (exterior), Metal (interior)
Color	Beige (as per specifications, though product images show multiple colors)
Manufacturer Recommended Age	12 months and up
ASIN	B07XFT57HR
Date First Available	3 September 2019

9. WARRANTY AND SUPPORT

ELECTROPRIME products are manufactured to high-quality standards. For any issues or inquiries regarding your ED2F Security Mini Book Safe, please contact your retailer or the manufacturer directly. Please refer to your purchase receipt or product packaging for specific warranty terms and contact information. Keep your proof of purchase for warranty claims.

For general support, you may visit the ELECTROPRIME brand page on Amazon:[ELECTROPRIME Brand Store](#)

© 2025 ELECTROPRIME. All rights reserved.
This manual is subject to change without notice.