

[Manuals.plus](#) /

› [Timco](#) /

› Timco 5-in-1 Waterproof Shaver and Body Hair Trimmer BSK-1200 User Manual

Timco BSK-1200

Timco 5-in-1 Waterproof Shaver and Body Hair Trimmer BSK-1200 User Manual

INTRODUCTION

The Timco BSK-1200 is a versatile 5-in-1 grooming device designed for comprehensive hair removal and styling. This waterproof (IPX5 rated) shaver and body hair trimmer offers multiple functions including shaving, body hair trimming, outlining, and precision trimming. It features an innovative precision cutting system with 360° rotation and individual floating heads for maximum efficiency and comfort. This manual provides essential information for the safe and effective use, maintenance, and care of your Timco BSK-1200.



The Timco BSK-1200 shaver system includes the main shaver unit, a rotary shaving head, a body hair trimmer head, a precision trimmer head, a nose/ear hair trimmer head, a comb attachment, a cleaning brush, and a charging cable, all neatly organized on a charging stand.

SAFETY INFORMATION

General Safety Precautions

- **Caution:** Do not use the product while it is plugged in.
- Perform a test on a small skin area before initial use to check for any adverse reactions.
- Keep the device out of reach of children.
- Do not disassemble or attempt to repair the device yourself. Contact qualified personnel for service.
- Ensure the charging port is dry before connecting the charger.

PRODUCT COMPONENTS

The Timco BSK-1200 comes with several attachments and accessories to facilitate various grooming needs:

- Main Shaver Unit
- Rotary Shaving Head (for face)
- Body Hair Trimmer Head
- Precision Trimmer Head (for outlining, mustache, sideburns)
- Nose/Ear Hair Trimmer Head
- Adjustable Comb Attachment (20 length settings, 0.5-10 mm)
- Cleaning Brush
- Charging Cable



This image displays all included accessories: the main shaver unit, rotary shaving head, body hair trimmer head, precision trimmer head, nose/ear hair trimmer head, adjustable comb, cleaning brush, and power adapter.

SETUP

Initial Charging

1. Before first use, ensure the shaver is fully charged. Connect the charging cable to the shaver and a suitable power source.
2. The charging indicator light will illuminate during charging. A full charge typically takes approximately 60 minutes, providing up to 60 minutes of cordless operation.
3. Once fully charged, disconnect the shaver from the power source.

Attaching and Changing Heads

1. To attach a head, align the desired attachment with the main shaver unit and gently push until it clicks into place.
2. To remove a head, twist or pull it gently away from the main unit, depending on the attachment type.
3. Ensure the shaver is turned off before changing any attachments.

OPERATING INSTRUCTIONS

General Operation

1. Prepare the shaver by ensuring the battery is charged and the desired shaving or trimming head is clean and securely attached.
2. Adjust settings or modes as needed for the desired hair removal type and skin protection.
3. Turn on the shaver using the rotary ON/OFF switch.

Using the Rotary Shaving Head



A detailed view of the three individual floating rotary shaving heads, designed to adapt to facial contours for a close shave. The water droplets indicate its waterproof capability.

- Attach the rotary shaving head.
- Use the shaver on dry skin or in the shower, according to your personal preference.
- Move the shaver in small, circular motions against the direction of hair growth for a close shave. The individual floating heads will adapt to the contours of your face.

Using the Body Hair Trimmer Head

- Attach the body hair trimmer head. This head features a micro-fine skin protector with 10 layers of protection.

- Gently glide the trimmer over the desired body areas.

Using the Precision Trimmer and Comb Attachment



The adjustable comb attachment allows for precise trimming with 20 length settings, ranging from 0.5mm to 10mm, ideal for beard styling or body hair grooming.

- Attach the precision trimmer head. This is ideal for maintaining mustaches and trimming sideburns.
- For specific hair lengths, attach the adjustable comb. Select one of the 20 length settings (0.5-10 mm) by rotating the dial on the comb.
- Move the trimmer against the direction of hair growth for an even trim.

Using the Nose/Ear Hair Trimmer Head

- Attach the nose/ear hair trimmer head.
- Carefully insert the trimmer into the nostril or ear canal and gently move it to trim unwanted hair. Do not insert too deeply.

MAINTENANCE

Cleaning the Shaver

1. After each use, turn off the shaver and remove the attached head.
2. Rinse the shaving head and the main unit under running water. The device is waterproof, allowing for easy cleaning.
3. Use the included cleaning brush to remove any stubborn hair clippings from the blades and internal components of the heads.
4. Allow all parts to air dry completely before reattaching the head or storing the device.

Storage

- Store the shaver and its attachments in a dry place, away from direct sunlight and extreme temperatures.
- Ensure the device is clean and dry before storing to prevent corrosion or damage.

TROUBLESHOOTING

Common Issues and Solutions

- **Device not turning on:** Ensure the battery is charged. If the battery is low, connect the charger and allow it to charge for at least 10-15 minutes before attempting to turn it on again.
- **Poor shaving/trimming performance:** Clean the shaving head thoroughly to remove any accumulated hair or debris. Ensure the blades are not dull or damaged. If performance does not improve, consider replacing the shaving head if available.
- **Device stops during use:** The battery might be depleted. Recharge the device. If the issue persists after charging, contact customer support.
- **Irritation after use:** Ensure your skin is clean before use. Use the shaver on dry skin or with shaving foam/gel for wet shaving. Always perform a small skin test before full use.

SPECIFICATIONS

Feature	Detail
Product Dimensions	7 x 1 x 3 cm; 300 g
Manufacturer	Timco S.A. de C.V.
ASIN	B07XG8B1K2

Product Model Number	BSK-12000
Country of Origin	Mexico
Brand	Timco
Recommended Uses	Face, body, mustache, sideburns
Special Feature	Precision cutting system with 360° rotation
Power Source	Electric with rechargeable battery
Model Name	BSK-1200
Included Components	Trimmer, Body hair head, Charger
Battery Life	60 minutes
Color	Off-white
Blade Material	Stainless Steel
Head Type	Rotary

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact Timco customer service directly. You may also visit the official Timco store for additional product information and support resources:
[Timco Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question