

[manuals.plus](#) /

› [Monzana](#) /

› [MONZANA Lilly Smart Digital Desk Lamp User Manual](#)

Monzana 107703

MONZANA Lilly Smart Digital Desk Lamp User Manual

Model: 107703

1. PRODUCT OVERVIEW

The MONZANA Lilly Smart Digital Desk Lamp is a versatile LED lamp designed for various environments such as offices, bedrooms, or study areas. It features a modern design with a leather-look finish and a multifunctional digital display.



This image illustrates the MONZANA Lilly Smart Digital Desk Lamp being used in different settings, such as for reading, as a bedside lamp, and in an office environment. It highlights the lamp's versatility.

Key Features:

- **Multifunctional Digital Display:** Shows time, date, day of the week, temperature, and includes an alarm function.
- **3 Brightness Levels:** Adjustable light intensity (30%, 70%, 100%).
- **Flexible Lamp Arm:** Allows for precise light positioning.
- **Dark, Glare-Free Display:** Ideal for bedside use, can be turned off.
- **Energy-Saving LED Technology:** Long lifespan and low power consumption.
- **Non-Slip Base:** Rubberized base for stability and furniture protection.
- **Elegant Design:** Features a stylish leather-look finish.

2. SETUP

2.1 Unpacking

1. Carefully remove all components from the packaging.
2. Check for any damage during transit. If any damage is found, do not use the product and contact

customer support.

3. Ensure all listed components are present: Lamp unit, Power cable.

2.2 Power Connection

1. Place the lamp on a stable, flat surface. The rubberized base helps prevent slipping.
2. Connect the power cable to the lamp's power input port.
3. Plug the power adapter into a suitable electrical outlet.
4. The digital display should illuminate, indicating the lamp is powered.

3. OPERATING INSTRUCTIONS

3.1 Power On/Off

- To turn the lamp **ON** or **OFF**, briefly press the power button located on the base.

3.2 Adjusting Brightness

The lamp offers three levels of brightness:

1. With the lamp ON, press the power button repeatedly to cycle through the brightness levels: 30% (Level 1), 70% (Level 2), and 100% (Level 3).



This image shows the lamp's three adjustable brightness levels (Level 1, Level 2, Level 3), illustrating the different light intensities available for various tasks.

3.3 Digital Display Functions

The integrated digital display shows the time, date, day of the week, and ambient temperature.

Temperatur

Zeit

Tag

Datum



A detailed view of the lamp's digital display, clearly showing the temperature, current time, and date. Icons below indicate its functions: light, clock, calendar, alarm, and thermometer.

Setting Time and Date:

Refer to the specific buttons near the display for setting the time, date, and alarm. Typically, there are 'Mode', 'Set', 'Up', and 'Down' buttons. Press 'Mode' to select the setting (Time, Date, Alarm), then 'Set' to enter adjustment mode, and 'Up'/'Down' to change values. Press 'Set' again to confirm and move to the next setting.

Alarm Function:


The lamp includes an integrated alarm clock. Follow the display setting instructions to set and activate the alarm. The button cell battery included ensures settings are retained even when the lamp is unplugged.

Turning Off the Display:

- To completely turn off the digital display (e.g., for use as a bedside lamp), press and hold the power button for 3 seconds.
- To turn the display back on, briefly press the power button again.

3.4 Adjusting the Lamp Arm

The lamp features a flexible arm that can be rotated and tilted to direct the light as desired.



This graphic demonstrates the flexible design of the lamp's arm, which can be bent and adjusted to direct light precisely where needed.

- Gently bend or rotate the lamp arm to achieve the optimal lighting angle. Avoid excessive force to prevent damage.

4. MAINTENANCE

4.1 Cleaning

- Before cleaning, ensure the lamp is unplugged from the power outlet.
- Wipe the lamp's surface with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electronic components.
- Avoid getting moisture into the electrical parts.

4.2 LED Lifespan

- The integrated LED bulbs are designed for a long lifespan and are not user-replaceable.
- If the LEDs fail, the entire lamp unit may need to be replaced.


5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Check if the power cable is securely plugged into the lamp and the wall outlet. Test the outlet with another device.
Digital display is off.	Display was intentionally turned off.	Briefly press the power button to reactivate the display.
Time/Date/Alarm settings are incorrect after power loss.	Button cell battery may be depleted or missing.	The lamp uses a button cell battery to retain settings. Ensure it is present and functional. Replace if necessary (refer to battery compartment, usually on the base).
Brightness cannot be adjusted.	Lamp is not in the correct mode or button malfunction.	Ensure the lamp is on. Briefly press the power button to cycle through brightness levels. If the issue persists, contact customer support.

6. SPECIFICATIONS

Feature	Specification
Brand	Monzana
Model Number	107703
Power	5 W
Luminous Flux	260 lm

Feature	Specification
Light Color Temperature	4000 Kelvin (Neutral White)
Operating Mode	Mains operation
Dimensions (H x W x D)	50 x 9 x 6.5 cm (approximate)
Material	ABS, Rubber
Finish Type	Leather look
Energy Efficiency Class	G
Energy Consumption	5 kWh/1000h



7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Keep your proof of purchase for any warranty claims.