

ASHATA F899

ASHATA F899 Flip Mobile Phone User Manual

Model: F899

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your ASHATA F899 Flip Mobile Phone. Please read this manual thoroughly before operating the device and retain it for future reference. The ASHATA F899 is designed for ease of use, featuring a 2.4-inch display, large buttons, and essential functions for communication.

SAFETY INFORMATION

- **Network Compatibility:** This phone operates on 2G GSM 900/1800 MHz networks. Verify network compatibility with your service provider before use.
- **Battery Safety:** Use only approved batteries and chargers. Do not short-circuit, puncture, or expose the battery to extreme temperatures.
- **Water Resistance:** This device is not water-resistant. Avoid exposure to liquids.
- **Hearing Protection:** Avoid prolonged listening at high volume levels to prevent hearing damage.
- **Driving Safety:** Do not use the phone while driving. Follow local laws and regulations regarding mobile phone use.

PHONE OVERVIEW

Familiarize yourself with the physical components of your ASHATA F899 phone.



Image Description: A red ASHATA F899 flip phone shown from the front, closed. Labels point to the outside screen earpiece, one-button flashlight, HD outer screen, answer key, one-button telling time key, and hang up key.



Image Description: The back of the red ASHATA F899 flip phone with labels indicating the HD camera, external horn (speaker), strong light flashlight, and metal shell.



Image Description: A composite image showing both the front (closed) and back of the ASHATA F899 phone with various features labeled, including outer earpiece, one key on/off torch, 1.44" outer display, answer call, SOS help, off call, back camera, loud speaker, pull down to open back cover, and 50m flashlight.

SETUP

1. Inserting SIM Cards and Battery

1. **Remove Back Cover:** Gently pull down the back cover from the designated area (refer to Phone Overview image).
2. **Insert SIM Cards:** The phone supports dual SIM cards. Carefully insert your 2G GSM SIM cards into the designated slots. Ensure the gold contacts face downwards.
3. **Insert Battery:** Place the 2800mAh battery into its compartment, aligning the contacts.
4. **Replace Back Cover:** Securely attach the back cover until it clicks into place.



Longer Battery Life

- 2800mAh large capacity battery
- multiple protection, safe to use
- support long time standby




Image Description: The ASHATA F899 flip phone is shown open, displaying the internal screen with "Insert SIM" prompts and the keypad. This illustrates where SIM cards would be inserted and the phone's internal display.

2. Charging the Phone

Before first use, fully charge the phone's battery.

- Connect the charger cable to the phone's USB port.
- Plug the charger into a power outlet.
- The battery indicator on the screen will show charging status.
- Disconnect the charger once the battery is fully charged.



Image Description: A graphic representation of a battery icon with a lightning bolt, indicating the phone is charging or has a full battery.

3. Powering On/Off

- **To Power On:** Press and hold the Power/End Call button until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power-off options appear, then select "Power Off".

OPERATING INSTRUCTIONS

Making and Receiving Calls

- **To Make a Call:** Open the flip, dial the number using the keypad, and press the green Call button.
- **To Receive a Call:** When the phone rings, open the flip (if closed) and press the green Call button to answer.
- **To End a Call:** Press the red End Call button or close the flip.



Image Description: The ASHATA F899 flip phone is shown open, highlighting its large, easy-to-read keypad buttons, designed for user convenience.

Phone Book

Store frequently called numbers in the phone book for quick access. Navigate to the "Phone Book" menu, select "Add New Contact," and enter the name and number.

Flashlight Function

The phone features a dedicated flashlight button for convenience.

- **To Turn On/Off:** Press and hold the dedicated flashlight button (often an orange button on the side or top, as shown in images).
- The flashlight provides illumination up to 50 meters.



Image Description: An image demonstrating the flashlight function of the ASHATA F899 phone. A beam of light emanates from the phone's top, and an inset shows the orange button used to activate it.

FM Radio

Listen to FM radio stations without needing headphones.

- Access the "Radio" application from the main menu.
- Use the navigation keys to scan for stations.
- The phone features an external antenna for improved signal reception.



Image Description: The ASHATA F899 flip phone is shown with its external FM antenna extended, indicating its capability for radio reception.

Other Functions

The ASHATA F899 includes several utility functions:

- **Alarm:** Set multiple alarms for reminders.
- **Recording:** Use the voice recorder for notes or conversations.
- **Calendar:** Keep track of dates and events.
- **Calculator:** Perform basic arithmetic operations.
- **E-book:** Read text files on the device.
- **Vibration:** The phone supports vibration alerts for calls and messages.
- **Telling Time Function:** A dedicated button provides an audible time announcement.
- **Camera:** The phone includes a rear camera for basic photo capture.
- **Voice Assistance:** The phone offers full voice assistance for enhanced usability.

Functions: phone book, camera, radio, alarm, recording, calendar, flashlight, calculator, e-book, vibration and other functions



Image Description: The ASHATA F899 flip phone is shown closed, displaying icons on its outer casing that represent functions such as camera and FM radio.

Vibration



Image Description: A graphic illustrating the vibration feature of the ASHATA F899 flip phone, with wavy lines indicating vibration around the device.

SOS Function

The phone is equipped with an SOS button for emergency situations.

- **Setup:** Access the SOS settings in the menu to program emergency contact numbers.
- **Activation:** In an emergency, press and hold the dedicated SOS button (located below the screen on the front). The phone will automatically dial the pre-set emergency numbers and send an emergency message.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's exterior. Avoid harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the phone regularly.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Phone does not power on	Low battery; Battery not inserted correctly; Damaged battery.	Charge the battery; Reinsert the battery; Replace the battery.
Cannot make/receive calls	No network signal; SIM card not inserted correctly; Incorrect network settings; Incompatible network (not 2G GSM 900/1800 MHz).	Move to an area with better signal; Reinsert SIM card; Check network settings; Verify your service provider supports 2G GSM 900/1800 MHz.

Problem	Possible Cause	Solution
Poor call quality	Weak signal; Obstructions; Network congestion.	Move to an open area; Try again later.
Battery drains quickly	Frequent use; Background applications; Old battery.	Reduce screen brightness; Close unused applications; Replace battery if old.

SPECIFICATIONS

Feature	Detail
Model	F899
Brand	ASHATA
Display Size	2.4 Inches
Operating System	KaiOS
Cellular Technology	2G (GSM 900/1800 MHz)
SIM Card Slot Count	Dual SIM
Battery Capacity	2800 mAh
Phone Talk Time	Up to 11 Hours
Connectivity	USB
Camera	Rear Camera
Dimensions (L x W x H)	4.09 x 2.17 x 0.79 inches (10.4 x 5.5 x 2 cm)
Item Weight	7.4 ounces
Special Features	Flashlight, FM Radio, Voice Assistance, SOS Button, Large Buttons

Size: Approx. 10.4x5.5x2 cm/ 4.09x2.17x0.79 inch



Image Description: The ASHATA F899 flip phone is shown with its approximate dimensions (length, width, thickness) labeled in both centimeters and inches.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact ASHATA customer service. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07XH1PPVQ>

More documents and user manuals: <https://manuals.plus/>