

[Manuals.plus](#) /

› [TRIXIE](#) /

› TRIXIE 24451 Replacement Filter for 24450 Pet Water Fountain - User Manual

TRIXIE 24451

TRIXIE 24451 Replacement Filter for 24450 Pet Water Fountain

Model: 24451 | Brand: TRIXIE

INTRODUCTION

This manual provides instructions for the TRIXIE 24451 replacement filters, designed for use with the TRIXIE 24450 pet water fountain. Regular filter replacement is essential for maintaining water quality and the longevity of your fountain.

PRODUCT OVERVIEW

The TRIXIE 24451 replacement filter pack contains four individual filters. Each filter is designed to purify water, removing impurities and odors, ensuring fresh drinking water for your pet.



This image illustrates the TRIXIE 24451 replacement filter positioned alongside the TRIXIE 24450 pet water fountain, demonstrating how the filter fits into the overall system.

INITIAL SETUP AND FILTER INSTALLATION

Before first use or after cleaning the fountain, install a new filter by following these steps:

1. Rinse the new filter thoroughly under cold running water for several minutes to remove any loose carbon dust.
2. Disassemble the TRIXIE 24450 water fountain according to its specific instructions.
3. Locate the filter housing within the fountain.
4. Insert the rinsed filter into the designated slot, ensuring it is seated correctly.
5. Reassemble the fountain, ensuring all parts are securely in place.
6. Fill the fountain with fresh water.



This image provides a top-down view of the TRIXIE 24451 filter, highlighting its shape and how it would be oriented during installation.

OPERATION

Once the filter is installed and the fountain is filled with water, plug in the fountain to begin operation. The filter will continuously purify the water as it circulates. Ensure the water level is always above the minimum mark to prevent pump damage.

MAINTENANCE AND FILTER REPLACEMENT

For optimal water quality and fountain performance, replace the filter regularly. It is recommended to replace the filter every 2 to 4 weeks, or more frequently if multiple pets use the fountain or if the water appears dirty.

1. Unplug the water fountain from the power outlet.
2. Disassemble the fountain.
3. Remove the old, used filter from its housing. Dispose of the old filter responsibly.
4. Rinse a new TRIXIE 24451 filter under cold running water for several minutes.
5. Insert the new filter into the filter housing, ensuring a snug fit.
6. Clean the fountain components (pump, bowl, lid) thoroughly before reassembly.
7. Reassemble the fountain and refill with fresh water.
8. Plug the fountain back into the power outlet.



This close-up image details the internal structure of the TRIXIE 24451 filter, illustrating the filtration media responsible for purifying the water.

TROUBLESHOOTING

- **Fountain not dispensing water:** Check if the pump is clean and free of debris. Ensure the water level is sufficient. Verify the power connection.
- **Water flow is weak:** The filter might be clogged. Replace the filter. Clean the pump and impeller.
- **Unpleasant odor or taste in water:** Replace the filter immediately. Clean the entire fountain thoroughly.
- **Filter does not fit:** Ensure you are using the correct replacement filter (TRIXIE 24451) for the TRIXIE 24450 fountain.

PRODUCT SPECIFICATIONS

Brand	TRIXIE
Model Number	24451
Product Type	Replacement Filter for Pet Water Fountain
Compatibility	TRIXIE 24450 Pet Water Fountain
Package Contents	4 Filters
Package Dimensions (L x W x H)	1.8 x 10.0 x 20.0 cm
Package Weight	60 g
Product Dimensions (L x W x H)	4 x 15 x 20 cm
Product Weight	80 g
Color	White
Batteries Required	No
Batteries Included	No
Country of Origin	Germany

WARRANTY INFORMATION

This product is a consumable item. Please refer to the TRIXIE 24450 Pet Water Fountain manual for warranty details regarding the fountain itself. For specific information on the replacement filters, please contact TRIXIE customer support.

CUSTOMER SUPPORT

For further assistance or inquiries regarding the TRIXIE 24451 replacement filters, please visit the official TRIXIE website or contact their customer service department.

www.trixie.de