

## KONIX MD862G

# KONIX Electronic Drum Set MD862G User Manual

Comprehensive instructions for your KONIX Electronic Drum Set, Model MD862G.

## 1. PRODUCT OVERVIEW

The KONIX Electronic Drum Set MD862G is a portable, roll-up electronic drum kit designed for beginners and enthusiasts. It features 9 pads, built-in speakers, and various connectivity options for an enhanced drumming experience.



## 2. PACKAGE CONTENTS

---

Verify that all items are present in your package:

- 1 x Electronic Drum Pad
- 2 x Drum Sticks
- 1 x USB Cable
- 2 x Foot Pedals (Bass Drum, Hi-Hat)
- 1 x User Manual
- 1 x 3.5mm Audio Cable
- 1 x Power Adapter

## 3. SETUP INSTRUCTIONS

---

1. **Unpack the Drum Set:** Carefully remove all components from the packaging.
2. **Place the Drum Pad:** Unroll the electronic drum pad on a flat, stable surface.
3. **Connect Foot Pedals:** Plug the two foot pedals into their respective ports on the control module. One pedal controls the bass drum, and the other controls the hi-hat.
4. **Power Connection:** Connect the power adapter to the 'USB/DC 5V' port on the control module and plug it into a power outlet. The unit can also be powered via the built-in rechargeable battery.
5. **Power On:** Locate the ON/OFF switch on the control module and slide it to the 'ON' position.
6. **Optional Audio Connections:**
  - **Headphones:** For private practice, plug headphones into the headphone jack.
  - **External Speaker/Amplifier:** To output sound to an external speaker or amplifier, use the 3.5mm audio cable to connect the drum set's MP3 output to your external audio device's input.
  - **MP3 Input:** To play along with music from an external device (e.g., smartphone, MP3 player), connect it to the 'MP3' input port using the 3.5mm audio cable.
  - **MIDI Connection:** Connect the drum set to a computer or phone via the USB port to use it as a MIDI controller for music software or games.

- ① Crash cymbal
- ④ Ride cymbal
- ⑦ High tom

- ② Crash cymbal
- ⑤ Snare
- ⑧ Low-mid tom

- ③ Open/Close hi-hat
- ⑥ Bass drum
- ⑨ Low floor tom



Image 3.1: Detailed view of the drum pads and control module ports for connections.

Video 3.1: An official product video demonstrating the setup and basic features of the KONIX Electronic Drum Set.

## 4. OPERATING YOUR KONIX ELECTRONIC DRUM SET

### 4.1 Drum Pads and Pedals

The drum set features 9 velocity-sensitive pads, including bass drum, tom, snare, hi-hat, and crash cymbal. Use the included drumsticks to strike the pads. The foot pedals control the bass drum and hi-hat for a more realistic drumming experience.

### 4.2 Control Module Functions

- **VOL+ / VOL-:** Adjusts the master volume of the drum set.
- **STYLE:** Cycles through 7 different drum tones/kits.
- **DEMO:** Plays one of the 12 built-in demo songs.
- **REC:** Activates recording mode to capture your drumming.
- **PLAY:** Plays back your recorded performance.
- **RHY:** Cycles through 9 different rhythms to play along with.
- **START/STOP:** Starts or stops demo songs, rhythms, or recorded playback.

- **T+ / T-:** Adjusts the tempo (speed) of demo songs or rhythms.



Image 4.1: A child enjoying the drum set with headphones, allowing for quiet practice.

## Built-in Stereo Speakers



Image 4.2: A child playing the drum set, utilizing the built-in stereo speakers.

## 5. MAINTENANCE

### 5.1 Cleaning

The drum pad is made of silicone. To clean, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.

### 5.2 Battery Charging

The drum set features a built-in rechargeable Lithium-Ion battery. Connect the power adapter to charge the unit. A full charge provides approximately 10 hours of playtime. The charging indicator light on the control module will show the charging status.

## High Quality & Safety Material

Made of top quality premium silicone that is 100% safe for your little angels



Image 5.1: The drum set connected to its power adapter for charging.

### 5.3 Storage

The flexible silicone design allows the drum pad to be rolled up for compact storage and portability. Ensure the unit is powered off before rolling it up. Store in a cool, dry place away from direct sunlight and extreme temperatures.

# Feel Your Music On The Road



rechargeable battery  
up to 8 hours



Rechargeable Batteries included  
Roll up & Portable



Image 5.2: The drum set being rolled up for easy storage and transport.

## 6. TROUBLESHOOTING

- **No Sound:**

- Ensure the unit is powered on.
- Check the volume level using the VOL+ button.
- If using headphones or external speakers, ensure they are properly connected and their volume is adjusted.

- **Pads Not Responding:**

- Ensure the drum pad is fully unrolled and lying flat.
- Check that the drumsticks are making proper contact with the pads.

- **Foot Pedals Not Working:**

- Verify that the foot pedals are securely plugged into their designated ports.

- **Bluetooth Connectivity Issues:**

- Ensure the drum set's Bluetooth is enabled (refer to specific instructions in the included manual if available).
- Ensure your external device's Bluetooth is on and attempting to pair.
- Move the drum set closer to the external device to reduce interference.

## 7. SPECIFICATIONS


<b>Model Name</b>	MD862G
<b>Brand</b>	KONIX
<b>Item Weight</b>	3.08 Pounds
<b>Product Dimensions</b>	18 x 12 x 2 inches
<b>Body Material</b>	Bass Wood
<b>Material Type</b>	Plastic, Silicone
<b>Color</b>	Green
<b>Included Components</b>	Electronic Drum Pad, 2 Drum Sticks, USB Cable, 2 Foot Pedals, 3.5mm Audio Cable, Power Adapter
<b>Speaker Count</b>	2 (Built-in)
<b>Battery Type</b>	1 Lithium Ion battery required (included)
<b>Connector Type</b>	AUX In, USB

## 8. WARRANTY AND SUPPORT

For any questions or support needs regarding your KONIX Electronic Drum Set MD862G, please refer to the contact information provided in your product packaging or visit the official KONIX website. Specific warranty details may vary and are typically outlined in the documentation included with your purchase.


### Related Documents - MD862G

	<p><a href="#"><u>KONIX MD862 Electronic Drum Kit User Manual</u></a></p> <p>User manual for the KONIX MD862 Portable USB 7 Pads Roll Up Electronic Drum Kit. Includes setup instructions, features, and software download information.</p>
	<p><a href="#"><u>KONIX PA61DM PA88DM Electronic Keyboard User Manual</u></a></p> <p>User manual for the KONIX PA61DM and PA88DM foldable portable 88-key electronic keyboards, detailing functions like Bluetooth Play, Bluetooth MIDI, and charging indicators.</p>
	<p><a href="#"><u>Dynamic Portable Electronic Drum Operation Manual</u></a></p> <p>This manual provides instructions for the Dynamic Portable Electronic Drum, covering its features, functions, connections, troubleshooting, and precautions. It details how to set up and use the electronic drum kit for practice, entertainment, and music creation.</p>
	<p><a href="#"><u>Konix KHXPIANO6188 Portable Electronic Piano User Manual</u></a></p> <p>User manual for the Konix KHXPIANO6188 Portable Electronic Piano, providing setup, operation, and maintenance information from Shenzhen Konix Technology Co., Ltd.</p>



#### [Konix Naruto Shippuden Gaming Headset User Manual](#)

User manual for the Konix Naruto Shippuden gaming headset, detailing specifications, features, and safety guidelines for console and PC gaming.



#### [Konix Naruto Shippuden Wired Controller User Manual for Nintendo Switch and PC](#)

User manual for the Konix Naruto Shippuden Wired Controller, detailing setup and usage for both Nintendo Switch and PC. Includes troubleshooting for joysticks and maintenance guidelines.