

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CHOUBENBEN](#) /

› [CHOUBENBEN Replacement Remote Control for Arctic King Midea Comfort-aire Window Air Conditioners User Manual](#)

## CHOUBENBEN R09/BGE R09/BGCE

# CHOUBENBEN Replacement Remote Control User Manual

For Arctic King, Midea, and Comfort-aire Window Air Conditioners

## INTRODUCTION

---

This manual provides instructions for the CHOUBENBEN replacement remote control, designed for use with various Arctic King, Midea, and Comfort-aire window air conditioner models. This remote offers essential functions for comfortable climate control.

## COMPATIBILITY

---

This remote control is compatible with the following air conditioner remote control models:

- R09B/BGE
- R09B/BGCE
- R09A/BG(C)E
- R09B/BG(C)E
- R09C/BG(C)E
- R09/BG(C)E
- RG09B/BG(C)EF
- RADS-151P
- BG-103P
- BG-101P
- BG-121P
- RADS-183P
- BG-81P
- BG-123P
- BGE-143M

## SETUP

---

### Battery Installation

The remote control requires two AAA 1.5V batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Back of the remote control with the battery compartment.

## OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and display on your remote control:



Figure 2: Front view of the remote control, highlighting the display and buttons.

- **Power Button ( ):** Press to turn the air conditioner ON or OFF.
- **MODE Button:** Cycles through various operating modes such as Cool, Fan, Dry, Heat (if supported by AC unit), and Auto.
- **Temperature Adjustment Buttons (▲ / ▼):** Use these buttons to increase or decrease the desired temperature setting.
- **FAN Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER Button:** Sets the timer for automatic ON/OFF operations. Refer to your air conditioner's manual for specific timer programming.
- **CANCEL Button:** Cancels the currently set timer or other active functions.
- **CLOCK Button:** Used to set the current time on the remote's display.
- **ENERGY SAVER Button:** Activates or deactivates the energy-saving mode.
- **FOLLOW ME Button:** If your air conditioner supports this feature, the remote will sense the temperature at its location and adjust the AC accordingly.
- **RESET Button:** Resets certain settings or functions.

- **LOCK Button:** Locks the remote control buttons to prevent accidental changes.
- **SLEEP Button:** Activates the sleep mode, which typically adjusts temperature and fan speed for comfortable sleep.
- **LED Button:** Controls the display light or other LED indicators on the remote.

## Display Features

- **Green Backlight:** The remote features a green backlight for improved visibility in low-light conditions.
- **Fahrenheit and Celsius Display:** The temperature can be displayed in both Fahrenheit and Celsius. Consult your air conditioner's manual or experiment with the remote's buttons (often a combination press) to switch between units.

## MAINTENANCE

---

### Battery Replacement

Replace batteries when the remote's display becomes dim or the remote stops responding. Always replace both batteries at the same time with new AAA 1.5V batteries. Do not mix old and new batteries or different types of batteries.

### Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the remote's surface or internal components.

## TROUBLESHOOTING

---

- **Remote not responding:**
  - Check if the batteries are installed correctly and are not depleted. Replace if necessary.
  - Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Remove any obstructions.
  - Confirm the remote is compatible with your specific air conditioner model (refer to the Compatibility section).
- **Display is dim or blank:**
  - Replace the batteries.

## SPECIFICATIONS

---

- **Model Number:** R09/BGE R09/BGCE
- **Power Source:** 2 x AAA 1.5V Batteries (not included)
- **Item Weight:** 1.76 ounces
- **Package Dimensions:** 6.3 x 3.5 x 1.18 inches
- **Compatible Devices:** Air Conditioner
- **Max Number of Supported Devices:** 1
- **Special Feature:** Ergonomic design, Luminous button, Green backlight

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact the manufacturer, CHOUENBEN, or your retailer. Keep your purchase receipt for any warranty claims.

