

[Manuals.plus](#) /

> [Apple](#) /

> Apple Leather Case for iPhone 11 Pro Max - Instruction Manual

Apple MX0E2ZM/A

Apple Leather Case for iPhone 11 Pro Max - Instruction Manual

INTRODUCTION

This manual provides instructions for the Apple Leather Case designed specifically for the iPhone 11 Pro Max. This case is crafted from specially tanned and finished European leather, offering a soft touch and developing a natural patina over time. It is engineered to protect your iPhone from scratches and drops while maintaining a sleek profile.

SETUP AND INSTALLATION

To install the case, align your iPhone 11 Pro Max with the case and gently press it into place, ensuring all edges are securely covered. To remove the case, gently peel back one corner and carefully extract your iPhone.






Image: Back view of the Apple Leather Case, showing the camera cutout and Apple logo. This image illustrates the exterior design of the case.





Image: Front view of the Apple Leather Case installed on an iPhone 11 Pro Max, highlighting the precise fit around the screen and buttons. This image demonstrates how the case fits the device.

OPERATING INSTRUCTIONS

The case features machined aluminum buttons that match its finish, providing tactile feedback for volume and power controls. A microfiber lining inside helps protect your iPhone's finish. The case supports wireless charging, allowing you to charge your device without removing the case.

MAINTENANCE

The European leather used in this case will develop a natural patina over time, enhancing its unique character. To clean the case, gently wipe it with a soft, damp cloth. Avoid harsh chemicals or abrasive materials, as these can damage the leather finish.

TROUBLESHOOTING

- **Buttons Unresponsive:** Ensure the case is correctly seated on the iPhone, with all buttons aligned properly.
- **Improper Fit:** Verify that the case is specifically designed for the iPhone 11 Pro Max. A misaligned installation can also cause fit issues.
- **Wireless Charging Issues:** Ensure your iPhone is correctly positioned on the wireless charger. If issues persist, temporarily remove the case to confirm it is not interfering.

For persistent issues, refer to Apple's official support resources.

SPECIFICATIONS

- **Material:** European Leather
- **Compatible Phone Models:** iPhone 11 Pro Max
- **Item Weight:** 1.65 ounces
- **Product Dimensions:** 62.19 x 30.65 x 3.19 inches
- **Model Number:** MX0E2ZM/A
- **Color:** Black

WARRANTY AND SUPPORT

For detailed warranty information and product support, please visit the official Apple website or contact Apple customer service directly. This product is covered by Apple's standard warranty policies.