

SHW OD-005-2

SHW L-Shape Corner Office Computer Desk User Manual

Brand: SHW

Model: OD-005-2

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your SHW 55 x 60 Inches Commercial-Grade L-Shape Corner Office Computer Desk. Designed for demanding workspaces, this desk offers a robust and adaptable solution for offices, corporate environments, and team settings. Its L-shape design maximizes corner space, providing ample surface area for various tasks.

2. PRODUCT FEATURES

- **Engineered for Demanding Workspaces:** Ideal for offices, corporate environments, and team settings requiring dependable, professional-grade furniture.
- **Commercial-Quality Construction:** Built with a powder-coated steel frame and environmentally certified particle board, designed to withstand daily operational use.
- **Enhanced Stability:** Adjustable leveling glides ensure a steady setup on uneven floors, supporting consistent performance across varied office layouts.
- **Integrated Cable Management:** Equipped with 3 grommets openings for organized wire routing, ideal for IT, audio & visual, or workstation configurations.
- **Dimensions:** 23.8" D x 55–60" W x 28" H.



Figure 2.1: Desk Dimensions. The desk measures 23.8 inches deep, with one side being 55 inches long and the other 60 inches long. The overall height is 28 inches.



Figure 2.2: Integrated Cable Management. The desk features grommet openings to help organize and route cables, keeping your workspace tidy.

3. SAFETY INFORMATION

For optimal stability and safety, the desk should be anchored to the wall. The maximum weight recommendation for the desk surface is **100 pounds (approximately 45 kg)**. Do not exceed this weight limit to prevent damage or injury. Ensure all components are securely fastened during assembly and periodically check for tightness.

4. SETUP AND ASSEMBLY

The SHW L-Shape Corner Office Computer Desk is designed for simple and easy assembly. All necessary tools are included. Follow the step-by-step instructions provided in the packaging. It is recommended to have two people for assembly to ensure proper alignment and stability, especially when attaching the larger top pieces.

Assembly Tips:

- Unpack all components and verify against the parts list before beginning assembly.
- Assemble on a soft, clean surface to prevent scratches to the desk components.
- Do not fully tighten screws until all components are loosely assembled and aligned. This allows for minor adjustments.

- The L-shape configuration is reversible, allowing you to set up the longer or shorter side to your left or right as needed.




Figure 4.1: Desk Frame Assembly. The sturdy powder-coated steel frame provides a stable base for the desk.



Figure 4.2: Completed Desk Structure. The desk features an oak finish desktop on a white steel frame, ready for use.

5. OPERATING AND USAGE

This L-shaped desk provides a generous work surface suitable for various applications, from a home office setup to a gaming station. The ample space accommodates multiple monitors, keyboards, and other peripherals, allowing for an organized and efficient workspace.

Optimizing Your Workspace:

- Utilize the L-shape to create distinct work zones, such as one area for your computer and another for paperwork or creative tasks.
- Adjust the leveling glides on the bottom of each leg to ensure the desk remains stable and level on uneven floor surfaces.
- Route power cords and data cables through the integrated grommets to maintain a clutter-free and safe environment.



Figure 5.1: Typical Office Setup. The desk provides ample space for multiple monitors and office equipment.



Figure 5.2: Versatile Workspace. The desk can be adapted for various uses, including a home office or creative station.

6. MAINTENANCE

To ensure the longevity and appearance of your SHW L-Shape Corner Office Computer Desk, regular maintenance is

recommended:

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. For stubborn marks, a mild soap solution can be used, followed by drying with a clean cloth.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the particle board.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain desk stability.
- **Protection:** Use coasters for drinks and desk pads for heavy or sharp objects to protect the surface from scratches and heat.

7. TROUBLESHOOTING

If you encounter any issues with your desk, consider the following common troubleshooting steps:

- **Desk Wobbles:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling glides on the bottom of each leg to compensate for uneven flooring.
 - Verify the desk is placed on a flat, stable surface.
- **Damaged Parts Upon Arrival:**
 - Inspect all components immediately upon delivery. If any parts are damaged, contact customer support with details and photos of the damage.
- **Missing Parts:**
 - Refer to the parts list in your assembly manual. If any components are missing, contact customer support for replacements.

8. SPECIFICATIONS

Feature	Detail
Brand	SHW
Model Number	OD-005-2
Product Dimensions (D x W x H)	23.8" D x 55–60" W x 28" H
Color	Oak
Style	ArtWork
Base Material	Engineered Wood
Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Feature	Adjustable Leveling Glides, Cable Grommets
Maximum Weight Recommendation	100 Pounds (45 kg)

Item Weight	27.22 Kilograms
-------------	-----------------

9. WARRANTY AND SUPPORT

Your SHW L-Shape Corner Office Computer Desk is covered by a **10-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For warranty service, technical support, or to order replacement parts, please contact SHW customer service through their official website or the retailer where the product was purchased. Provide your model number (OD-005-2) and a detailed description of the issue to expedite service.

For more information, visit the [SHW Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question