

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Our Generation](#) /

› [Our Generation Retro Turntable Set Instruction Manual - Model BD67050D](#)

### Our Generation BD67050D

## Our Generation Retro Turntable Set Instruction Manual

Model: BD67050D

### INTRODUCTION

This manual provides instructions for the Our Generation Retro Turntable Set, model BD67050D. This set is designed as an accessory for 46 cm dolls, allowing for imaginative play scenarios. It includes a miniature turntable, a vinyl record, and a party invitation, all crafted to enhance doll playtime.

### PRODUCT CONTENTS

The Our Generation Retro Turntable Set includes the following components:

- 1 x Turntable
- 1 x Vinyl Record with Sleeve
- 1 x Party Invitation



**Image 1:** All components of the Our Generation Retro Turntable Set, including the red turntable, a yellow record sleeve with a black vinyl record, and a checkered party invitation.

## SETUP

- 1. Unpack Components:** Carefully remove all items from the packaging. Ensure all listed components are present and undamaged.
- 2. Placement:** Place the turntable on a flat, stable surface suitable for doll play.
- 3. Record Placement:** Gently place the vinyl record onto the turntable's platter.

## OPERATING INSTRUCTIONS

The Our Generation Retro Turntable Set is designed for imaginative play and does not require batteries or produce actual sound. Follow these steps for interactive play:

- 1. Open Lid:** Lift the clear plastic lid of the turntable.
- 2. Position Record:** Place the included vinyl record onto the central spindle of the turntable.
- 3. Lower Tonearm:** Gently move the red tonearm from its resting position and lower it onto the record.
- 4. Imaginative Play:** Encourage dolls to 'dance' to the 'music' or use the party invitation to create a themed play scenario.



**Image 2:** The red Our Generation Retro Turntable with a black vinyl record placed on its platter and the tonearm positioned over the record.

## MAINTENANCE

- **Cleaning:** Clean the turntable and accessories with a soft, dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the plastic.
- **Storage:** Store the set in a cool, dry place away from direct sunlight when not in use. Prolonged exposure to sunlight can cause colors to fade or plastic to warp.
- **Handling:** Handle all components gently to prevent breakage, especially the tonearm and lid.

## TROUBLESHOOTING

- **Damaged Parts:** If any part of the set appears damaged (e.g., sharp edges, broken plastic), discontinue use immediately to prevent injury.
- **Missing Components:** Refer to the 'Product Contents' section. If any components are missing upon unboxing, contact the retailer or manufacturer for assistance.

- **Functionality:** Remember that this is a toy accessory and does not have electronic functions or produce actual sound. If you expect sound, please note this product is designed for imaginative play only.

## SPECIFICATIONS

<b>Brand</b>	Our Generation
<b>Model Number</b>	BD67050D
<b>Material</b>	99% Plastic
<b>Color</b>	Multicolored
<b>UPC</b>	062243419735
<b>Components Included</b>	1 turntable, 1 vinyl record with sleeve, 1 party invitation

## SAFETY INFORMATION

**WARNING: Contains small parts. Choking hazard. Not suitable for children under 3 years.**

- Adult supervision is recommended during play.
- Keep small parts away from young children to prevent accidental ingestion.
- Inspect the product regularly for any damage or loose parts that could pose a hazard.

## WARRANTY AND SUPPORT

Warranty information for this specific product is not provided in the available documentation. For support inquiries, including questions about product defects or missing parts, please refer to the manufacturer's official website or contact their customer service directly. Please retain your proof of purchase for any potential claims.